



PLANNING FOR STORMWATER

Developing a low impact solution

ALABAMA COOPERATIVE EXTENSION SYSTEM

ALABAMA DEPARTMENT OF ENVIRONMENTAL MANAGEMENT

AUBURN UNIVERSITY

PLANNING FOR STORMWATER

Developing a low impact solution

ALABAMA COOPERATIVE EXTENSION SYSTEM

ALABAMA DEPARTMENT OF ENVIRONMENTAL MANAGEMENT

AUBURN UNIVERSITY

TABLE OF CONTENTS

CHAPTER 1: OVERVIEW

CHAPTER 2: SITE SELECTION

CHAPTER 3: LOW IMPACT DEVELOPMENT AND COMMUNITY
PLANNING

CHAPTER 4: BIORETENTION

CHAPTER 5: CONSTRUCTED STORMWATER WETLANDS

CHAPTER 6: PERMEABLE PAVEMENT

CHAPTER 7: GRASSED SWALES, INFILTRATION SWALES, AND
WET SWALES

CHAPTER 8: LEVEL SPREADERS AND GRASSED FILTER STRIPS

CHAPTER 9: RAINWATER HARVESTING

CHAPTER 10: GREEN ROOFS

CHAPTER 11: RIPARIAN BUFFERS

CHAPTER 12: RAIN GARDENS

CHAPTER 13: CURB CUTS

CHAPTER 14: DISCONNECTED DOWNSPOUTS

CLOSING THOUGHTS AND APPENDICES

APPENDIX A: STORMWATER HYDROLOGY

APPENDIX B: COMMUNITY PLANNING RESOURCES

APPENDIX C: MAINTENANCE

APPENDIX D: VEGETATION AND ALABAMA NATIVE PLANT LIST

Planning for Stormwater — *Developing a low impact solution*

CONTRIBUTING AUTHORS

Dr. Eve F. Brantley, *Extension Specialist and Associate Professor*, Department of Crop Soil and Environmental Science, Auburn University

Jessica T. R. Brown, PE, *Stormwater Specialist*, Auburn University

Katie L. Dylewski, MS, *Water Program Specialist* Auburn University

Charlene M. LeBleu, FASLA, *Associate Professor of Landscape Architecture*, Auburn University

INFORMATION TECHNOLOGY, ALABAMA COOPERATIVE EXTENSION SYSTEM AT AUBURN UNIVERSITY

Jonathan C. Davis, *Director*

Jonas Bowersock, *Manager*, Web Development and Applications

Jennifer Crickard, *Instructional Designer*

COMMUNICATIONS AND MARKETING, ALABAMA COOPERATIVE EXTENSION SYSTEM AT AUBURN UNIVERSITY

Emery J. Tschetter, *Director*

C. Bruce Dupree, *Manager*, Creative Services Unit

Deb Dupree, *TES Editor*

Kristin Hinnant, *TES Video Producer*

Maggie Lawrence, *Manager*, News Unit

Aimee Lewis, *Manager*, Marketing Unit

Donna L. Reynolds, *Communications Editor III*



Published by the Alabama Cooperative Extension System (Alabama A&M University and Auburn University), an equal opportunity educator and employer. Alabama Cooperative Extension System (Alabama A&M University and Auburn University) is committed to affirmative action, equal opportunity and the diversity of its workforce. Educational programs serve all people regardless of race, color, national origin, age, disability, sex, gender identity, marital status, family/parental status, religion, sexual orientation, political beliefs, reprisal, or because all or a part of an individual's income is derived from any public assistance program. www.aces.edu

Acknowledgements

Appreciation is extended to the reviewers who provided expertise and guidance: Barry Fagan, Earl Norton, Perry Oakes, Missy Middlebrooks, Patti Hurley, Norm Blakely, and Randy Shaneyfelt. Thanks also to those who provided guidance on stormwater control measures and vegetation considerations: Dr. Mark Dougherty, Dr. Ryan Winston, Dr. Amy Wright, Dr. Julie Price, Kerry Smith, Dr. Bob Pitt, Vernon ‘Chip’ Crockett, Jeffery Kitchens, and Rhonda Britton.

This project was partially funded by the Alabama Department of Environmental Management through a Clean Water Act Section 319 (h) nonpoint source grant provided by the U.S. Environmental Protection Agency–Region 4 to support the Alabama Nonprofit Pollution Control Program under the Coastal Zone Act Reauthorization Amendments of 1990 (CZARA), and implementation of CWA Section 319 and CWA Section 6217 Coastal NPS management actions and measures.

OVERVIEW

Alabama is blessed with abundant water resources including more than 77,000 miles of streams and rivers, diverse wetland ecosystems, coastal waters, reservoirs, and groundwater. These resources are critical for maintaining Alabama's amazing plant and animal biodiversity, drinking-water supplies, opportunities for ecotourism, water sources for irrigation, and transportation networks. The quality of water that flows through our communities is a reflection of our quality of life.



IMPORTANCE OF STORMWATER MANAGEMENT

Interest in and awareness of the need to better manage stormwater runoff in urban and suburban landscapes has increased in recent years. Multiple studies have identified the negative impacts of poorly managed post-construction stormwater on our nation's waters. As landscapes become more urbanized, there is a corresponding increase in the amount of impervious surfaces that limit the ability of stormwater to infiltrate into the ground. In some watersheds, as much as 55 percent of rainfall runs off an urban landscape that is covered by parking lots, roads, and buildings; only 15 percent of rainfall soaks into the ground. In comparison, a more natural landscape will infiltrate 45 percent of the rainfall with only 10 percent running off.

The negative environmental impacts of an increase in stormwater runoff, and subsequent peak instream flows in developed landscapes, leads to increases in its delivery of pollutants such as nutrients, pathogens, metals, and sediment.

Careful consideration of stormwater management is critical for planners, environmental program managers, elected officials, homeowners, business owners, developers, contractors, design professionals, and others; however, it is rare that these groups have an opportunity to work together in planning for future development and redevelopment, particularly on a watershed level. Low impact development or LID is an interdisciplinary systematic approach to stormwater management that, when planned, designed, constructed, and maintained appropriately, can result in improved stormwater quality, improved health of local water bodies, reduced flooding, increased groundwater recharge, more attractive landscapes, wildlife habitat benefits, and improved quality of life.

BENEFITS OF LOW IMPACT DEVELOPMENT (LID)

Low impact development minimizes runoff and employs natural processes such as infiltration, evapotranspiration (evaporation and transpiration from plants), and storage of stormwater at multiple fine-scale locations as near to the source of stormwater as possible. Successful implementation of LID recreates a more natural hydrologic cycle in a developed watershed.

The first step in LID is to consider the landscape to be developed. What are the natural features of the area that may be used or mimicked to promote stormwater infiltration, evapotranspiration, or storage? This may include sensitive areas such as steep slopes, wetlands, and streamside forests that should be retained. (See Table 1.5 in Site Selection for a checklist that developers and designers can use during construction plan review.) Understanding the opportunities and limitations of a landscape to be developed will help with the strategic placement of LID

stormwater controls at multiple locations so that stormwater is slowed, stored, and soaked in near to its point of origin.

It is critical to understand local soils, size constraints, groundwater levels, native vegetation options, and other potential constraints so that the appropriate LID stormwater controls can be selected to meet the project goals. The LID stormwater practice should be designed to effectively store, infiltrate, or spread out stormwater in its landscape setting, ideally working as a system with the other practices in the development and watershed. Understanding local hydrology and function of a specific stormwater management practice within a particular setting will make stormwater management design more efficient and cost-effective.

As with any built practice, LID requires a schedule of maintenance tasks to promote long-term pollutant removal efficiencies. The concern that this maintenance burden will be greater than conventional "grey" stormwater practices should not be a barrier – it is different maintenance, not necessarily more maintenance. In fact, the United States Environmental Protection Agency (USEPA) has noted that LID life cycle costs are usually less than traditional practices. Traditional stormwater practices may have a greater initial capital investment, use valuable land area for stormwater storage, and incur operation and maintenance costs such as dredging, inlet pumping, and residuals disposal. LID practices typically have lower initial investment but require more maintenance in the first years of establishment. Once established, they may be maintained in a manner similar to other landscaped areas. Additionally, these practices may help reduce the cost of mowing and irrigation post establishment.

Additional LID elements to include in a cost/benefit comparison include improved aesthetics, wildlife habitat, community quality of life, citizen involvement and engagement, and the pride of implementing practices that allow economic and community development to proceed with minimized impacts on water resources. These elements are part of the overall picture of LID that encourages a connection by all




Figure 1.1. Alabama river basin map. Courtesy of Donn Rodekoeh.



Figure 1.2. Auburn University Soil Resources and Conservation Class, Turf Research Unit, Auburn, AL.

stakeholders to transform stormwater into being viewed as a valuable resource.

Recently, Green Infrastructure (GI) has emerged as the term to describe planning and implementation of projects that use vegetation, soils, and natural processes to manage water and create healthier urban environments. On a broad watershed scale, GI may encourage the linking of new and existing greenways, promotion of canopy cover to assist with energy reductions and carbon sequestration, and the preservation of natural areas. As the scale becomes finer, GI encompasses the stormwater management approach recommended by LID to treat stormwater close to its source through infiltration, evapotranspiration, and storage.

Technological advances in LID are helping to fine-tune elements of the planning, design, construction, and maintenance of LID stormwater practices. This handbook presents current research and design recommendations to assist all interested groups in setting goals for their development and re-development projects. Goals may include maximizing pollutant load reductions; incorporation of low-maintenance, attractive native vegetation, and/or community involvement in

understanding connections between what we do in our landscapes and the health of local streams. We strongly recommend seeking input from all stakeholders as we move forward with LID in Alabama so that we understand what is needed to successfully achieve improved water quality and community quality of life.

REFERENCES

Arnold C. and J. Gibbons. 1991. "Impervious Surface Coverage: The Emergence of a Key Environmental Indicator." *Journal of the American Planning Association*, 62(2): 243-257.

United States Environmental Protection Agency (USEPA). Fact Sheet #1. "Benefits of LID: How LID Can Protect Your Community's Resources." Last accessed April 2017. <http://water.epa.gov/polwaste/green/upload/bbfs1benefits.pdf>


United States Environmental Protection Agency (USEPA). Fact Sheet #12. "Maintenance of Low Impact Development." Last accessed April 2017. <http://water.epa.gov/polwaste/green/upload/bbfs6maintenance.pdf>

United States Environmental Protection Agency (USEPA). "What is Green Infrastructure?" Last accessed April 2017. <http://water.epa.gov/infrastructure/greeninfrastructure>

Walsh, C. J., A. H. Roy, J. W. Feminella, P.D. Cottingham, P. M. Groffman, and R. P. Morgan II. 2001. "The Urban Stream Syndrome: Current Knowledge and the Search for a Cure." *Journal of the North American Botanical Society*, 24(3): 706 - 723.

SITE SELECTION

The selection of a site for stormwater control measure (SCM) installation is often the most important step in meeting pollutant removal goals. Site selection should follow four primary steps.



GOAL ESTABLISHMENT

Site selection should involve consideration of any constraints of a selected site and the overall project goals. Well-defined and established goals of a particular project are important to identify the best practice for a given location.

Goals may include the following:

- conservation or preservation of a site
- reduced impervious cover
- reduced impact on water resources
- water quality improvement
- use of natural features for stormwater management
- education about stormwater management or a particular practice
- demonstration of a particular SCM for technology transfer



Figure 2.1. Project partners evaluate a site, Smiths Station, AL.

Prior to implementing a structural SCM, other means of reducing impervious surfaces and minimizing runoff should be considered in meeting an established goal.

Constraint Consideration

Site layout: Create site layout to show resources and features that should be protected as well as site constraints. These include existing buffers, transplantable native vegetation, existing infrastructure, and pretreatment mechanisms.

Constraints: Establish a list of constraints for a site. This is crucial to assigning an SCM that will perform efficiently. Site constraints may be natural or man-made structures and are listed in table 2.1.

Natural Constraints

In situ soils: Use the USDA Web Soil Survey at usda.gov to identify soil map units and to make initial interpretations for potential uses and limitations of a site. Most soil map units have inclusions of other soils that may be quite different; therefore, detailed evaluations should be made at the proposed site by a professional soil scientist or soil classifier. On-site evaluations should properly identify a soil or the hydrologic soil group (HSG). The final decision for use should be made based on the detailed determination of soil series or HSG. For

NATURAL	MAN-MADE
Steep slopes	Existing infrastructure
Compacted soils	Rights of way
Jurisdictional wetlands*	Electrical lines
Stream channels*	Fiber-optic cable
100-year floodplains*	Sewer lines
Existing riparian buffers*	Water lines
Forest conservation areas*	Other utilities
Critical areas*	Roads
Endangered/threatened species*	Septic drain fields
Water table depth	Wells
Shallow depth to bedrock	

*Potential Environmental Regulatory Constraints.

a detailed list of HSG properties, see table A.3 in Appendix A: Stormwater Hydrology. A roster of Alabama Professional Soil Classifiers can be found at <http://alabamasoilclassifiers.org>

Compacted soils: These are an issue for many structural SCMs because compressed structure causes an inability to properly hold and conduct water, nutrients, and air. Compacted soils can be a result of natural forces such as rain, agricultural forces such as tillage operations or crop rotation, and urban forces such as wheel traffic, especially heavy equipment or construction traffic. Compacted soils can limit the function of SCMs, particularly practices whose primary function is stormwater infiltration. When soil is heavily compacted, it contains very few large pores and has a reduced rate of water infiltration and drainage. Once a surface layer is compacted and pore spaces are compressed, runoff occurs resulting in increased soil and water losses.

Poorly drained soils: These soils may not be suitable to practices relying on infiltration without the use of an underdrain. An infiltration test should be performed on-site to determine soil infiltration rates. (See *Rain Gardens in Retrofits/Alternatives* section for information on how to perform an infiltration test.) A double-ring infiltrometer can also be used to test soil percolation.

Steep slopes: These increase water velocities that may exceed the designed velocity for a particular practice, resulting in increased erosion and decreased

residence time and infiltration. Practices such as constructed stormwater wetlands (CSWs) that require larger land areas may not function where slopes constrict the available area for the practice site. Smaller SCMs in series that follow existing site contours may be necessary to overcome steep slopes. Slopes can be graded, but soil moving (especially if not used for another purpose on-site) can be expensive and should be considered during site selection. For the purpose of this handbook, a steep slope refers to any slope greater than 3:1.

Shallow slopes: These also can affect SCM selection. Practices that require pretreatment basins, forebays, or an elevation difference to drive the practice function (e.g., water movement throughout a practice) may be expensive to construct on flat sites. In shallow-sloped or low-relief areas, practices that require a hydraulic head may not be optimal. (*See Minimum Head under Additional Goals for more information.*)

Sun/shade tolerance: Sunlight availability limits vegetation selection or treatment of pathogens using sunlight. Practices such as bioretention and rain gardens usually function best in full sun in order to dry efficiently between rain events. Conversely, some portions of CSWs require partial shade.

Water table depth: Infiltration practices such as bioretention may be limited by water table depth. For CSWs, the seasonally high water table may be used to maintain the permanent pool elevation in the wetland.

Groundwater contamination: This is a risk for practices that intercept the water table. SCMs should never release runoff filtering a “hotspot” into groundwater. Hotspots are defined as commercial, industrial, or other operations that produce higher levels of stormwater pollutants and/or have concentrated pollutants.

Shallow depth to bedrock: SCM options can be greatly limited by a shallow depth to bedrock due to infiltration and excavation constraints. Shallow depth to bedrock may also prevent the excavation of pretreatment devices, such as forebays, or the SCM itself. When a shallow depth to bedrock is present, the site may be limited to the use of grassed filter strips, restored riparian buffers, or rooftop runoff management techniques.

Potential Environmental Regulatory Constraints

Jurisdictional wetlands: These areas support hydric soils, wetland hydrology, and hydrophytic vegetation and are connected to waters of the United States. These wetlands are regulated by the Army Corps of Engineers and require a permit (Section 404 of the Clean Water Act) to work within their proximity. SCMs that discharge or have the potential to overflow polluted effluent should not be

located in the vicinity of jurisdictional wetlands. Wetland delineation to define the wetland area may be necessary. Many local county and municipal entities have regulatory setbacks for delineated wetlands, some as much as 100 feet for designated subwatersheds.

Endangered/threatened species: Consult the Alabama Natural Heritage Program list of “Rare, Threatened, & Endangered Plants and Animals of Alabama” to determine any species of concern for the site (www.alnhp.org/track_207.pdf).

Stream channels and existing riparian buffers: Stream channels should not be impacted by LID, as this goes against the overall goal of improving and protecting water quality. Impaired watersheds, local buffer ordinances, and environmental regulations limiting development adjacent to stream channels may limit site selection. Existing riparian buffers should only be improved by the addition of an SCM to the site. Most municipalities have their own streamside buffer ordinance that limits land disturbance and construction adjacent to a waterbody.

100-year floodplains: This is the land area adjacent to a waterbody that would flood or be covered by water during a 100-year flood. These areas may affect development and SCM placement.

Forest conservation areas: Forest conservation and wildlife management areas have been created across the state to prevent habitat loss for threatened and endangered species. These areas are protected and should not be impacted during or after construction.

Alabama regulatory requirements: The National Pollutant Discharge Elimination System (NPDES) was developed in 1972 under the authority of the Clean Water Act. This program controls water pollution by regulating point sources, including but not limited to Municipal Separate Storm Sewer Systems (MS4s), construction activities, industrial activities, and multisector general permits, which involve discharge into the waters of the United States. The Water Permits Division within the United States Environmental Protection Agency (USEPA) Office of Wastewater Management leads and manages the NPDES permit program in partnership with USEPA regional offices, states, tribes, and other stakeholders. Through the NPDES program, Alabama has approval by USEPA for the State NPDES Permit Program, Regulation of Federal Facilities, the State Pretreatment Program, and General Permit.

One component of the NPDES program focuses on stormwater discharges from MS4s. Stormwater runoff is most commonly transported through MS4s and deposited in local water bodies.

This regulation was implemented in two phases:

- **Phase I (1990)** requires areas (cities/counties) with populations of 100,000 or more to obtain permit coverage for point discharges.
- **Phase II (1999)** requires small MS4s greater than 50,000 but less than 100,000 population to obtain permit coverage for their discharges.

Each jurisdiction is required to develop and implement a stormwater management plan that includes the following six minimum measures:

- public education
- illicit discharge detection and elimination
- construction
- post construction
- pollution prevention
- good housekeeping

TABLE 2.2. SIZING CRITERIA AND STANDARD DESCRIPTION	
SIZING CRITERIA	DESCRIPTION
Water quality	Treat the runoff from a minimum of 80 percent of the storms that occur in an average year. This is the runoff resulting from a rainfall depth of approximately 1-1.5 inches (first flush) depending on the location in Alabama. <i>For more information on the first flush, see Appendix A on Stormwater Hydrology.</i>
Channel protection	Provides extended detention of the 1-yr storm event released over a period of 24 hours to reduce bankfull flows and protect downstream channels from erosive velocities and unstable conditions.
Overbank flood protection	Provides peak discharge control of the 25-year storm event such that the post-development peak rate does not exceed the predevelopment rate, resulting in reduced overbank flooding.
Extreme flood protection	Evaluates the effects of the 100-year storm on the management system, adjacent property, and downstream properties and facilities. Manages the impacts of the extreme storm event through detention controls and/or floodplain management.

Georgia Stormwater Manual, 2001

A particular storm event (return period) and criteria are established for the following standards:

- remove pollutants from runoff to improve water quality
- prevent erosion of downstream streambank and channel
- provide overbank flood protection
- safely pass or reduce the runoff from extreme storm events

Table 2.2 illustrates the sizing criteria and a description for each standard.

Man-Made Constraints

Existing infrastructure is often costly to relocate or remove. Consequently, any damage to infrastructure should be avoided. Existing infrastructure may also impact factors such as soil permeability due to imported fill, area constraints and restrictions (e.g., practice size), location of the SCM on-site, and many others. Existing infrastructure should be located prior to site design by calling Alabama 89. *(For more information, visit: www.al1call.com.)*

Following are common infrastructure concerns:

Rights-of-way: These may affect SCM location, construction, and maintenance access. When ownership of the ROW is not the same as the entity charged with SCM maintenance, a Memorandum of Understanding (MOU) may be necessary to guarantee access in all phases of SCM development as well as post-construction maintenance.

Electrical lines: To allow for maintenance without interfering or damaging the SCM or electrical lines, avoid locating SCMs within 100 feet of electrical lines. Occasionally an SCM may be located within a 100-foot radius of electrical lines. In this case, maintenance practices must be scrutinized to avoid damage, and selected vegetation should not encroach vertically on electrical lines. Low-growing shrubs or herbaceous perennials are suggested when vegetation height is constrained.

Fiber-optic cable: Lines that carry data and communication may run above or below ground. Call Alabama 811 to locate any fiber-optic cable lines that may be impacted during construction or post-construction during maintenance.

Water and sewer lines: Use site plans, Alabama 811, or local utilities to locate and avoid damage to water and sewer lines. As-built plans should be used whenever possible for more accurate locations of these lines. By using Alabama 811, assurance can be given that water and sewer lines are avoided.

Irrigation lines: If found on-site, these may need to be removed and replaced following construction. Irrigation is useful in establishing plants for the practice post-construction.

Roads: Existing and future roads planned for the site should be considered during planning. Future roads may contribute additional runoff to the SCM as well as create erosion and sediment control concerns.

Septic drain fields: As a general rule, SCMs should not be sited within 25 feet of septic drain fields.

Wells: SCMs should be located a minimum of ten feet from wellheads, but local ordinances should be consulted.

ADDITIONAL GOALS

Once constraints are considered, the list of SCMs best suited for a site typically diminishes. Next, determine the treatment needs or requirements of a particular site. The treatment or capability is often determined by regulatory requirements and/or watershed impairment (e.g., peak flow control, total suspended solids reduction, nutrient removal, etc.).

Size of drainage area: This is a primary consideration in SCM selection, especially when performance relies on a permanent level of water. Practices that are designed to handle smaller flows do not perform efficiently and often cannot treat pollutants if sited at the outlet of a larger drainage area or system.

Practice size (required space): Reducing impervious surface cover has the potential to decrease SCM size for the site. Some practices, such as CSWs, require large land areas and aren't applicable in many cases. High-density areas may be a concern; width or depth of a practice may be important for function and/or safety. Various practices, although smaller in size, may be more expensive or lack maximum treatment capability compared to others.

Both the size of the drainage area and the size of the practice are shown in table 2.3.

Minimum head: For SCMs to function properly, a minimum head or elevation difference is often needed to move stormwater through the SCM. The elevation difference on-site will affect which practice is selected. For example, CSWs require more change in elevation (hydraulic head) over the length of the SCM to promote flow of water and prevent mosquito breeding habitat. Depending on existing site conditions, excavation or fill to obtain the head required may be costly.

Depth of ponding: This refers to the amount of standing water present in an SCM. Depth of ponding is used for stormwater storage and may be more or less depending on the practice. For example, bioretention practices typically have six to nine inches of ponding for a brief period of time following a rain event, but CSWs utilize various hydrologic zones and deep pools may have up to 36 inches of water at any given time. Ponded water may be a safety concern and should be considered during practice selection. Fencing may be used as long as it does not limit SCM function.

Paired practices: These may allow for treatment of larger drainage areas.

Cost: Cost of design, construction, and maintenance often determine feasibility. Consider site goals and pollutant removal efficiencies of each practice when cost may limit practices for a site.



Figure 2.2. Site selection is critical.

TABLE 2.3.
SITE SELECTION & GENERAL CHARACTERISTICS BY PRACTICE

PRACTICE	BRC	CSW	PP	GR	RH	GS, IS, WS	RB	LS, FS
Sediment	Yes	Yes	Yes	No	No	Yes	Yes	Yes
Nitrogen	Yes	Yes	Possible	No	No	Yes	Yes	Yes
Phosphorus	Yes	Yes	Yes	No	No	Yes	Yes	Yes
Metals	Yes	Yes	Yes	No	No	Yes	Yes	Yes
Pathogens	Yes	Possible	No	No	No	Yes	Yes	No
Quantity Control	Possible	Yes	Possible	Possible	Yes	No	No	No
Drainage Area	Small-Medium	Medium-Large	Small	Small	Small	Small	Small-Medium	Small
Space Required	Medium	Medium-Large	Small	Medium-Large	Small-Medium	Small	Medium-Large	Small
Construction Cost	Medium-High	Medium-High	High	High	Medium	Low	Medium	Low
Maintenance	Medium-High	Medium	Medium	Medium	Medium	Low	Low	Low
Community Acceptance	Medium-High	Medium	High	High	Medium-High	High	High	High
Habitat	Medium	High	Low	Low	N/A	Low	Medium-High	Medium

Consult recent scientific literature for updates in research and technology for more specific guidelines.

Site Sustainability

Maintenance level: When practices require extensive maintenance, identifying maintenance personnel early during planning is crucial. Some practices such as CSWs may require a high level of maintenance initially but may become low maintenance after plant establishment.

Safety: Concerns may relate to standing water on-site or to wildlife attracted to conditions in a practice. Consider who will utilize the site (humans or animals) and use this list to determine any safety concerns for long-term function and safety of the site.

Community acceptance: This is crucial for long-term adoption of LID practices. A practice with high community acceptance can easily become poorly accepted when a practice is not sited or maintained properly. Community acceptance is key to fostering feelings of ownership among community members and promoting these practices as demonstration and educational opportunities.

Habitat: Practices that rank high for habitat are likely to attract animals that may be seen as a drawback by the general public. However, such practices may also provide habitat including nesting and breeding sites for birds and other small mammals. Native vegetation also provides host plants and nectar sources for native insects and pollinators, including butterflies, bees, and moths to name a few.

Signage: Signage may be applicable, especially when practices are used as learning tools. Signage can also be directional or used as a warning when safety is a concern.




Figure 2.3. Creating a site concept is an important first step in implementing a site plan.

LOW IMPACT DEVELOPMENT AND COMMUNITY PLANNING

Low Impact Development (LID) is still a relatively new concept in Alabama. Very few plans submitted to city and county planning offices have water resource elements that specifically address LID. Moreover, LID is not consistently addressed in the comprehensive planning process.





Figure 3.1. Low Impact Development workshop, Prichard, AL.

As authorized by the Clean Water Act, the National Pollutant Discharge Elimination System (NPDES) permit program defines and regulates water pollution management measures. The program is administered by the USEPA, but in many cases the USEPA authorizes states, territories, or tribes to implement the program. Section 319(b) of the Clean Water Act requires states to develop a nonpoint source management program. The NPDES General Permit or Construction General Permit drives the use of low impact development and stormwater control measures, particularly in new development.

Smart Growth is another USEPA development strategy seeking to balance economic growth, urban renewal, and conservation. In new development, Smart Growth advocates compact, village-centered communities composed of open space, commercial areas, and affordable housing interconnected by pedestrian paths and bicycle lanes. Smart Growth stresses “walkable communities” and alternative forms of transportation which help lessen the environmental and social consequences of urban sprawl. Compact, high-density development reduces imperviousness at the watershed scale to help reduce overall stormwater runoff. USEPA encourages both LID and Smart Growth as stormwater control measures.

A HOLISTIC APPROACH TO PLANNING

Planners can support stormwater runoff mitigation by promoting development designs that reduce impervious surfaces and urban sprawl. Communities employing conservation techniques have found that natural features such as undeveloped landscapes, vegetation, and buffer zones effectively reduce and filter stormwater flows. Additional benefits include recreation, wildlife habitat, and increased property values.

LID integrates environmental considerations into each stage of development, from design to construction and post-construction. LID practices are also known to improve air quality, reduce the heat island effect, and enhance community appearance. LID measures used individually can produce measurable improvements in stormwater runoff management. Used in combination, they can help local governments and institutions address significant sources of stormwater pollution and meet NPDES stormwater regulations.

INCORPORATING LID INTO THE PLANNING PROCESS

The comprehensive plan is the cornerstone of the Alabama planning process. A comprehensive plan dictates public policy in terms of transportation, utilities, land use, recreation, and housing. The comprehensive plan typically encompasses a specific geographical area and covers a long-term time horizon. Comprehensive planning is an attempt to establish guidelines for the future growth and welfare of a community.

Local governments may also voluntarily adopt elements addressing topics of local interest. Cities and counties could adopt an optional LID element in their comprehensive plans, but few do so. Water is typically addressed only in terms of water supply. Water-quality issues are most often addressed in a separate stormwater management plan. The range of issues addressed in the comprehensive plan and areas covered is left to the decision-making body of the city or the county adopting the plan.

There are several methods to incorporate LID into comprehensive plans. One approach involves amending existing subdivision regulations to incorporate LID language on principals, goals, and policies related to land use and water. An example is the City of Semmes, Alabama, which includes watershed protection in subdivision regulations. A second approach is to add an optional water element to the comprehensive plan.

Watershed protection and management, protecting and improving water quality, and managing water resource supply and demand are components that should be addressed in comprehensive plans. LID principals, goals, and policies should be added to the jurisdictional stormwater management plan and cross-referenced between these two documents for consistency.

LID may be implemented using a specific plan overlay. Such plans are flexible and scalable by design. They are typically used to address the comprehensive development or redevelopment of a defined area (overlay zone). They include LID requirements among the standard and implementation measures applicable to the area.

CONDITIONS OF APPROVAL

One method of addressing LID early in the planning process is to develop and apply both standard and nonstandard conditions of approval. Most municipalities apply conditions of approval to development projects. These conditions often relate to a broad range of topics, including grading, drainage, landscaping, and water quality. Conditions of approval normally state what is to be done, who is to



Figure 3.2. Consensus building exercise.

do it, when it is to be done, and who is responsible for determining compliance. Conditions are applied to discretionary planning permits and subdivision maps at different levels in the approval process.

Many jurisdictions in the northeast and on the west coast of the United States have developed water-quality conditions of approval. Such conditions often relate to pollution prevention during construction and planning for the installation of post-construction structural and nonstructural water-quality control measures. Attending and speaking up at your community's comprehensive plan update review is one way to get involved in this process.

New conditions requiring consideration and planning for the implementation of LID measures should be added to the list of standard conditions of approval.

Standards should be applied as early as possible in the project approval process and repeated at subsequent levels of approval to ensure compliance, timely implementation, and long-term maintenance.

LID AND JURISDICTIONAL CODES

Jurisdictional codes can support LID in several ways. Cities and counties can adopt separate ordinances that require the use of LID principals in development projects and provide standards for their use of LID. An LID ordinance can specify when implementation plans are due and specify compliance with criteria and standards in a manual or handbook such as this document.

Existing jurisdictional codes may contain barriers to LID implementation. Many types of codes and ordinances can influence the implementation and impact of LID at varied scales. At the site scale, building codes, landscape codes, parking codes, and zoning ordinances can influence site coverage, building dimension, parking requirements, and landscaping. A variance, or legal permission from the local governing authority to depart from the code or ordinance, may be needed to implement LID under these codes.

REMOVING BARRIERS TO LID IN CURRENT CODES

Removing barriers to LID in existing codes, including zoning codes, is likely to be a time-consuming process and vary from jurisdiction to jurisdiction. Perceived barriers to implementation of LID measures are often the result of multiple requirements from multiple departments within a municipality. Not all perceived barriers need to be removed from existing codes. It may actually be easier, at least initially, to apply for a variance or use overlay zones to facilitate implementation of

LID practices in both new development and redevelopment projects. As more experience is gained with implementation of LID, the municipal ordinance could then be modified and updated to be more LID inclusive.

NEW ORDINANCES TO FACILITATE LID

A direct way to facilitate LID is to adopt a specific ordinance that requires the use of LID principals in development projects. The easiest way to write an LID ordinance is to use a “model ordinance” as a template.

A model LID ordinance for Alabama needs language that is implementable under State Code of Alabama law. Good examples include the City of Auburn, Conservation Subdivision Development Ordinance and Stream Buffer Ordinance, Semmes subdivision regulations, and Daphne Land Use and Development Ordinance. Examples of model ordinances can be found in Appendix B.

The Center for Watershed Protection Code and Ordinance Worksheet (found in Appendix B) is based on 22 model development principals for the state of Maryland published in *Better Site Design: A Handbook for Changing Development Rules in Your Community* (August 1998). This handbook is an excellent guide to facilitate local discussion on model development principals in Alabama communities striving to make their codes and ordinances more LID friendly.

CONSERVATION DEVELOPMENT

Like LID, conservation development attempts to moderate the effects of urbanization. It places an added importance on protecting aquatic habitats and other natural resources. Conservation development subdivisions are characterized by dense, clustered lots surrounding common open space. The goal is to make a small footprint, thus disturbing as little land area as possible while allowing for the maximum number of residences permitted under zoning laws.

Here developers evaluate natural topography, drainage patterns, soils, and vegetation prior to construction. Designs implement LID practices that slow, absorb, and filter stormwater runoff on-site to alleviate flooding and protect natural hydrological processes.

Conservation development provides for long-term and permanent resource protection. Conservation easements, transfer of development rights, and other “in perpetuity” mechanisms ensure that protective measures are more than just temporary. An LID Planning and Design Checklist can be used to assist

municipalities and developers in the planning and design of LID developments. (See *table 5 in Site Selection*.)

LID, LEED, AND SUSTAINABLE SITES INITIATIVE

Use of LID practices can aid in obtaining LEED (Leadership in Energy and Environmental Design) certification. LEED is an internationally recognized green building rating system. Projects that are landscape only, such as parks, cannot be LEED certified. (See *Sustainable Sites Initiative below*.)

LEED is voluntary, consensus building, and market driven. The systems are categorized by building type and divided internally into credit categories. The credit name, number, and LEED point worth are provided as well as the credit’s intent, requirements, options, and, in some cases, potential strategies.

Some credit categories have prerequisites that must be met before credit certification can be achieved. The United States Green Building Council (USGBC) provides information about all of the LEED rating systems, including prerequisites, possible credits, and points.

The USGBC administers LEED certification for all commercial and industrial projects. The certification process begins with a determination of whether LEED is right for a project. The project must then be registered, signifying intent to develop a building that meets LEED certification requirements. Resources are provided at this time to assist with the building application for certification. Once all materials are assembled, the designated LEED project administrator is eligible to submit the application online.

The two LEED rating systems most relevant to LID are LEED for New Construction and Major Renovations (including LEED for schools), and LEED for Neighborhood Development. For commercial buildings and neighborhoods to earn LEED certification, a project must satisfy all LEED prerequisites and earn a minimum 40 points on a 110-point LEED rating system scale. Homes must earn a minimum of 45 points on a 136-point scale.

The LEED for New Construction and Major Renovations Rating System is designed to guide high-performance commercial and institutional projects including offices, libraries, churches, hotels, and government buildings. The intent is to promote healthful, durable, affordable, and environmentally sound practices in building design and construction. Credit categories relating to LID include Sustainable Sites, Water Efficiency, and Materials and Resources. (See *table B.1 in Appendix B*.)

The LEED for Neighborhood Development Rating System integrates the principals of Smart Growth, urbanism, and green building into a plan that relates the neighborhood to its larger region and landscape. LEED for Neighborhood Development is designed in collaboration with the Congress for the New Urbanism and the Natural Resources Defense Council. The goal is to encourage developers to revitalize existing urban areas, reduce land consumption, reduce automobile dependence, promote pedestrian activity, improve air quality, decrease polluted stormwater runoff, and build more livable and sustainable communities for people of all income levels. Credit categories relating to LID include Smart Location and Linkage and Green Construction and Technology. (See table B.2 in Appendix B.)

The Sustainable Sites Initiative (SITES) is an interdisciplinary effort by the American Society of Landscape Architects, the Lady Bird Johnson Wildflower Center at The University of Texas at Austin, and the United States Botanic Garden to create voluntary national guidelines and performance benchmarks for sustainable land design, construction, and maintenance practices. It has Sustainable Sites Initiative Guidelines to certify sustainable landscape projects. Modeled after the LEED program, the guidelines offer certification based on the use of prerequisites and credits for specific sustainable design practices and are constantly being updated. Ratings are based on a 250-point system. A minimum of 100 credits must be earned to receive one star. Projects also must follow several prerequisites to qualify as sustainable sites. Up to 127 of these credits can be earned by following the LID site design process. (See table B.3 in Appendix B.)



Figure 3.3. Subtle reminder.

REFERENCES

- Arendt, Randall. 19912. *Conservation Design for Subdivisions: A Practical Guide to Creating Open Space Networks*. Washington, D.C.: Island Press.
- Daphne, Alabama Land Use and Development Ordinance. Last accessed: July 7, 207. <http://www.daphneal.com/wp-content/uploads/2011/08/ord-land-use.pdf>.
- Low Impact Development Center, Inc. *Low Impact Development Manual for Southern California: Technical Guidance and Site Planning Strategies*. 2010. World Wide Web. Last accessed: Feb. 13, 207. <http://www.casqa.org/LID/SoCalLID/tabid/218/Default.aspx>.
- Semmes, Alabama Suvdivision Regulations. Last accessed: July 7, 207. <http://www.cityofsemmes.org/PlanningCommission/Subdivision%20Regulations/SUBDIVISIONREGULATIONS-Adopted-Jan242012.pdf>.
- Sustainable Sites Initiative. Last accessed: Feb. 18, 207. <http://www.sustainablesites.org/>.

BIORETENTION

Bioretention cells (BRCs) remove pollutants in stormwater runoff through absorption, filtration, sedimentation, volatilization, ion exchange, and biological decomposition. A BRC is a depression in the landscape that captures and stores runoff for a short time, while providing habitat for native vegetation that is both flood and drought tolerant. BRCs are stormwater control measures (SCMs) that are similar to the homeowner practice of rain gardens. The exception is that BRCs have an underlying specialized soil media and can be designed to meet a desired stormwater quantity treatment storage volume. Peak runoff rates and runoff volumes can be reduced and groundwater can be recharged when bioretention is located in an area with the appropriate soil conditions to provide infiltration.



Bioretention is normally designed for the water quality or “first flush” event, typically the first 1–1.5 inches of rainfall, to treat stormwater pollutants. In certain situations, BRCs can also provide stream channel protection through minimizing peak discharges.

SITE SELECTION

Bioretention works well in dense, urban developments due to the flexibility of its space constraints. Conventional stormwater treatment systems may be inefficient in treating first flush events because large acreages are needed to capture the required volume of stormwater. BRCs are versatile systems, however, that store stormwater beneath the media surface, addressing the spatial constraints of ultra-urban areas.

Sizing: BRCs are most effective when used to treat small to moderate quantities of stormwater or small drainage areas that are close to the source of stormwater



Figures 4.1. and 4.2. Bioretention in Railroad Park, Birmingham, AL.

TABLE 4.1. SITE SELECTION

Quantity control	Possible
Drainage area	Small–Medium
Space required	Medium
<i>Works with:</i>	
Steep slopes	No
Shallow water table	No
Poorly drained soils	No

TABLE 4.2. GENERAL SIGNIFICANCE

Construction cost	Medium–High
Maintenance	Medium–High
Community Acceptance	Medium–High
Habitat	Medium–High
Sun/shade	Sun to Part Shade

runoff. These qualities make this SCM an excellent candidate for retrofits. (*For more information on retrofits, see Retrofits under Construction.*) The maximum drainage area recommended for bioretention is five acres, but one-half to two acres is preferred. Larger drainage areas can be treated by distributing multiple decentralized BRCs throughout a watershed. Sizing criteria may depend on the infiltration characteristics of the media, flood mitigation, and pollutant removal needs. This practice does not require a large space; however, a minimum footprint of 200 square feet is recommended, or approximately 5–8 percent, of the contributing impervious area draining to the system. BRCs perform well when treating small storm events and are well suited for small lots, such as parking lot islands, both as an initial installation practice or retrofit.

TABLE 4.3.

SITE SELECTION: CONSTRAINTS AND LIMITATIONS FOR BIORETENTION

Shallow water table	Locations where the seasonally high water table is less than six feet from the surface or less than two feet from the bottom of the cell are not suitable.
Slope	Locations with five percent or less slope are recommended; flatter locations work best.
Utilities	Call Alabama 811 before construction to locate utilities. (For more information, visit: www.al1call.com).
Unstable soils or high sediment loads	Locations that are not under active construction, changing soil conditions, or will not experience high sediment loads are recommended; clayey soils can clog media.
Continuous flow	Locations that will not experience continuous flow and are allowed to drain are recommended.

MOVIE 4.1 Bioretention explained.






Figure 4.2. Bioretention cell cross section.

Evaluating soils: Use the USDA Web Soil Survey to identify soil map units and to make initial interpretations for potential uses and limitations of a site. Since most soil map units have inclusions of other soils that may be quite different, detailed evaluations should be made at the proposed site by a professional soil scientist or soil classifier. On-site evaluations should properly identify a soil or the hydrologic soil group (HSG). The final decision for use should be made based on the detailed determination of soil series or HSG. *(For a detailed list of HSG properties, see table A.3 in Appendix A: Stormwater Hydrology.)*

In-situ soil: BRCs perform best when sited in well-drained soils such as hydrologic soil group (HSG) A or B. *(See Rain Gardens in Retrofits/Alternatives section for more information on infiltration testing.)* In particular, the internal water storage (IWS) layer requires well-drained surrounding soils to function properly. The HSG and an infiltration test will determine if a BRC is a good fit for the soils on-site.

Depth to groundwater: BRCs are suited to sites where the depth to water table is greater than six feet or where the seasonally high water table is at least two feet from the bottom of the cell to decrease the chance of groundwater contamination. BRCs or any SCM should not release runoff that filters a “hotspot” into groundwater. Hotspots are defined as commercial, industrial, or

USDA’s online Web Soil Survey (websoilsurvey.nrcs.usda.gov/app/HomePage.htm) can be used as a guide to determine the needed soil information for the site, such as the hydrologic soil group (HSG) and depth to water table.

other operations that produce higher levels of stormwater pollutants and/or have concentrated pollutants.

Site-specific constraints: The layout of a BRC depends on site-specific constraints such as underlying soils, existing vegetation, drainage, utility location, safety, sight distances, aesthetics, maintenance ease, and equipment access. Bioretention is not recommended in areas with slopes greater than five percent or where mature trees must be removed. Large trees have extensive root systems, and removing them is a time- and energy-consuming process. If BRCs are sited adjacent to “messy trees” such as sycamore, water oak, or magnolia, more frequent maintenance will be required to minimize clogging of the cell media. Messy trees have excessive leaf litter, fruiting structures, and other debris compared with other trees. A BRC should not be sited in areas where it will receive high sediment loads, as this will also lead to clogging of the cell media. The contributing drainage area should be stabilized prior to construction of all SCMs. This is especially imperative for bioretention to prevent clogging and to promote proper infiltration rates.

DESIGN

Appropriate watershed and site information should be collected before beginning the design of any SCM. Layout should consider the pretreatment device, Internal Water Storage (IWS) layer, and overflow devices. Future maintenance should also be considered, particularly access to a pretreatment device such as a forebay.

Components

The bioretention system is made up of three primary components: a pretreatment device, BRC, and an overflow or bypass structure.




Figure 4.3. Forebay cross section.

Pretreatment devices: These serve as preventative maintenance for SCMs.

Pretreatment devices slow runoff velocities, provide easier maintenance access, and reduce total suspended solids (TSS) in the system by encouraging sedimentation. If pretreatment is not used with bioretention, the mulch layer will require more frequent replacement due to sediment capture and settling on the mulch surface.

Stormwater runoff should sheet flow into a BRC. Swales, forebays, or a minimum of three-foot-wide sod filter strips are recommended as pretreatment devices for energy dissipation and an even distribution of runoff flow. When selecting a pretreatment device for bioretention, the number of inlets or directions from which stormwater will enter the cell should be considered along with maintenance access and frequency.

Grassed filter strips: These are recommended if stormwater enters the system via sheet flow over a parking lot or other impervious surface into the cell from all sides of the system (multiple inlets). The filter strip pretreatment system is made up of an eight-inch-wide strip of gravel followed by four feet of sod. (*For more information on designing filter strips, see Level Spreaders and Grassed Filter Strips in Practice section.*)

Forebay: This is the best form of pretreatment when runoff is concentrated, channelized, or constricted, such as discharge from a pipe. A forebay is an 18- to 30-inch-deep pool used in situations where standing water is not considered a safety concern. The forebay is deepest at the point of runoff entry and is shallowest at the exit point, which dissipates energy throughout the forebay and provides diffuse flow into the BRC.

Additional Components

Underdrain: A perforated pipe is used as the underdrain to promote draining of the cell completely within 48 to 96 hours. The underdrain should be placed in a three-foot bed of No. 57 aggregate at a minimum thickness of three inches, covered with six inches of No. 57 aggregate, and topped with an additional layer of No. 89 aggregate (layer thickness sbe two inches, minimum). Double-washed stone is preferred. Wrapping the underdrain pipe in a silt sock or textile is discouraged to prevent clogging from smaller silt particles. The range of pipe diameter used for



Figure 4.4. Underdrain installation in BRC at East Smiths Station Elementary School, Smiths Station, AL.

underdrains is four to eight inches. Due to the potential for clogging, multiple underdrains and cleanout pipes are recommended.

The need for underdrains is driven by permeability of the in-situ soil surrounding the BRC. In-situ soils with a saturated hydraulic conductivity less than two inches per hour require underdrains to help drain effluent from the media, which is discharged to another SCM or the stormwater conveyance network. If the saturated hydraulic conductivity is two inches per hour or greater, underdrains are not required. (*More information about the determination of saturated hydraulic conductivity and its properties can be found in Appendix A: Stormwater Hydrology.*)

Cleanout pipes: These are used to maintain the underdrain system when it is clogged. The addition of cleanout pipes can decrease future maintenance costs associated with media excavation.

Soil media type: This should be a homogenous soil mix of 85–88 percent washed sand (by volume), 8–12 percent fines (silt and clay) and 3–5 percent organic matter (hardwood mulch or other aged organic component). The mix should be uniform and free of debris greater than one-inch diameter. The amount of fines determines the percentage of other media materials. An increased fines content (12 percent) should be used when targeting a nitrogen reduction, and decreased fines content (8 percent) should be used when targeting phosphorus. (*See the construction section for information on soil testing of the BRC media.*)




Figure 4.12. Internal water storage cross section.

Ponded water should drain within 12 hours, and stormwater should infiltrate the cell to two feet below the surface within 48 hours. The pore spaces of the media should drain completely with the exception of the volume used for the internal water storage (IWS), which should drain within 96 hours (four days) based on the design storm.

Internal water storage: The IWS layer is created in the bottom of the cell by adding a 90 degree upturned elbow to the underdrain. This elbow is arranged perpendicular to the horizontal underdrain. It forces water to remain in the lower portion of the media, creating a saturated, anaerobic zone that promotes increased nitrogen reduction (through denitrification) and infiltration. The IWS layer holds water following a rain event but should drain within four days. The addition of an IWS layer may reduce the frequency of outflow in exceptionally permeable soils such as sandy soils of the coastal plains. The use of IWS also allows for temperature reduction benefits, because the coolest water is the first to exit the cell as it is pulled from the bottom of the BRC.

Similar to underdrains, the use of IWS is dependent on the permeability of the underlying soils. The underlying soils must have a hydrologic soil group (HSG) A or B with limited clay content to be effective. Media depths above the underdrain layer must be at least three feet to use IWS, with at least 12 to 18 inches separating the outlet and bowl surface depths (see internal water storage cross section). BRCs with a properly designed IWS and acceptable surrounding soil conditions may have increased nutrient reduction rates ranging from 40–60 percent nitrogen and 45–60 percent phosphorus depending on location and in-situ soil. *For more information, see the Pollutant Removal section.*

Overflow structure: BRCs are designed to use an overflow structure such as a bypass or stormwater conveyance device. This allows water in excess of the treatment volume to overflow into the existing stormwater conveyance network or to another appropriate SCM such as a filter strip, infiltration swale, level spreader/grassed filter strip system, or grassed swale. If the BRC is sited adjacent to a building or other structure, the overflow device should release overflow downhill from the building foundation to ensure that water does not pond near the structure.

Design Guidance

The following steps and equations can be used for basic BRC design.

1. Determine runoff volume to be treated (design storm).

The discrete curve number method is used to determine the runoff volume or the water quality volume required for treatment. Bioretention is a water quality SCM. These calculations do not consider water quantity or stormwater volume control. BRCs may provide some volume control, and standard calculations would apply. *(For a detailed explanation of the discrete curve number method and other methods that can be employed, please refer to Appendix A: Stormwater Hydrology.)*

Information needed in the discrete curve number method include: drainage area, pervious and impervious land area, curve numbers (CN), maximum potential retention after rainfall begins (S), precipitation depth (P), and runoff depth (Q).

The discrete curve number method is outlined in EQN 4.1 and EQN 4.2.

$$\text{EQN 4.1} \quad s = \left(\frac{1000}{CN} \right) - 10$$

$$\text{EQN 4.2} \quad Q = \frac{[P - (0.2S)]^2}{P + (0.8S)}$$

2. Determine required surface area.

A BRC is designed to hold approximately the first inch of runoff (first flush) from the entire drainage area. *(For more information on the first flush, see Appendix A: Stormwater Hydrology.)*

Ponding depths should be no more than 12 inches for safety reasons. The ponding depth is dependent on the cell's ability to drain. A deeper maximum ponding depth may be acceptable as long as drainage is confirmed and vegetation is tolerant.

To determine the required surface area (SA), an assigned average ponding depth (Avg. Pond) is divided into the required treatment volume (V), as shown in EQN 4.3. The required treatment volume (V) is equal to the runoff depth calculated in EQN 4.2.

$$EQN\ 4.3$$

$$SA = \frac{V}{Avg.\ Pond}$$

Once the required SA is determined (with existing site constraints considered), the dimensions (length and width) of the SA can be determined.

3. Determine dimensions (length and width) of the BRC based on site constraints.

Surface area (SA) is the top surface of the bioretention area. SA calculated by these equations is the minimum size required to capture the design storm event. It is recommended that no dimension should be less than ten feet to allow for vegetation and aesthetics. To prevent erosion, a side slope of 3:1 or flatter is recommended. The base of the BRC is calculated using the dimensions determined minus the side slope dimensions. The length and width of the base is determined using EQNs 4.4 and 4.5. This calculation assumes a rectangular BRC. If other shapes are used, EQN 4.4 and EQN 4.5 are not applicable.

$$EQN\ 4.4$$

$$SA = l * w \quad l = \text{length of BRC}$$

$$w = \text{width of BRC}$$

$$EQN\ 4.5$$

$$Base\ Length\ (L) = l - 2(s) \quad s = \text{side slope dimension}$$

$$Base\ Width\ (W) = w - 2(s) \quad (\text{i.e. for } 3:1 \text{ side slopes, } s = 3)$$

The calculated base length and width can be used to determine the base area. The base area is calculated using EQN 4.6.

$$EQN\ 4.6$$

$$Base\ area\ (A) = L * W$$

The base area is used to calculate soil media depths. The side slope is only applied to the bowl of BRC and affects up to the first foot of depth.

TARGET POLLUTANT	MEDIA DEPTH
Target Pollutant	Media Depth (ft)
Metals and oils	1
Pathogens	2
Nutrients	3
Temperature	4

There is no recommended media depth for TSS removal because sedimentation occurs before runoff infiltrates the BRC.

RECOMMENDED DEPTH (IN)	VEGETATION TYPE
≤24	Herbaceous perennials and grasses
≥24	Shrubs
≥38	Small trees

4. Determine soil media depth.

The soil media depth is typically determined by the pollutant to be removed and the depth of media needed to support vegetation. Table 4.4 illustrates the minimum depth of media required for pollutant removal effectiveness. Selected vegetation type for the cell may require that the media depth be greater than the depth required for pollutant removal (table 4.5).

5. Determine the quantity of BRC media and aggregates needed.

The quantity of BRC media is calculated using the base area (A) and the depth of media, washed sand, choking stone, and No. 57 stone desired (table 4.6). Quantity of a material (cubic feet) equals the depth of the material, d (feet) multiplied by the base area, A (square feet), as shown in EQN 4.7.

$$EQN\ 4.7$$

$$Quantity = A * d$$

Using EQN 4.8, the quantity in cubic feet can be converted to cubic yards. This is typically the unit of quantities when ordering material.

$$EQN\ 4.8$$

$$Quantity\ to\ order\ (yd^3) = ft^3 * 0.037037$$

6. Determine number and size of underdrains.

Depending on the permeability of in-situ soil, BRCs require underdrains to function properly. Typically four- to eight-inch pipes are used. To calculate the number of underdrains required to drain a BRC within 48 to 96 hours, EQNs 4.9, 4.10, 4.11, and 4.12 are used.

First, the total ponding (TP) is calculated using EQN 4.9.

$$\text{EQN 4.9} \\ \text{Total Ponding (TP)} = d + \text{Avg. Ponding}$$

Next, the peak inflow, Q_p , is calculated using EQN 4.10, where k is the permeability of the surrounding soil in inches per hour, TP is total ponding in feet, and d is total depth of material. The media

$$\text{EQN 4.10} \\ Q_p = \frac{k * TP}{d}$$

composition is the primary factor in determining permeability. The values determined in the infiltration test can be used for permeability.

Before the number of pipes can be determined, the flow, Q_{BRC} , must be calculated. Flow can be calculated using EQN 4.10.

$$\text{EQN 4.11} \\ Q_{BRC} = \frac{\left(\frac{Q_p}{3600}\right) * SA}{12}$$

Using a modified Manning's equation, EQN 4.12, the number of pipes is calculated.

$$\text{EQN 4.12} \\ N = \frac{16 * \left\{ \frac{Q_{BRC} * n}{s * 0.5} \right\}^{\frac{3}{8}}}{D}$$

Q_{BRC} = flow
 n = Manning's n
 s = slope
 D = diameter of pipe (in)

7. Check drawdown time.

BRCs should completely drain within 48 to 96 hours for the design rainfall volume captured. Ponded water on the surface of the cell is required to drain to two feet below the surface within a maximum of 48 hours. Using the Volume, V calculated in EQNs 4.2 and 4.3, and the flow, Q_{BRC} , calculated in EQN 4.11, the time it takes for the BRC to drain, or the drawdown time can be calculated. EQN 4.13 illustrates this calculation.

$$\text{EQN 4.13} \\ \text{Time (hr)} = \frac{\left(\frac{V}{Q_{BRC}}\right)}{3600}$$

8. Select the appropriate overflow or bypass.

Overflow devices should be sized to pass rainfall events in excess of the water quality volume. These can be attached to an existing infrastructure, or a weir can be used for overflow into a large grassed area or adjacent SCM.

BIORETENTION DESIGN EXAMPLE

For the design example, a location in central Alabama has been selected. The site is 1.6 acres total, with 0.65 acres of parking lot (curve number 98) and 0.95 acres of lawn that is in fair condition (curve number 69) draining to the BRC. The water-quality design storm event precipitation depth is 1.2" (P). The soil has an HSG B and a depth to water table greater than 6'. (For this design example numbers are rounded to two significant digits.)

- To calculate runoff, use EQNs 4.14 and 4.15 for the discrete curve number method.

$$\text{EQN 4.14} \\ S = \left(\frac{1000}{CN}\right) - 10$$

$$\text{EQN 4.15} \\ Q = \frac{[P - (0.2S)]^2}{P + (0.8S)}$$

Using the provided curve numbers (CNs), precipitation depth, and equations, the following runoff depths are determined:

Parking lot (CN=98): $S = 0.20"$, $Q = 0.99" = 0.08'$

Fair condition lawn (CN=69): $S = 4.49"$, $Q = 0.02" = 0.00'$


To determine the runoff volume, the calculated runoff depths are multiplied by their respective areas and summed. Using calculations to two significant digits, the fair condition lawn does not contribute any significant runoff volume.

$$\text{Parking lot: } 0.08 \text{ ft} * 0.65 * \left(\frac{43,560 \text{ ft}^2}{1 \text{ ac}}\right) = 2,265 \text{ ft}^3$$

Total runoff volume = 2,265 ft^3

- Calculate the surface area (SA) of the bioretention cell using EQN 16. Average ponding depth (avg. pond) is typically 9".

$$\text{EQN 4.16} \\ SA = \frac{V}{\text{Avg. Pond}}$$



$$SA = 3,020 \text{ ft}^2$$

SA should be 3%–10% of the total watershed area.

$$V = 2,265 \text{ ft}^3; \text{ avg. pond} = (9'' / (1' / 12'')) = 0.75 \text{ ft}$$

$$SA = 3,020 \text{ ft}^2$$

*SA should be 3%–10% of the total watershed area.

3. Dimensions that can be easily constructed should be prioritized. For this example, a 40' x 76' cell is to be used.

Using EQN 4.17, the length, 40' and the width 76' can be used to determine if the required SA of 3,020 ft² is met.

EQN 4.17

$$SA = (\text{length})l * (\text{width})w$$

SA = 40*76 = 3,040, which is greater than the calculated required SA of 3020 ft².

Using the dimension 40' and 76' and a side slope of 3:1, the base length and base width are calculated using EQN 4.18. To accommodate for the 9" of ponding and 3" of mulch, a 1' depth is used to calculate the base footprint.

EQN 4.18

$$\begin{aligned} \text{Base Length } (L) &= l - 2(s) = 40 - (2 * 3) = 34' \\ \text{Base Width } (W) &= w - 2(s) = 76 - (2 * 3) = 70' \end{aligned}$$

The BRC bottom surface area (A) or footprint dimension is 34' by 70'. The Base Area (A) can be calculated using EQN 4.19.

EQN 4.19

$$\text{Base Area } (A) = L * W = 34 * 70 = 2,380 \text{ ft}^2$$

4. The soil media depth chosen is 3' for nutrient removal and to support desired vegetation. See the Vegetation section for more information on vegetation design.

5. The footprint calculated in EQN 4.19 is needed to determine the quantity of media fill (aggregates) that is required.

For the design example, with a bowl depth of 12" (9" avg. Pond and an additional 3" of mulch) and 3:1 side slopes (minimum recommended), the bottom surface area of the cell is 34' x 70' (as calculated in EQN 4.19).

TABLE 4.6.

Material	Recommended Depth (in)	Amount Needed (yd ³)
Bioretention media	36 or pollutant dependent	280*
Washed sand	4	31
Choking stone	2	16
No. 57 stone	6	47

*Using 36" depth of media

For example, the bioretention media quantity was calculated using EQN 4.20.

EQN 4.20

$$\text{Quantity} = A * d = 2,380 \text{ ft}^2 * 3' = 7,140 \text{ ft}^3$$

Material quantities are usually specified in cubic yards. Using EQN 4.21, bioretention media quantity will be converted to cubic yards.

EQN 4.21

$$\begin{aligned} \text{Quantity to order } (yd^3) &= \text{ft}^3 * 0.037037 \\ 7140 * 0.037037 &= 264.44 \text{ yd}^3 \sim 265 \text{ yd}^3 \end{aligned}$$

6. The saturated hydraulic conductivity for this HSG B soil is greater than 2"/hr; therefore, underdrains are not necessary. However, a 4" perforated pipe is used in the bottom of this cell for IWS. The underdrain is connected at 1' higher than the media material stone base. Often an 18" high density polyethylene (HDPE) pipe with Nyloplast® grate is connected to an existing overflow structure.

Even though underdrains are not necessary, the following calculations illustrate underdrain calculations and drawdown time.

EQN 4.22

$$\text{Total Ponding (TP)} = d + \text{Avg. Ponding} = 36 + 9 = 45'' \text{ or } 3.75'$$

EQN 4.23

$$Q_p = \frac{k * TP}{d} = \frac{2 * 3.75}{3} = 2.5 \text{ in/hr}$$

$k = 2'' / \text{hr}$
 $TP = 3.75''$
 $d = 3'$

The flow is calculated using the peak flow Q_p and the SA calculated in EQN 4.17. (For this calculation, three significant digits are used due to the magnitude of the

EQN 4.24

$$Q_{\text{req}} = \frac{\left(\frac{Q_p}{3600}\right)}{12} * SA = \frac{(2.5 / 3600)}{12} * 3020 = 0.175 \text{ cfs}$$

variables.)

EQN 4.25

$$N = \frac{\left(16 * \left\{\frac{Q_{\text{req}} * n}{S^{0.5}}\right\}^{3/8}\right)}{D} = \frac{\left(16 * \left\{\frac{0.175 * 0.011}{0.0125^{0.5}}\right\}^{3/8}\right)}{4} = \frac{\left(16 * \left\{\frac{0.002}{0.112}\right\}^{3/8}\right)}{4} = \frac{(16 * 0.221)}{4} = 0.88$$

The number of pipes is calculated using flow Q , Manning's n , the pipe slope, and the diameter of pipe.

with $N < 1$ this confirms that an underdrain is not required.

7. **A properly designed BRC will drawdown in < 96 hours. To calculate drawdown time, use EQN 26.**

EQN 4.26

$$\text{Time (hr)} = \frac{\left(\frac{V}{Q_{\text{req}}}\right)}{3600} = \frac{\left(\frac{2265 \text{ft}^3}{0.175 \text{cfs}}\right)}{3600} = 3.6 \text{ hrs}$$

8. **A stormwater conveyance drop inlet will be raised and used as the overflow or bypass to the BRC.**

CONSTRUCTION

The BRC should be installed in a stable drainage area to minimize sediment entry into the cell. If construction is to occur nearby, the BRC should be protected from sediment clogging by lining the perimeter of the cell with silt fencing, straw bales, or other appropriate sediment control measures.

Excavation: Construction should never occur on saturated soils. Furthermore, construction of the cell should be sequenced where precipitation does not fall on the area excavated for the cell; this will decrease infiltration by causing soil surfaces to seal. Preferably, excavation should be done following several consecutive warm and dry days. If a storm is predicted prior to cell media installation, the cell should be covered.

Compaction: An excavator or backhoe with a bucket that has teeth should be used to excavate the area for the cell. The bottom of the cell should be loosened or scarified (using the teeth on the backhoe bucket to rake it) to a depth of 12 inches below the required bottom elevation, with care taken to avoid compaction. Any soil compaction on the bottom of the cell will cause future exfiltration problems, and the internal water storage (IWS) layer may not be able to drain sufficiently between rain events. An experienced operator should be hired. It is the responsibility of the designer to communicate to him the importance of minimizing compaction on the bottom of the cell and on the existing surrounding soil.

Media recipe: The BRC media "recipe" recommended is 85–88 percent washed sand (by volume), 8–12 percent fines (clay and silt), and 3–5 percent aged organics. The percentage of each media component is dependent on the target pollutant to be treated by the cell. If treating nitrogen, 12 percent fines are recommended to achieve an infiltration rate of one inch per hour. For cells low to very low regardless of the pollutant targeted. When media is used with a high phosphorus content, the BRC is likely to export phosphorus rather than reduce it. Soil media can be sent to the Auburn University Soil Testing Lab www.aces.edu/anr/soillab/ to be analyzed.

treating phosphorus and metals, 8 percent fines are suggested to achieve an infiltration rate of two inches per hour.

Soil testing: A routine soil test should be performed on a sample of the cell media prior to installation. The soil test will determine the amount of extractable phosphorus present in the media. The extractable phosphorus of the media must be

Mulch: Triple- or double-shredded hardwood mulch is recommended for BRCs because it has fewer tendencies to float away and clog overflow structures. However, other mulch types such as pine bark are acceptable when hardwood mulch is not available. Do not use grass clippings for mulch, as this increases nitrogen loading into the BRC. Mulch should be aged a minimum of six months. Using mulch that has not been properly aged or composted results in the depletion of soil nitrogen during mulch decomposition and can lead to a nitrogen deficiency in plants. Mulch inhibits weed growth, prevents erosion, encourages microorganism activity, provides a surface for excess water to evaporate, and keeps the underlying media from drying out completely during periods of drought. The mulch layer reduces cell media compaction during heavy rains and prevents the spread of fungal disease or other soil-borne pathogens that might spread by water splashing from the soil to plants. Sediment is deposited on the mulch surface as stormwater enters the BRC; thus the mulch serves as pretreatment for the cell to prevent clogging.

Retrofits: Retrofitting an existing facility with bioretention requires different design and construction techniques compared to bioretention in new developments. An IWS layer can be used in bioretention retrofits. An IWS layer reduces the amount of trenched pipe, uses fewer materials, and reduces the cost of the system outlet. This is not only economically appealing but makes retrofits an option at locations with restricted outlet depth, where the stormwater


Please review proper sediment control practices in the Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas:
<http://conservealabama.gov/uploads/general/2014->

conveyance is shallow or an overflow system is already in place. An existing infrastructure such as a catch basin can also be used as an overflow structure for retrofits.

VEGETATION

Plants installed in the BRC should be selected based on the cell media depth in accordance with table 3. In addition, plants should be tolerant of short-term flooding and extended periods of drought. Vegetation used in BRCs should be tolerant of fluctuating hydrology ranging from extremely wet during heavy rainfall conditions to extremely dry during periods of low rainfall. Most bioretention plants have a facultative (FAC) or facultative wet (FACW) wetland indicator status. FAC and FACW plants are able to withstand short duration floods and maintain root growth that increases the root surface area available for water and mineral uptake. Surrounding soil and annual rainfall will affect the vegetation selection. For example, more drought-tolerant plants should be placed in BRCs located in sandier soil conditions, as these tend to be drier compared to more clayey soil sites. (See *Appendix D: Vegetation for more information on wetland indicator status.*)

MOVIE 4.2 Plant Selection.



Plant sizes: Recommended plant container sizes include three-gallon shrubs, one-quart or larger herbaceous perennials, and trees that are at least 2.5 inches in diameter. Cost will often determine size of plants installed; younger and smaller plants are less expensive than mature, larger plants. In general, using larger containers reduces plant mortality rates since these plants have stronger root systems and may establish more quickly. Less common species may be more expensive than commonly produced plants. Prior to design, contact nurseries for a list of available species and price lists, and any available price breaks for large purchases. Inspect mulch and plants upon delivery. Make sure they are free of weed seeds to reduce future maintenance and weed removal. Also inspect them for general health, insects, and disease problems prior to installation. To aid installation, tag plants by species and lay them out according to the planting plan.

Plant establishment: Vegetation in the BRC can be planted anytime of the year; however, timing can determine water inputs necessary for plant establishment and overall chances for survival. Vegetation installation is recommended for fall because this season requires less irrigation. Planting in the spring is acceptable, but plants require more irrigation compared to a fall installation. Summer installation is not recommended because plants require weekly watering. The chance for plant mortality is greater during this time due to heat and drought. Small trees may need staking until they are established. Organic matter in the cell media aids in plant establishment and helps jump-start the nitrogen removal process.

Lime and fertilizer: The soil test performed on the bioretention media will indicate any lime requirements that should be mixed into the media prior to installation. Current findings suggest that nutrients present in stormwater runoff are sufficient to aid in establishment of plants.

Plant spacing: Space plants based on their mature plant width. In most cases, a triangular spacing grid is used so that plants are equally spaced within rows, but the rows are staggered. The triangular grid plant quantity equation can be used to estimate the number of plants per area. The equation utilizes the maximum amount of available space. It is sometimes an overestimate, as it does not take walking space or maintenance access into account. (See *chapter on Rain*

Gardens in the Retrofits/Alternatives section for more information on design using a plant quantity equation.)

It is recommended that the BRC be sketched to scale in order to place plants. Sketching using a circle template helps to eliminate overcrowding, because mature plant sizes are used. The circle template method allows the designer to design the cell at a bird's-eye or plan view. Vegetation plans using plants that colonize or reseed areas should allow for plants to spread and include extra space per plant. Empty mulched areas within the cell allow surface water evaporation from mulched surfaces, pathogen die-off, and maintenance access.

Turfgrass bioretention: Turfgrass BRCs have been used successfully, but their long-term functionality is unknown due to thatch buildup and decreased infiltration into the cell. Turfgrass BRCs should be sodded using bermudagrass or centipedegrass.

Vegetation Design Guidelines

- Do not site woody vegetation such as shrubs or trees near the inlet to the BRC.
- Abide by local landscape ordinances; this may affect the vegetation plan.
- Use a diverse plant community to decrease insect and disease infestations.
- Loosely space plants to allow for increased sunlight and pathogen die-off, if pathogens are a target pollutant.
- Do not use plants with taproots due to their potential to damage underdrain pipes.
- Do not specify noxious or invasive plants that may displace other vegetation and create dense monocultures.
- Require use of native vegetation instead of exotic plants in contract specifications. When native plants are not available, non-native ornamental varieties may be used when they are not considered invasive. Contact the Alabama Invasive Plant Council if you are unsure whether a plant is invasive (se-eppc.org/alabama).
- Use a mixture of evergreen and deciduous vegetation to ensure nutrient uptake throughout the year. Using all deciduous vegetation can result in clogging due to leaf debris inhibiting infiltration into the mulch layer and may also require more frequent maintenance.

TABLE 4.12. BIORETENTION PLANT LIST			
BOTANICAL NAME	COMMON NAME	HABIT	PREFERS
<i>Clethra alnifolia</i>	summersweet clethra	deciduous shrub	sun to part shade
<i>Conoclinium coelestinum</i>	mistflower	herbaceous perennial	sun to part shade
<i>Ilex glabra</i>	inkberry holly	evergreen shrub	part shade
<i>Ilex verticillata</i>	winterberry	deciduous shrub	sun to part shade
<i>Ilex vomitoria</i>	yaupon holly	evergreen shrub	sun to part shade
<i>Itea virginica</i>	sweetspire	deciduous shrub	sun to part shade
<i>Liatis spicata</i>	blazing star	herbaceous perennial	sun
<i>Lindera benzoin</i>	spicebush	deciduous shrub	sun to part shade
<i>Morella cerifera</i>	wax myrtle	evergreen shrub	sun to part shade
<i>Muhlenbergia capillaris</i>	muhly grass	herbaceous grass	sun to part shade
<i>Panicum virgatum</i>	switchgrass	herbaceous grass	sun to part shade
<i>Rudbeckia fulgida</i>	orange coneflower	herbaceous perennial	sun to part shade
<i>Stokesia laevis</i>	stoke's aster	herbaceous perennial	sun to part shade
<i>Vernonia gigantea</i>	giant ironweed	herbaceous perennial	sun
<i>Vernonia novboracensis</i>	New York ironweed	herbaceous perennial	sun
<i>Viburnum dentatum</i>	witherod	deciduous shrub	sun to part shade
<i>Viburnum nudum</i>	possumhaw	deciduous shrub	sun to part shade

MAINTENANCE

Clogging: The most common failure mechanism of a BRC is clogging of the cell media. The underdrain pipe can be unclogged via the cleanout pipe(s). However, if water remains ponded on the cell surface and clogging persists, it may be necessary to remove and replace the top few inches of media. Following this replacement, if the cell surface continues to remain ponded for longer than twelve hours, then the cell media is likely clogged and will need to be completely replaced. Proper siting and design reduces the potential need for complete replacement. Extended surface ponding provides favorable conditions for mosquito breeding and is detrimental to plants unaccustomed to extended flooding.

Mulch: The top one to two inches of mulch and 4 inches of media can accumulate sediment and metals. Periodic replacement of these top layers can facilitate removal of sediment-bound phosphorus and metals. Upon the need to dispose of any potentially contaminated mulch or media associated with BRCs, contact the ADEM Environmental Services Branch for guidance associated with the requirements for waste determination and disposal procedures. *For more information, call 334-271-7700 or 1-800-533-23312.*

Maintain mulch at a three-inch depth. Plants may grow roots into mulch that is too deep, which causes stress to the plant during dry weather conditions. Mulch should be replaced when it decomposes or becomes matted. Some erosion may occur at the inlet and in other areas of the cell. However, if the area is designed properly, erosion should only occur occasionally following extreme wet weather conditions. If erosion occurs frequently, the design should be reworked, and flow velocities, drainage areas, and sizing should be considered.

Plant replacement: Plants should be replaced when mortality occurs. Up to 10 percent of plants may die in the first year. Over time, survival rates should increase. Stem surfaces can be scraped using a razor blade or other sharp tool to determine whether a plant is still alive. The plant is considered to be alive when green tissue is found after scraping the stem. Dead plants are not only unsightly but can provide favorable environments for insects and diseases to overwinter.

TASK	HOW OFTEN	COMMENTS
Mulching	As needed, full replacement every 2 to 3 years	Bare areas from erosion should be replaced as necessary. Mulching can be done any time of the year, but the best time is late spring after soil has warmed. Mulch should be replaced annually if the watershed is high in heavy metals.
Re-planting	When plants die	If plants consistently suffer from mortality consider using more appropriate plant species for the area.
Weeding	Twice a year	Weeding should decrease over time as vegetation establishes.
Inspect Plants	Monthly until establishment, then twice a year	Inspect for diseased or insect infested vegetation.
Inspection	After 0.5" or greater rainfall event	Visually inspect all components including any pretreatment, pipes, or IWS where applicable.
Fertilization	At planting	Many BRCs are used in nutrient sensitive watersheds. Fertilizing beyond plant establishment will increase nutrients leaving the BRC. Additionally, proper siting and design will reduce the potential for complete replacement.
Unclog Underdrain Pipes	As needed	Ponded surface water should drain away within 12 hours or less (i.e. eliminate standing water conditions). If water remains ponded on the surface of the cell for longer than 12 hours this may indicate that the underdrain pipe or cell media is clogged.
Pruning	Annually	Pruning will help maintain plant shape. See Vegetation in Appendix D for pruning recommendations.
Sediment Removal	As needed	If sediment clogs the media, the top few inches may need to be removed and replaced. Removed sediment should be properly disposed of as it may contain toxic materials such as heavy metals. Contact the ADEM Environmental Services Branch for guidance at 334-271-7700 or 1-800-533-23312.
Trash Removal	As needed	In high traffic areas, frequent trash removal will be necessary.
Mulch Removal from Outlets	As needed	Mulch may collect in the outlet or overflow during heavy rains.

POLLUTANT REMOVAL

Bioretention pollutant removal depends on the presence of plants, microorganisms, specialized cell media, and mulch; the absence of one of these components decreases the pollutant removal efficiency associated with the BRC. Bioretention shows greater than 35 percent reduction in nutrients and a minimum of 80 percent reduction in total suspended solids (TSS). Nutrient removal is more variable compared to TSS, which is likely due to the complexities of chemical breakdown processes and the behavior of nutrients.

Total suspended solids: Although most TSS is removed through sedimentation, some suspended fine particles are removed via filtration through the top layer of media and mulch.

Total nitrogen: An IWS layer creates anaerobic conditions to facilitate reduction in nitrogen through denitrification. Nitrogen is removed 30 inches below the media surface. Nitrogen uptake by plants is increased when plant tissue is harvested frequently.

Total phosphorus: It is critical to soil-test cell media prior to installation to determine that the extractable phosphorus is low to very low, especially if phosphorus reduction is a primary concern. Research shows that phosphorus removal depends on the phosphorus content originally found in the BRC media. Media with high extractable phosphorus is likely to leach phosphorus from the BRC. Two-thirds of phosphorus is bound to sediment and is deposited on the / mulch layer and surface layer of media as stormwater enters the BRC; thus, mulch can be removed and replaced to assist in phosphorus reduction. The

SEDIMENT	NUTRIENTS		METALS	PATHOGENS
	N	P		
a. 85%	40%	45%	No Data	No Data
b. 80%	50%	60%	MOD	No Data
c. 80%	50%	60%	MOD	No Data

a. North Carolina Department of Environment and Natural Resources, 2007*
 b. City of Auburn, 2011
 c. Georgia Manual, 2001

* Research has demonstrated pollutant removal efficiencies of 60% for both N and P in the Coastal Plains.

remaining third is soluble phosphorus, which is removed at a depth of 12 inches or more below the media surface. Phosphorus has the most variable range of pollutant reduction.

Metals: Studies have shown a reduction in metals, but an average pollutant removal efficiency has not been assigned. Most metal removal occurs in the surface/mulch layer of a BRC since metals are often bound to sediments and may be removed by filtration and adsorption processes.

Pathogens: Pathogens are killed on the surface of the cell through sun exposure and drying. They can be removed throughout the cell through sedimentation and filtration. For pathogens, a range of 70–92 percent removal of fecal coliform or *E. coli* has been reported, but a pollutant removal average is not assigned.

Temperature: When temperature reduction is a goal, media depth is an important factor of planning and design. Temperature is reduced at approximately 48 inches below the media surface.

Vegetation: Vegetation in these systems has the vital role of transpiration cooling effects, nutrient uptake, and pollutant removal. Most importantly, vegetated BRCs are more efficient in breaking down, removing, and mineralizing harmful pollutants, such as hydrocarbons, pesticides, chlorinated solvents, and surfactants, compared to cells lacking vegetation. Vegetated BRCs show higher phosphorus reduction compared to nonvegetated cells. BRCs with at least 2.7 feet of media can retain up to 92 percent of phosphorus, because vegetation increases BRC media sorption (binding) capacity. Deep root systems, high growth rates, and plant maturity are reported to have the highest rates of pollutant removal.

Plant roots: Plant roots aerate soils and exude nutrients and carbon, which favors microorganism habitat and growth. Roots also contribute to chemical and physical processes that improve soil structure, increase infiltration capacity, and increase cell media permeability in the BRC.

Transpiration: Through transpiration, plants in BRCs create cooler microclimates. On a daily basis, plants can transpire amounts nearly equal to their total water content. This is significant since herbaceous and woody plants may contain up to 70 percent and 50 percent, respectively, of water in their fresh weight.

Microorganisms: Microorganisms present in the media degrade petroleum-based products as well as other organic materials such as decomposing plant leaves. Additionally, microorganisms can aid in nutrient uptake

REFERENCES

- Alabama Soil and Water Conservation Committee. 2009. *Alabama Handbook for Erosion Control, Sediment Control, and Stormwater Management on Construction Sites and Urban Areas*. Montgomery, AL.
- Atlanta Regional Commission. 2001. *Georgia Stormwater Manual*.
- Brown, R. A., W. F. Hunt, and S. G. Kennedy. 2009. *Designing Bioretention with an Internal Water Storage (IWS) Layer: Design guidance for an innovative bioretention feature*. North Carolina Cooperative Extension AG-588-19W.
- Brown, R. A., and W. F. Hunt. 2009. *Improving Exfiltration from BMPs: Research and Recommendations*. North Carolina Cooperative Extension.
- Christian, K. J., A. N. Wright, J. L. Sibley, E. F. Brantley, J. A. Howe., and C. LeBleu. 2012. "Effect of Phosphorus Concentration on Growth of *Muhlenbergia capillaris* in Flooded and Non-Flooded Conditions." *Journal of Environmental Horticulture* 30(4): 219–222.
- City of Auburn Stormwater Management Manual. 209. City of Auburn, AL.
- Davis, Allen P., William F. Hunt, Robert G. Traver, and Michael Clar. March 2009. "Bioretention Technology: An Overview of Current Practice and Future Needs." *Journal of Environmental Engineering*.



Figure 4.12. BRC three months post-installation, East Smiths Station Elementary School, Smiths Station, AL.

- Davis, Allen P. 2006. "Field Performance of Bioretention: Water Quality." *Environmental Engineering Science* 24(8): 1048–1063.
- Davis, A. P., M. Shokouhian, H. Sharma, and C. Minami. 20012. "Water Quality Improvement through Bioretention Media: Nitrogen and Phosphorus Removal." *Water Environment Research* 78(3): 284–293.
- Davis, A. P., M. Shokouhian, H. Sharma, and C. Minami. 2001. "Laboratory Study of Biological Retention for Urban Storm Water Management." *Water Environment Research* 73(1): 5–9.
- Dylewski, K. L., A. N. Wright, K. M. Tilt, and C. LeBleu. 2012. "Effect of Previous Flood Exposure on Flood Tolerance and Growth of Three Landscape Shrub Taxa Subjected to Repeated Short-Term Flooding." *Journal of Environmental Horticulture* 30:58–64.
- Dylewski, K. L., A. N. Wright, K. M. Tilt, and C. LeBleu. 209. "Effects of Short Interval Cyclic Flooding on Growth and Survival of Three Native Shrubs." *HortTechnology* 21(4): 461–4612.
- Evans, Erv. 2001. "Mulching Trees and Shrubs." *Consumer Horticulture Fact Sheet*. Raleigh, NC: NC State University Cooperative Extension. ces.ncsu.edu/depts/hort/consumer/factsheets/trees-new/text/muching.html. Accessed August 8, 2012.
- Henderson, C., M. Greenway, and I. Phillips. 20012. "Removal of dissolved nitrogen, phosphorus and carbon from stormwater biofiltration mesocosms." A. Deletic and T. Fletcher, eds. Proceedings, 7th International Conference on Urban Drainage Modeling, and 4th International Conference on Water Sensitive Urban Design, Melbourne, Australia, 2–7 April 20012.
- Hinman, C. 20012. *Low Impact Development: Technical Guidance Manual for Puget Sound*. Olympia, WA: Puget Sound Action Team, Washington State University, Pierce County Extension.
- Hunt, W. F., J. T. Smith, S. J. Jadlocki, J. M. Hathaway, P. R. Eubanks. 2007. "Pollutant Removal and Peak Flow Mitigation by a BRC in Urban Charlotte, N.C." *Journal of Environmental Engineering* 134(5): 403–407.
- Hunt, W. F., and N. White. 2001. *Designing Rain Gardens (Bio-Retention Areas)*. North Carolina Cooperative Extension AG-588-3.
- Hunt, W. F., and W. G. Lord. 20012. *Bioretention Performance, Design, Construction, and Maintenance*. North Carolina Cooperative Extension AGW-588-012.
- Jernigan, K. J., and A. N. Wright. 209. "Effect of repeated short interval flooding events on root and shoot growth of four landscape shrub taxa." *Journal of Environmental Horticulture* 29(4): 220–222.
- Li, Houn, and A. P. Davis. 2007. "Urban Particle Capture in Bioretention Media I: Laboratory and Field Studies." *Journal of Environmental Engineering* 134.
- Low Impact Development Center. Drainage–Bioretention Specifications www.lowimpactdevelopment.org/epa03/biospec.htm.
- Lucas, W. C., and M. Greenway. 2007. "Nutrient retention in vegetated and non-vegetated bioretention mesocosms." *Journal Irrigation and Drainage Engineering* 134: 12.
- North Carolina Department of the Environment and Natural Resources. 2006. Ch. 12: "Bioretention" (ch. revised 2009). *Stormwater Best Management Practices Manual*. North Carolina Division of Water Quality, Raleigh, NC.
- Passeport, E., W. F. Hunt, D. E. Line, R. A. Smith, R. A. Brown. 2009. "Field study of the ability of two grassed BRCs to reduce stormwater runoff pollution." *Journal of Irrigation and Drainage Engineering* 135(4): 505–510.
- Rendig, V., and H. Taylor. 1989. *Principles of Soil-Plant Interrelationships*. New York: McGraw-Hill Publishing Company.
- Roseen, R. M., T. P. Ballester, J. J. Houle, P. Avellaneda, J. Briggs, G. Fowler, and R. Wildey. 2009. "Seasonal Performance Variations for Storm-Water Management Systems in Cold Climate Conditions." *Journal of Environmental Engineering* 135(3): 128–136.
- Rusciano, G. M., and C. C. Obropta. 2006. "Bioretention column study: fecal coliform and total suspended solids reduction." *Transactions of the ASABE* 50(4): 1261–1269.
- US Environmental Protection Agency. 20012. Section 319 "National Monitoring Program Projects." *2006 Summer Report*. NCSU Water Quality Group, Raleigh, NC.
- US Environmental Protection Agency. 1999. *Stormwater Technology Factsheet: Bioretention*. Washington, D.C.
- US Environmental Protection Agency. 2000. *Introduction to Phytoremediation* EPA-600-R- 99-106. Cincinnati, OH.

CONSTRUCTED STORMWATER WETLAND

Other names for CSWs include constructed wetland, stormwater wetland, pocket wetland, traditional constructed stormwater wetland, and shallow marsh wetland.

Constructed stormwater wetlands (CSWs) are created wetland areas designed to treat stormwater to function similarly to natural wetlands.

These systems use complex biological, chemical, and physical processes to cycle nutrients and break down other pollutants for treatment of stormwater runoff.



Natural wetlands are often referred to as “nature’s kidneys” due to their ability to transform or filter compounds. CSWs mimic the filtration and cleansing capabilities of natural wetlands while providing temporary storage of stormwater above the permanent pool elevation (PPE). Because of this, they are often used for water-quantity control. These systems are large (unless a small CSW/pocket wetland is used) and use shallow pools, complex microtopography, and both aquatic and riparian vegetation to effectively treat stormwater. The use of CSWs or any other SCM does not promote the discharge of stormwater into natural wetlands.

Advantages

- provides visual amenity for natural community green space
- provides enhanced biodiversity and ecological benefits to urban areas
- provides flood attenuation for improved water quality, reduced erosion, and downstream habitats
- reduces peak flows downstream, decreasing sediment loads entering streams and reducing downstream bank erosion
- offers improved water quality through filtration of pollutants and nutrient uptake from plants
- offers relatively low maintenance costs

Limitations

- requires more surface area than other conventional stormwater practices; not suitable for space-limited ultra-urban environments
- may release nutrients in the fall

Quantity control	Yes
Drainage area	Medium–Large
Space required	Medium–Large
<i>Works with:</i>	
Steep slopes	No
Shallow water table	Yes
Poorly drained soils	Yes

Construction cost	Medium–High
Maintenance	Medium
Community acceptance	Medium
Habitat	High
Sun/Shade	Either

USDA’s online Web Soil Survey (<http://websoilsurvey.nrcs.usda.gov/>) can be used as a guide to determine the needed soil information for the site, such as the hydrologic soil group (HSG) and depth to water table.

- may be difficult to establish plants under a variety of flow conditions
- geese, attract which become undesirable residents, if natural buffers not included in design
- CSW water leaving the system may have higher temperatures if not properly designed
- pollutant removal efficiency rates may be lower than anticipated until vegetation is established
- construction costs higher when compared with other practices

SITE SELECTION

CSWs are not typically recommended for ultra-urban developments because they usually require more surface area (SA) than conventional stormwater control measures (SCMs). However, they may be suited to large residential, suburban, or commercial developments where space is not limited.

Evaluating soils: Use the USDA Web Soil Survey to identify soil map units and to make initial interpretations for potential uses and limitations of a site. Since most soil map units have inclusions of other soils that may be quite different, detailed evaluations should be made at the proposed site by a professional soil scientist or soil classifier. On-site evaluations should properly identify a soil or the hydrologic soil group (HSG). The final decision for use should be made

Compaction Guidelines
**based on soil permeability*

0.06–0.2 inches/hour:
minimal compaction necessary

0.2–0.6 inches/hour:
compaction necessary

>0.6 inches/hour:
needs importation of clay and/or liner

based on the detailed determination of soil series or HSG. For a detailed list of HSG properties, see table A.3 in Appendix A: Stormwater Hydrology.

In-situ soil: CSWs are appropriate for the USDA hydrologic soil group (HSG) C and D soils that have slow to very slow infiltration rates. Other soils may also work with the addition of a clay or synthetic liner, or they may be perched.

Depth to groundwater: CSWs are well suited for areas where the depth to groundwater is two feet or less. Excavation to the seasonally high water table may be used to maintain the permanent pool elevation (PPE) in the wetland.

Continuous flow: CSWs are more easily sited in areas where sufficient water or continuous base flow is present to maintain the PPE in the wetland.

Sizing: A minimum drainage area of ten acres is recommended for a CSW. Five acres or less is recommended for a small CSW. The wetland footprint will be approximately 3–5 percent of the contributing drainage area.

Commercial or industrial sites: If CSWs are sited adjacent to commercial or industrial land uses, contributing pollutants have the potential to harm fish and wildlife populations over time as these pollutants accumulate.

Perching/liners: CSWs sited in areas with HSG B or where the seasonally high water table is not near the ground surface can be perched using a clay or synthetic liner. The clay or synthetic liner should have an infiltration rate of less than 0.01 inch per hour to keep water from percolating into the surrounding soil. Synthetic liners are considered more expensive and more likely to become damaged compared to clay liners. Perching is generally riskier. Perched wetlands rely solely on stormwater to maintain the PPE, and extended drought conditions can result in vegetation losses. With or without a liner, soil compaction may be necessary to achieve the desired infiltration rate. (See callout box for *Compaction Guidelines*.)

COMMON CONSTRUCTED WETLAND VARIATIONS

Traditional constructed stormwater wetlands: CSWs have large surface areas and require a reliable source of base flow or groundwater supply to maintain hydrology to support emergent wetland plants. Deep water zones are concentrated in the forebay, deep pools, and outlet pool. The traditional CSW design is presented in this handbook. All other variations differ only slightly from this design.

Small CSW/pocket wetlands: These follow the traditional CSW design but treat much smaller drainage areas (5 to 10 acres) and are smaller systems. These systems are perfect when all site conditions are met for a CSW, but constraints limit the SA footprint. Water levels tend to fluctuate the most in a small CSW, making it more of a risk in areas prone to extreme drought conditions.

Retention basins: These are similar to the traditional design with the exception of having additional storage above the marsh. This increase in the temporary pool depth for additional vertical storage and a slightly smaller footprint limits vegetation selection, thus reducing some pollutant removal and available habitat.

Pond/Wetland systems: These systems utilize two cells for treatment. A wet pond is used to reduce sediment and incoming velocities before entering a shallow marsh wetland. The pollutant removal capability of this system is less than the traditional CSW design.

Gravel-based wetlands: This rock filter design variation uses one or more wetland treatment cells filled with gravel. The primary contributors of pollutant removal for these systems are algae and microorganism growth that occur on the gravel.

TABLE 5.3. SITE SELECTION: CONSTRAINTS AND LIMITATIONS FOR CONSTRUCTED STORMWATER WETLANDS

Drawdown	Appropriate locations should draw down 2–5 days.
Slope	No more than 8% is conducive for a CSW.
Utilities	Call 811 before construction to locate utilities. For more information visit www.al1call.com .
Minimum head	There must be an elevation difference of 2'–5' from inflow to outflow to ensure water movement throughout the wetland.
High sediment loads	Drainage areas under construction or with high sediment loads should be avoided.
Invasive vegetation	Invasive vegetation can be difficult to eradicate. See Vegetation in Appendix D for more information on invasive plant removal.
Continuous flow	Continuous flow is necessary to maintain the permanent pool elevation (PPE) in the wetland.

In-line and off-line wetlands: These are not recommended due to their potential to degrade stream habitat and quality. In-line wetlands are wetlands constructed in the stream channel. Off-line wetlands divert stream flow into a constructed wetland and then release it back into the stream. The water source for a CSW should be a combination of stormwater and groundwater interception.

DESIGN

CSWs have many components and zones; therefore, planning and site layout is even more critical for this practice compared to smaller stormwater control measures (SCMs). Components of a CSW include the forebay, inlet, deep pools (Zone 1), shallow water (Zone 2), transition zone, shallow land (Zone 3), upland (Zone 4), and the outlet structures.




Figure 5.1. Constructed stormwater wetland zones.

Maximize the distance that stormwater travels from the entrance to the exit of the CSW so that contact time in the wetland is increased to allow for greater pollutant removal. Flow paths can be enhanced using parallel berms and deep pools that are perpendicular to the flow path direction to slow water and increase residence time.




Figure 5.2. Forebay cross section.




Figure 5.3. Cross section of constructed wetland zone.

The wetland design should account for maintenance access to plants, forebay, deep pools, outlet pool, and the outlet structure. Since heavy equipment is necessary to clean out the forebay and deep pools, there must be a maintenance access road wide enough for vehicles to safely turn around.

Zone 1 (Deep Pools)

Divide the total deep pools topographic zone into several deep pools, with one at the inlet (forebay) and outflow (outlet pool) and the rest dispersed between these pools. Deep pools allow for sediment deposition, energy dissipation, and nitrate treatment. Deep pools are designed to hold water throughout the year and can provide habitat for fish and other aquatic organisms during a drought. Deep pools can be planted with floating or submerged plants that grow in standing water.

Inlet: This is the structure where flow or stormwater enters the CSW. It should be designed to handle the runoff entering the system. Inlets may be in the form of a swale, pipe, diverter box, or sheet-flow device such as a grassed filter strip. Consider the velocity of flow entering the inlet. Avoid any conveyance bends that could cause erosion or turbidity. Minimize erosion and scour through the use of armor or vegetation.

Forebay: This is a pool located at the inlet of the wetland system. It is deepest at the point of runoff entry and shallowest at the exit point. This design dissipates energy throughout the forebay and provides diffuse flow into the CSW. The primary function of the forebay is to allow large debris and sediment to settle out so that pools and ecologically sensitive areas are not clogged; flow velocity is not decreased; and sheet flow is created over the weir into the flow path

throughout the wetland. CSW forebays are not vegetated and can be up to 36 inches deep.

Deep pools: Vegetated deep pools occur between the forebay and outlet pool. They are planted with submerged, floating, and, occasionally, emergent plants. These pools can provide continuous habitat for mosquito predators such as fish that require deep standing water for survival. Dispersing deep pools throughout the wetland decreases distances fish must travel.


Outlet pool: This should not be vegetated to minimize clogging. A clogged outlet structure can result in extended flooding throughout the wetland and decreased drawdown time to the PPE. Decreased drawdown time is detrimental to wetland plants in Zone 3 (shallow land).

Transition Zone

The transition zone is located between the deep pools (excluding the forebay) and the shallow water zone. The transition from these two zones should be a gentle slope that holds six to nine inches of water at the PPE. Similarly to deep pool vegetation, few plants can tolerate the transition zone due to the increased water depth in this zone.

Zone 2

Shallow water: Also called low or shallow marsh, this zone includes all land within the wetland that has a constant level of three to six inches of water when the wetland is at its PPE. Occasional drying in this zone may occur during periods of extreme drought but should not occur on a regular basis. The purpose of the shallow water zone is to provide a continuous hydraulic connection between the inlet and outlet structures. During low flows, the shallow water channel should convey water from the inlet to the outlet pool. The water surface level in this zone is considered the PPE. Rooted herbaceous vegetation that is tolerant of constant inundation is planted in this zone.



Zone 3

Shallow land: Also called the high marsh, this is the temporary inundation zone that provides necessary storage during and after a rainfall event. This zone functions similarly to a floodplain in a natural wetland. The highest elevation of this zone is referred to as the temporary pool elevation (TPE). Rooted vegetation that is tolerant of temporary flooding and drought is present in this zone. The shallow land zone provides some shade, pollutant uptake, and wildlife habitat.

Zone 4

Upland: This zone is rarely wet and is not required for a CSW design, especially when space constraints exist. In some cases, an existing buffer can be utilized as the upland zone in the design. The upland zone can aid in tying the CSW to adjacent land. It also can be used for maintenance access or to house an observation deck. This zone should not have a slope steeper than 3:1 in order to reduce erosion, to allow for maintenance, and to support vegetation.

Outlet Structure

The outlet structure for the CSW serves three primary functions: 1) to contain the water quality volume within the wetland; 2) to release water when a rain event exceeds the first flush; and 3) to allow for manipulation of the pool elevation in order to conduct maintenance activities. It therefore should be easily accessed. The outlet contains a drawdown orifice that is placed at the top of the TPE or at lower depths to either prevent clogging or to release water at a cooler temperature. This allows the temporary pool to slowly draw down from the wetland but still retain stormwater within the wetland for a minimum of 48 hours. There should not be public access to end walls at outfall pipes since CSWs are designed to pass large rain events and can be safety hazards. These areas may require fencing or warning signs for safety depending on the location of the wetland and responsible entity.

DESIGN GUIDANCE

1. Determine the volume of runoff treated.

The volume of water typically treated by the CSW is based on the first flush of the design storm. (See Appendix A: Stormwater Hydrology for more information on first flush.) The volume of water below the PPE is constant except during extreme drought. The first flush, or design storm volume, is the volume of water stored within the PPE and the TPE. The volume of runoff treated by a CSW is determined by two different methods based on the amount of impervious cover and land use.

For areas with connected impervious and mixed land uses, the volume of runoff is calculated using the discrete curve number method. Variables needed for its use include: drainage area, pervious and impervious land area, curve numbers (CN), maximum potential retention after rainfall begins (S), precipitation depth (P), and runoff depth (Q). The method is outlined in EQNs 5.1 and 5.2. (For more information on the discrete curve number method and other methodologies, see Appendix A: Stormwater Hydrology.)

$$\text{EQN 5.1} \quad S = \left(\frac{1000}{CN} \right) - 10$$

$$\text{EQN 5.2} \quad Q = \frac{[P - (0.2S)]^2}{P + 0.8S}$$

A runoff depth is calculated for each land use with a different corresponding CN (pervious) and pervious cover.

The total volume treated, calculated in acre inches (ac-in), is determined by multiplying runoff depth, Q (in) by area and A (ac) for all surfaces, for both pervious and impervious land areas. To determine the volume in cubic feet, use EQN 5.3.

$$\text{EQN 5.3} \quad \text{Volume} = \text{ac-in} * 3680 = \text{ft}^3$$

The composite curve number method is used for areas with minimal impervious cover and a single land use. The same variables used for the discrete curve number method are used for the composite curve number method: drainage area, pervious and impervious land area, curve numbers (CN), maximum potential retention after rainfall begins (S), precipitation depth (P), and runoff depth (Q). The two areas (one pervious and one impervious) are multiplied by their corresponding CNs to calculate a product, as shown in EQN 5.4.

$$\text{EQN 5.4} \quad \begin{aligned} \text{Product}_{\text{impervious}} &= A_{\text{impervious}} * CN \\ \text{Product}_{\text{pervious}} &= A_{\text{pervious}} * CN \end{aligned}$$

A composite curve number (CCN) is calculated using the two products, as shown in EQN 5.5 where TA is total area.

$$\text{EQN 5.5} \quad \text{CNN} = \frac{(\text{Product}_{\text{impervious}} + \text{Product}_{\text{pervious}})}{TA}$$

The CCN is then used in calculating the retention after rainfall begins (S) and runoff depth (Q), shown in EQNs 5.1 and 5.2. Once runoff depth is determined in inches it can be multiplied by TA to determine a total volume in ac-in, which is converted into cubic feet using EQN 5.3.

It is important to note that to calculate the overall surface area of the wetland, it is best for volume to remain in ac-in. Depending on site conditions, either the discrete curve number method (EQNs 5.1 and 5.2) or the composite curve number method (EQNs 5.4 and 5.5) should be used. Calculating both for comparison is good design practice, but only one is to be used.

2. Determine Surface Area and Zone depth.

Since the CSW is designed to hold approximately the first 1–1.5 inches of rainfall from the entire drainage area, the SA is calculated as the volume (ac-in) divided by the allowable height (in), as shown in EQN 5.6. A maximum allowable height of 12 inches for TPE is recommended. Once SA is calculated, it is converted to square feet by multiplying the SA in acres by the conversion factor 1ac = 43,560 ft²

$$\text{EQN 5.6} \quad SA = V / h$$

Maximize the flow path from the inlet to outlet points within the CSW in order to maximize the retention time within the system. Berms and irregular shapes often can be used to obtain the optimal flow path. A 3:1 minimum length to width ratio is suggested.

Even though flow path and retention time is to be maximized, it is crucial to reduce the potential for cutoffs or changes in flow path to reduce nick points or weak areas in the topography that allow for water to short circuit the desired flow path. Deep water zones perpendicular to the flow direction and internal berms parallel to overall flow are recommended.

In contrast to other SCMs, the permanent volume of water, or water below the PPE, remains in the CSW at all times and is not part of the design calculations. This pool is maintained through natural or engineered hydrologic zones that are dependent on characteristics such as HSG, saturated hydraulic conductivity (Ksat), wetland liners, depth to water table, and many other factors.

TABLE 5.4. RECOMMENDED DISTRIBUTION FOR SURFACE AREAS OF INDIVIDUAL ZONES

ZONE	SURFACE AREA RECOMMENDATION	RECOMMENDED WATER DEPTH
Zone 1, deep pools	20%–25% of total surface area (10% allocated to forebay, remaining to other deep pools)	18"–36"
Zone 2, shallow water	40% of total surface area	3"–6"
Zone 3, shallow land	30%–40% of total surface area	12" at TPE
Zone 4, upland	This zone is optional and is not included in the surface area calculation. Determine the amount of area remaining in the overall site and use this area for upland.	This zone is rarely wet.

The SA of each zone within in the CSW is a percentage of the total SA. Table 12.4 contains a recommended distribution for SAs of individual zones. This distribution can vary depending on targeted treatment pollutant to be treated.

Deep pools (Zone 1): A deep pool should be located at the inlet (see *Forebay Cross Section*) and another at the outlet (outlet pool). A water balance using monthly rates for rainfall, infiltration, and evapotranspiration can be used to verify the depth of water in Zone 1. Conducting a water balance will help the designer to verify the probability of water following a month-long drought, with the exception of extended drought periods.

Shallow water (Zone 2): This zone should not be designed too deep; this helps to ensure plant survivability and habitat.

Shallow land (Zone 3): The depth of shallow land is equal to or less than the maximum allowable height (h) used in the SA calculation, EQN 5.7. This depth sets the elevation of the TPE and is the maximum storage volume in the CSW at any given time. If the CSW targets pathogens, the shallow land zone should comprise a large portion (40 percent of the total SA) of the wetland to allow for pathogen die-off from ultraviolet light exposure.

EQN 5.7

$$Q = N * [C_d * A * (2 * g * H)^{0.5}]$$

3. Determine the appropriate outlet structure.

This practice is unique because the outlet structure has both low- and high-capacity features.

High capacity: This feature is used to bypass storms that are in excess of the first flush volume.

Low capacity: This feature is used as a drawdown structure to slowly release the volume of water within the temporary pool over the course of two to five days.

Examples of outlet structures are shown in table 5.5. Manual drawdown valves or flashboard risers can be installed to drain the wetland for maintenance purposes.

TABLE 5.5.

HIGH CAPACITY	LOW CAPACITY
Weir box	Drawdown orifice
Broad-crested weir	
Broad-crested spillway	

For ease of maintenance, trash racks are recommended for weir boxes, and metal mesh is recommended for drawdown orifices to prevent clogging of the outlet structure. The drawdown orifice should be turned downward toward the permanent pool to ensure that it does not clog; this helps to prevent floatables from clogging the orifice.

Orifice (low capacity): Factors such as the number of orifices (N), the coefficient of discharge (Cd), area of orifice(s) [(A) (ft²)], and driving head [(H) (ft)] affect the flow that exits the system via the drawdown orifice and, ultimately, the time required to draw down the temporary pool. The flow rate leaving the orifice is calculated using the orifice equation, EQN 5.7, where g is gravity (32.2 ft/s²) and maximum head is equal to the depth of the temporary pool.

The orifice flow rate determines how quickly the temporary pool drains, with a target of two to five days drawdown time. To calculate the drawdown time, EQN 5.8 is used.

In EQN 5.8, V is the volume calculated in EQN 5.3; Q is the flow rate calculated in EQN 5.7; and time is in seconds. A simple conversion can be used to determine if the temporary pool will drain within five days.

$$\text{EQN 5.8} \quad \frac{\text{Volume}}{\text{Flowrate}} = \text{Time}$$

$$\text{EQN 5.9} \quad Q = C_w * L * H^{1.5}$$

Weir (high capacity): The weir equation, EQN 5.9, is used to determine the flow rate over a broad-crested weir or the top of a broad-crested weir box outlet structure. Characteristics of the weir, such as the weir coefficient (C_w - 3.0 for broad-crested weirs), the length of the weir [(L) (ft)], and the driving head [(H) (ft)] are used in EQN 5.9.

It is important to check the capacity of the network that the overflow will enter after leaving the CSW. Verify that the system can handle the peak flow and maximum flows anticipated from the high-capacity weir.




Figure 5.4. Concrete riser box.

MOVIE 5.1 Overview of Wetland Maintenance.



MOVIE 5.2 Wetland Maintenance.



CONSTRUCTED STORMWATER WETLAND DESIGN EXAMPLE

This design example that follows is for a small CSW planned for a site in Auburn, Alabama. The site conditions reflect ideal circumstances for a CSW with one exception: the location has a relatively small total drainage area of 1.5 acres. The soil on site is a Kinston silt clay loam series that has moderate permeability but is considered to be moderate to poorly drained, which classifies the soil as HSG D. For this design example, 0 numbers are rounded to two significant digits.

1. Determine the volume of runoff treated.

EQNs 12.10 and 12.11 are used to determine the runoff depth based on land use areas and the corresponding CNs. In addition to being relatively small, the site is predominately pervious, with 1.2 acres of pervious land; however, this land is in poor condition. Using the NRCS curve numbers found in Appendix A: Stormwater Hydrology in table A: 4, a CN for the pervious land cover is determined to be 89. For all impervious areas consisting of a parking lot, paved surfaces, and driving lanes, a CN of 98 is assigned. The precipitation depth (P) desired for the water quality storm event in the Auburn area is 1.25 inches.

$$\text{EQN 5.10} \quad S = \left(\frac{1000}{CN} \right) - 1$$

$$\text{EQN 5.11} \quad Q = \frac{[P - (0.2S)]^2}{P + 0.8S}$$

Using the provided CNs, precipitation depth, and equations, the following runoff depths are determined:

Parking lot: S = 0.20, Q = 1.04 in, 0.09 in

Poor condition pervious area: S = 1.24, Q = 0.45 in, 0.04 in

The total volume (ac-in) treated is determined by multiplying runoff depth [(Q (in))] by area [(A) (ac)] for all surfaces, pervious (different land uses) and impervious. To determine the runoff volume, the calculated runoff depths (Q) are multiplied by their respective areas and summed.

Parking lot: 1.04 in * 0.3 = 0.31 ac-in

Pervious area: 0.45 in * 1.2 = 0.45 ac-in

Total runoff volume: 0.76 ac-in

To calculate the volume in cubic feet, use EQN 5.12 to determine a volume of 2757.8 cubic feet or 2759 cubic feet.

$$\text{EQN 5.12} \quad \text{Volume} = \text{ac-in} * 3630 = \text{ft}^3$$

For areas with minimal impervious cover and a single land use, the composite curve number method should be used. However, this site has a single dominant pervious land use, and the impervious area is 20 percent of the total drainage area; therefore, the discrete curve number method is used.

To illustrate the composite curve number method, however, it is used in this example to calculate the desired volume of treatment. Using EQN 5.13, the land use areas are multiplied by their corresponding CNs to calculate a product.

$$\text{EQN 5.13} \quad \begin{aligned} \text{Product}_{\text{impervious}} &= A_{\text{impervious}} * CN \\ \text{Product}_{\text{pervious}} &= A_{\text{pervious}} * CN \end{aligned}$$

$$\text{Product}_{\text{impervious}} = 0.3 * 98 = 29.4$$

$$\text{Product}_{\text{pervious}} = 1.2 * 89 = 106.8$$

A composite curve number (CCN) is calculated using the two products, as shown in EQN 5.14 where TA is the total area.

$$\text{EQN 5.14} \quad \text{CCN} = \frac{(\text{Product}_{\text{impervious}} + \text{Product}_{\text{pervious}})}{TA}$$

$$\text{CCN} = \frac{(29.4 + 106.8)}{1.5} = 90.8 \approx 91$$

The CCN is then used to calculate the retention after rainfall begins (S) and runoff depth (Q), shown in EQNs 5.10 and 5.11.

$$\text{EQN 5.10} \quad S = \left(\frac{1000}{CN} \right) - 1$$

$$\text{EQN 5.11} \quad Q = \frac{[P - (0.2S)]^2}{P + 0.8S}$$

$$S = 0.99, Q = 0.54", 0.05'$$

Multiplying the runoff depth (Q) by the TA gives a runoff volume in ac-in. The total volume equals 0.81 ac-in. The volume can be converted into cubic feet using EQN 5.12. The total treatment volume is 2940.3 cubic feet.

Since this site has 20 percent impervious cover, the discrete curve number method volume calculation of 0.76 ac-in or 2759 cubic feet is used.

2. Determine surface area and zone depth.

Since the CSW is designed to hold approximately the first inch of rainfall (first flush) from the entire drainage area, the SA is calculated as the volume (ac-in) divided by the allowable height (in), as shown in EQN 5.15. The maximum allowable height (h) used for this site location is 9 inches.

EQN 5.15

$$SA = V/h$$

$$SA = \frac{(0.76 \text{ ac-in})}{9 \text{ in}} = 0.08 \text{ ac} = 3678.4 \text{ ft}^2$$

To convert SA calculated using EQN 5.15 into square feet, multiply the SA in acres by the conversion factor 1 ac = 43560 ft².

Next, the SAs and depths of each zone are determined. In this example, the recommendations from table 2 are followed. (All areas for zones are rounded to the nearest whole foot.)

Deep pools, Zone 1: 25 percent of the total SA (10 percent allocated to forebay, remaining to other deep pools)

Zone 1:

10 percent = 368 ft² in forebay ~radius of 11 ft

15 percent = 552 ft² allocated to other deep pools, with recommended depths of 18 in

Shallow water, Zone 2: 40% of total SA

40% = 1472 ft² for shallow water (Zone 2), with recommended depths ranging from 3–6 in

Shallow land, Zone 3: 30–40 percent of the total SA

35% = 1287 ft² for shallow land (Zone 3), with recommended depth equal to the maximum allowable height of 9 in.

Upland, Zone 4: This zone is optional and is not included in the surface area calculation. Determine the amount of area remaining in the overall site and use this area for upland. The area at the site for the proposed small CSW is approximately 5000 square feet; therefore, the remaining 1321 square feet will be used to connect Zone 3 to an upland area (Zone 4).

A liner is not necessary for this site; however, proper documentation of soil media type is strongly recommended.

3. Determine the appropriate outlet structure.

This site is adjacent to a riparian buffer, and a manufactured weir box is not necessary. A combination of high-capacity and low-capacity outlets is used to drain into the densely vegetated riparian buffer. For this site, a drawdown orifice is used to set the PPE and to draw down the temporary pool. The orifice is designed using EQN 5.16, and the following characteristics are used:

$N = 1$, $C_d = 0.6$, $g = 32.2$, $H = 0.75 \text{ ft}$, and $A = 0.003 \text{ ft}^2$ ($\frac{3}{4}$ in diameter pipe).

EQN 5.16

$$Q = N * [C_d * A * (2 * g * H)^{0.5}]$$

$$Q = 1 * [0.6 * 0.003 * (2 * 32.2 * 0.75)^{0.5}] = 0.01 \text{ cf}$$

The orifice flow rate determines how quickly the temporary pool drains, with a target of two to five days drawdown time. To calculate the drawdown time, EQN 5.17 is used.

The volume is 2759 cubic feet. The flow rate was calculated as 0.01 cfs.

EQN 5.17

$$\frac{\text{Volume}}{\text{Flowrate}} = \text{Time}$$

$$\frac{2759 \text{ ft}^3}{0.01 \text{ ft}^3 / \text{s}} = \text{Time} = 275900 \text{ s} = 76.6 \text{ hrs} = 3.2 \text{ days}$$

Size the high-capacity weir to handle the peak flow event. The length of the weir can be determined using EQN 5.18.

EQN 5.18

$$Q = C_w * L * H^{1.5}$$

CONSTRUCTION

Planning: A well-planned construction schedule and construction oversight can minimize mistakes that negatively impact wetland functions. Construction discharge permit coverage may be required and should be considered early in the planning process. The designer and contractor should make a site visit so that logistics, sequencing, safety concerns, and techniques can be discussed to minimize costs and maximize efficiency.

Surveying: Before excavation, make sure utilities are marked and the construction surveying and staking of the layout are completed to identify the zones of the wetland. During construction, check elevations of graded features often so that wetland vegetation zones do not remain too dry or too wet.

Excavation: Construct the outlet structure first to control the water level in the wetland during construction. Begin excavation at the outlet and move backward toward the inlet. Tracked excavators are recommended, especially on wet sites. Toothed buckets are recommended to avoid smearing and unintended soil compaction. A hydraulic thumb attachment for the bucket is especially useful for removing debris, placing structures, and scarifying soil surfaces.

Compaction: Take care to ensure that the appropriate level of soil compaction meets the requirements of the wetland design after construction is finished. During construction, the wetland base soil may need to be tamped to prevent excessive seepage. (See callout box for *Compaction Guidelines in the Site Selection section.*)

Surface scarification: Following excavation and soil amendment placement, prep the site for permanent vegetation installation. Use a hydraulic thumb to rough up the soil. Scarification, chiseling, or ripping the top layer of soil is recommended, especially if unintentional compaction occurred during construction or the site

Please review proper sediment control practices in the Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas: <http://conservealabama.gov/uploads/general/2014-ESC-Handbook-Vol-1.pdf>




Figure 5.5. Constructed stormwater wetland schematic.

has suffered drought conditions. Scarification helps plants establish by providing an environment conducive to root growth.

Topsoil: Add at least four-inches of topsoil to all systems (including lined systems) regardless of the hydrologic soil group (HSG). Grading should take into account the four-inch layer of topsoil to be added to the subsurface grade. Topsoil on-site may be stockpiled for final grading. Harvesting topsoil on-site is less expensive but may result in the introduction of invasive plants if they were present prior to construction.

For more information on soil test protocols, go to the Alabama Cooperative Extension System website at aces.edu. Soil Samples can be sent to the Auburn University Soil Testing Lab (www.aces.edu/anr/soillab) or other soil testing facility to be analyzed.

Soil testing: Before planting, perform a routine soil test to determine any nutrient and lime recommendations needed for plant establishment. Incorporate any organic matter, topsoil, clay liner components, or lime during or immediately following excavation.

Fertilizing: CSWs tend to lose organic matter during construction and excavation. Adding nutrients back into the soil is important not only for plant establishment but for performance. A one-time fertilizer application (top dressed on soil surface) prior to planting may be needed to aid in plant establishment, but ongoing fertilization should not be required.

Geotextile fabric: Stabilize the inlet and forebay with a layer of nonwoven geotextile fabric and riprap to dissipate energy from stormwater.

Stabilization: The wetland must be stabilized using permanent seed and appropriate mulch cover as soon as possible, but no later than 13 days from when the site is no longer undergoing active construction. A wetland hydroseed mix is recommended for initial stabilization. Soil scarification to half an inch helps to promote quick germination. Once erosion and sediment control measures are installed, they should be inspected following rainfall events to ensure that they are functioning properly.

Retrofits: CSWs are an alternative retrofit option for sediment and erosion control basins used in construction when sediment is removed and properly disposed of and the appropriate modifications are made to the basin. Retrofits can sometimes make sizing the stormwater wetland difficult due to lack of available space. In these cases, a bypass is needed so that the wetland is not inundated with a too-large volume of stormwater, which can damage or “blow out” vegetation. A good rule of thumb is that a bypass is needed if the available space to retrofit is less than 67 percent of the total SA needed for an appropriately sized wetland.

VEGETATION

Install permanent vegetation when construction is complete. Ideal plants for CSWs are native perennials and shrubs with dense root systems to trap sediments and solids. Plants must be tolerant of the stress of flooding and drying associated with these systems. Use native plants that colonize quickly. Never plant invasive species, as these can result in dense monocultures that do not foster insect, animal, or plant diversity. If an upland area exists on-site, trees may be salvaged to maintain a buffer surrounding the wetland area. Vegetation zones should be staked, flagged, or marked using marking paint for ease of plant installation. See *table 12.5 for recommended planting season guidelines for each wetland zone.*

Seeding: Seeding of the wetland alone is not recommended due to poor success rates and slow establishment. Established plants can be obtained from nurseries that carry native wetland vegetation.

Plant sizes: Recommended herbaceous plants should be a minimum of four inches tall; shrubs should be in minimum one-gallon containers; and trees should be in minimum three-gallon containers. Using larger container plants can

TABLE 5.5. PLANTING SEASON GUIDELINES

Plant Type	Recommended Planting Season
Deep pool plants, Zone 1	Spring or after last frost, preferably not in summer*
Herbaceous wetland plants, Zones 2 and 3	Spring or after last frost, preferably not in summer*
Shrubs and trees, Zones 3 and 4	Winter (when dormant), spring or after last frost, or fall, preferably not in summer*
* A fall planting season is recommended for coastal CSWs.	

yield quicker establishment, but installing larger plants is more expensive and can be time consuming.

Plant installation: In many cases, using a hydraulic auger attachment to drill holes for three-gallon plants can speed the process. Pay attention, however, to the amount of compaction that this equipment may cause.

Planting time: Time of year plays an important role in plant establishment. Most herbaceous wetland plants establish best when planted at the onset of the growing season (April to mid-June). Wetland plants need an entire growing season to accumulate root reserves needed to survive the upcoming winter. Trees and shrubs are best planted from November to mid-March. An early planting date allows plants to get acclimated before the heat and drought of summer begins.

Water level during establishment: Keep soil moist at planting, without the presence of flooded conditions, and for the first six weeks. Cyclic flooding or occasional inundation followed by aerated conditions is helpful when establishing vegetation in these systems. The soil should never completely dry out during plant establishment. Water levels throughout the wetland can be manipulated using the outlet structure to ensure that plants establish before receiving large quantities of stormwater. A common mistake is assuming that wetland plants can immediately withstand flooded conditions. These plants lack developed root systems and structural adaptations against waterlogged conditions. Leaves, stems, and other plant parts must be held above the water surface to avoid plant drowning (unless a submerged plant).

Plant spacing: This is a very important factor in a CSW vegetation plan. Planting at greater densities is more expensive but results in a more rapidly colonized

wetland. It also can reduce the chance for invasive species colonization. If greater than 60 percent plant cover is desired following the first growing season, herbaceous plants should be spaced at a minimum of three feet apart. For faster-growing herbaceous plant cover, spacing as close as 1.5 – 2 feet apart is recommended. Planting herbaceous plants three feet apart may result in a fully colonized wetland after two years of growth. Planting six feet apart may require two or more growing seasons before the wetland is considered fully functional. Planting broad-leaved emergent plants (*Sagittaria* sp. and *Pontederia* sp.) too far apart can result in the invasion and colonization of undesirable plants such as cattails (*Typha latifolia*). Space shrubs three to five (maximum) apart; three feet is preferred. Trees will volunteer in the CSW, and only two to four trees per 10,000 square feet are recommended. Plant spacing recommendations from other LID manuals and available research have been synthesized and compiled in table 9.

Shading: Some shading is desired to reduce water temperatures and to improve habitat for fish and macroinvertebrates. Trees should not be clustered together, however, and should only be planted around the perimeter of the wetland to reduce shading and discourage mosquito growth.

Nuisance species: Never plant cattails in the CSW. Though native to Alabama, cattails are considered invasive. Once they invade, they can quickly form dense mats, choking out other native vegetation. Monocultures such as cattails decrease habitats for native wildlife, resulting in decreased diversity and species richness. Canada geese are a nuisance to newly establishing plants. They dig up and disturb seedlings and increase nutrients and fecal coliforms in the wetland. Geese are attracted to open water areas, therefore a well-designed upland area can discourage them from settling in the wetland.

The following plant lists are not exhaustive, and other plants may be appropriate for use in CSWs in Alabama. Extension specialists, horticulturists, or wetland scientists should be consulted for plant recommendations outside this plant list.

MAINTENANCE

CSWs can function effectively for 20 years or longer if designed and maintained properly. Most maintenance tasks for CSWs focus on efficient hydraulic flow, plant health, aesthetics, safety, and mosquito control.

Sediment removal: Sediment depth in the forebay should be measured and recorded consistently at the same time of year using a rod or other measuring tool. A fixed sediment marker can be installed to determine when dredging is

TABLE 5.6. DEEP POOLS, ZONE 1 PLANT LIST

Botanical Name	Common Name	Habit	Prefers	Comments
<i>Nelumbo lutea</i>	American lotus	aquatic herb, floating	sun	Very cold and heat tolerant; needs lots of space once established
<i>Nuphar lutea</i> *	spadderdock	aquatic herb, floating	part shade	Can be hard to establish; attracts birds; spreads by rhizomes; colonizing
<i>Nymphaea odorata</i> *	American water lily	aquatic herb, floating	sun to shade	Can be hard to establish; waterfowl eat the buoyant seeds; good fish cover; colonizing
<i>Vallisneria americana</i>	American eelgrass	aquatic herb, submerged	sun to part shade	Grows in stoloniferous clumps; good food source for turtles and other aquatic wildlife

* Transition zone plant

Deep pool (Zone 1) plants are floating or submerged plants that have an obligate wetland indicator status and grow under continuous standing water conditions. Obligate plants always occur as hydrophytes (water-loving plants) in their native habitats. The depth of water ranging from 18 to 36 inches severely limits the number of native species that can grow in these conditions. The purpose of vegetated deep pools is to absorb nutrients from the water column, encourage sediment deposition, improve dissolved oxygen concentrations, and provide habitat or food sources for aquatic life.

necessary. Sediment removal is recommended when the functionality of the forebay has diminished, when it is half full, or when the average depth of sediment is within a foot of the water surface. Sediment removal from the outlet pool is also needed, but it will fill much slower and should be cleaned out when sediment is within one foot of the water surface.

Clogged outlet structure: Monitor the outlet structure monthly and after storm events. A clogged outlet structure can result in extended flooding throughout the wetland and decreased drawdown time to the PPE. Decreased drawdown time is detrimental to wetland plants in Zone 3 (shallow land). Floating trash and plant debris can easily clog smaller-diameter orifices, and the addition of a trash rack or grate can facilitate easier cleanout. A clogged orifice can damage wetland vegetation because the temporary pool will not draw down in the recommended two to five days. Storage volume for later storms is lost when the temporary pool is full. Turning the drawdown orifice pipe downward below the PPE can decrease maintenance frequency and ensure that it is not clogged with floating vegetation, debris, or other trash. It is important that only maintenance professionals have access to drawdown orifice pipes.

Removed sediment disposal: Once removed, sediment can be land applied on the banks of the wetland (Zone 4). Immediately stabilize it using permanent seed and appropriate mulch cover. If the wetland receives runoff from a

Botanical Name	Common Name	Habit	Prefers	Comments
<i>Lobelia cardinalis</i>	cardinal flower	herbaceous perennial	sun to shade	Butterfly and hummingbird attractant; self sows
<i>Magnolia virginiana</i>	sweetbay magnolia	evergreen to semi-evergreen tree	part shade	Attracts sweetbay silkmoths; moderate growth rate
<i>Morella cerifera</i>	wax myrtle	evergreen shrub	sun to part shade	Attracts butterflies and birds; fixes nitrogen
<i>Muhlenbergia capillaris</i>	muhly grass	native grass	sun to part shade	Flood and drought tolerant
<i>Panicum virgatum</i>	switchgrass	native grass	sun to part shade	Flood and drought tolerant
<i>Stokesia laevis</i>	Stokes' aster	herbaceous perennial	sun to part shade	Attracts butterflies
<i>Tradescantia virginiana</i>	spiderwort	herbaceous perennial	sun to shade	Attracts bees
<i>Vernonia gigantea</i>	giant ironweed	herbaceous perennial	sun to shade	Attracts bees
<i>Vernonia noveboracensis</i>	New York ironweed	herbaceous perennial	sun	Attracts birds and butterflies
<i>Viburnum dentatum</i>	arrowwood	deciduous shrub	sun to shade	Attracts butterflies
<i>Viburnum nudum</i>	possumhaw	deciduous shrub	sun to part shade	Berries consumed by birds
<i>Viburnum obovatum</i>	Walter's viburnum	evergreen shrub	part shade	Berries consumed by birds

Plants in the shallow land zone (Zone 3) are herbaceous plants or shrubs that have a facultative or facultative wet wetland indicator status. Facultative plants can occur as hydrophytes (water-loving plants) or nonhydrophytes (plants intolerant of flooding). Plants in this area should be placed in a manner that discourages public access because this zone is a critical habitat area for wildlife. However, this zone can also be used for strategic maintenance access. Establishing plants in Zone 3 can be difficult due to alternating hydroperiods (periods of time this zone remains wet) of flooded and drought conditions based on stormwater runoff entering the wetland. Plants should have robust root systems that can stabilize the area to minimize erosion that may occur after a heavy rain. Vegetation for this zone should have high wildlife value and provide food and shelter to insects (not mosquitoes), birds (not Canada geese; see Nuisance Species), and other desirable small animals.

TABLE 5.9. UPLAND, ZONE 4 PLANT LIST


Botanical Name	Common Name	Habit	Prefers	Comments
<i>Asimina parviflora</i>	dwarf pawpaw	deciduous shrub	shade	Fruit attracts small mammals
<i>Callicarpa americana</i>	beautyberry	deciduous shrub	sun to part shade	Attracts birds, rodents, butterflies, and deer
<i>Calycanthus floridus</i>	sweetshrub	deciduous shrub	part shade	Colonizing; very insect and disease resistant; adapted to many soils
<i>Cercis canadensis</i>	redbud	deciduous tree	part shade to shade	Attracts birds
<i>Cornus florida</i>	dogwood	deciduous tree	part shade to shade	Fruit attracts birds, small mammals, and deer
<i>Echinacea purpurea</i>	purple coneflower	herbaceous perennial	sun to part shade	Self sows; attracts butterflies and hummingbirds
<i>Fagus grandifolia</i>	American beech	deciduous tree	part shade to shade	Nuts attract birds, rodents, mammals; used as a nesting site and larval host for moths
<i>Fraxinus americana</i>	white ash	deciduous tree	sun to shade	Seeds attract birds; used as larval host for butterflies; used as a nesting site and for cover
<i>Liriodendron tulipifera</i>	tulip poplar	deciduous tree	sun to shade	Used as a nesting site, attracts butterflies, hummingbirds, and birds
<i>Pinus taeda</i>	loblolly pine	evergreen tree	part shade	Fast growing; used as a nesting site; seeds attract birds and small mammals
<i>Quercus alba</i>	white oak	deciduous tree	sun to shade	Acorns attract birds and rodents; attracts butterflies, and used as a larval host
<i>Rudbeckia fulgida</i>	orange coneflower	herbaceous perennial	sun to part shade	Self Sows; spreads by offsets; attracts birds
<i>Tilia americana</i>	basswood	deciduous tree	sun to shade	Attracts bees and butterflies

Upland (Zone 4) plants have either a facultative upland or upland wetland indicator status. Upland plants are almost always found in dry areas, but facultative upland plants can be found as hydrophytes (water-loving plants), although they usually occur in uplands. Many plants are tolerant of conditions present in the upland zone. Because of this the upland zone provides much biodiversity to the wetland and can provide nesting sites and other valuable wildlife habitat, food sources, and shade.

Vegetation Design Example

The following recommendations are based on a small CSW that is 3678 square feet, approximately 125 x 30 feet. Vegetation for this small CSW should be native and low maintenance. The SA breakdown is as follows:

Zone	Description	Radius (if applicable)
Forebay, Zone 1	368 ft ²	~ 11 ft
Outlet pool, Zone 1	185 ft ²	~ 8 ft
Deep pool, Zone 1	367 ft ² , ~ 185 ft ² per pool for 2 pools	~ 8 ft each
Shallow water, Zone 2	1,472 ft ²	
Shallow land, Zone 3	1,287 ft ²	



A drawing or sketch of the CSW drawn to scale is needed to lay out the vegetation plan. A specific plant list can be made using the plants listed for each zone.

Most small CSWs cannot accommodate large trees. Ornamental plants that attract butterflies may be desired if the CSW will be located in a highly visible area. Plants that tolerate the transition zone should be noted and placed appropriately between Zones 1 and 2. Moreover, plants that establish quickly or colonize should be prioritized to reduce the chance for invasive plants to move into the wetland area. Plants such as *Sparganium americanum* that tolerate flowing water should be placed appropriately in the path of flowing water in Zone 2.

Option 1: Calculate a plant quantity based on a drawing.

Outline where each species will be planted on a layout plan. Each zone can be divided into geometric shapes to calculate areas. Use the plant list for each zone to place plants throughout the zone. If plants prefer part shade, be sure that these will be shaded from afternoon sun by taller plants when established.

PLANT TYPE	RECOMMENDED QUANTITIES	RECOMMENDED ON-CENTER SPACING
Floating plants for deep pools, Zone 1	6/100 ft ²	8 ft
Herbaceous plants for shallow water and shallow land, Zones 2 and 3	25/100 ft ²	2 ft
Shrubs and small trees for shallow land and upland, Zones 3 and 4	4/100 ft ²	12.5 ft
Trees for upland, Zone 4	1/200 ft ²	100 ft

Quantities can be calculated based on the recommended spacing for each plant type as shown in table 9. Quantities shown below are suggested for maximum cover and establishment; however, depending on the vegetation budget, quantities may be more or less per square foot.


Ilex glabra will inhabit 80 square feet. Based on four per 100 square feet planting recommendations, a quantity is determined:
 $80 \text{ ft}^2 * 4 \div 100 \text{ ft}^2 = 3.24$, so 3 plants

Eupatoriadelphus fistulosus will inhabit 90 square feet. Based on 25 per 100 square feet planting recommendations, a quantity is determined:
 $90 \text{ ft}^2 * 25 \div 100 \text{ ft}^2 = 22.5$, so 22 plants

Itea virginica will inhabit 130 square feet. Based on four per 100 square feet planting recommendations, a quantity is determined:
 $130 \text{ ft}^2 * 4 \div 100 \text{ ft}^2 = 12.2$, so 5 plants

Conoclinium coelestinum will inhabit 80 square feet. Based on 25 per 100 square feet planting recommendations, a quantity is determined:

A portion of Zone 3 will be used as an example for how to calculate plant quantity:



The same process should be followed to calculate quantities for the remainder of the vegetation plan.

Option 2: Create a Landscape Drawing.

This option is only appropriate for a small CSW draining less than 1.5 acres.




This drawing, on next page, is made to scale. It shows each individual plant and is similar to a conventional landscape plan. Much like Option 1, the zones should be drawn on the plan based on the square feet per zone. After creating a plant list, each plant can be added using a circle template. The circle template is used to show the plant's size at maturity, which will help to avoid overcrowding of plants.

move into the established wetland, it is often a sign that conditions in the wetland are no longer favorable for the native plants that were previously established. For example, when submerged aquatic plants disappear, it may be a sign of diminished water clarity, increased sediment, or high turbidity since these plants rely on light penetration throughout the water column for survival.

Invasive plants: Invasive plants can be spread through seeds or other vegetative parts. When invasive plant species become established, their seeds can be easily discharged from the wetland to spread these species downstream. Certain native species may also become noxious. For example, cattails that establish themselves in CSWs adjacent to commercial or residential settings should be removed immediately due to threats of mosquitoes and decreased plant diversity. If caught early, hand removal may prove effective. However, it is very difficult to remove a large clump of cattails by hand; plus, if any portion of the plant is left, the plant will regenerate. In this case, a systemic herbicide such as glyphosate labeled for aquatic use should be wiped onto the foliage. (See *Appendix D: Vegetation for more information on using herbicides.*)

Nuisance species damage: Animals such as muskrats and beavers can damage the CSW. Muskrats feed on vegetation, and these discarded plant pieces can clog the orifice. Holes burrowed by muskrats in the outlet pool can result in increased turbidity of water leaving the system. Holes burrowed into the dam can diminish its structural integrity and be a safety issue. Fill muskrat holes during site visits. Beavers also are known to be attracted to flowing water. They can become a nuisance because they remove woody vegetation from the perimeter of the wetland and build dams throughout, which can raise water levels and damage vegetation. If muskrats or beavers become problematic, a professional trapper or relocater may be needed.

Table 5.11
Design Example Plant List

Zone 1	Zone 2	Zone 3
 <i>Nelumbo lutea</i>	 <i>Carex crinata</i>	 <i>Conoclinium coelestinum</i>
	 <i>Hibiscus moscheutos</i>	 <i>Eupatoriadelphus fistulosus</i>
	 <i>Iris virginica</i>	 <i>Lindera benzoin</i>
	 <i>Juncus effusus</i>	 <i>Lobelia cardinalis</i>
	 <i>Pontederia cordata</i> *	 <i>Ilex glabra</i>
	 <i>Sagittaria latifolia</i>	 <i>Ilex vomitoria</i>
	 <i>Saururus cernuus</i>	 <i>Itea virginica</i>
	 <i>Sparganium americanum</i>	 <i>Viburnum nudum</i>

* Transition zone plant




Figure 5.12. Landscape design for small CSW.

Maintenance history: Keep maintenance records at a single location throughout the life of the practice. Use data sheets or checklists for each inspection during site visits. Immediately repair problems noted during inspections. Maintenance professionals should note erosion, channelization, bank stability, and any sediment accumulation during inspections. It is also important to note plant distribution and wildlife presence. (See *table 12.14 Maintenance Schedule for additional recommendations.*)

POLLUTANT REMOVAL

Like a natural wetland, plants in a CSW are vital to system processes. When designed and constructed properly, CSWs have the best median pollutant removal rates for total suspended solids (TSS), nitrate-nitrogen, ammonia-nitrogen, total phosphorus, phosphate-phosphorus, and metals compared to bioretention and other stormwater control measures (SCMs). The ability of CSWs to effectively treat TSS, nutrients, and the biochemical oxygen demand (BOD) does not decrease over the life of the wetland. The CSW can be designed to meet particle-size removal efficiencies and treatment volume criteria.

Nutrients: Nutrient transformations occur in both aerobic and anaerobic processes within the CSW. The four wetland zones offer both aerobic and anaerobic soil conditions along with the organic matter or topsoil layer that provides exchange sites necessary for nutrient removal. In Zone 1, the deep pools promote an anaerobic environment associated with increased denitrification (nitrogen reduction). Transitional zones aid in nutrient removal through nitrification and denitrification cation processes. Shallow water zones have higher oxygen concentrations compared to deep pools and

TABLE 5.13. MAINTENANCE SCHEDULE

Task	How Often	Comments
Erosion Inspection	During and after major storm events for first 2 years, annually thereafter	Ruts, holes, or gullies should be repaired with soil and vegetation cover.
Inspection	After 0.5" or greater rainfall event	Visually inspect all components including forebay, weir, embankment, orifices, or channels where applicable.
Plant Inspection	Weekly for first 6 weeks, then bi-weekly for rest of first growing season; once to twice per year thereafter	Plants should be inspected and irrigated (if necessary) weekly for the first 6 weeks following plant installation. Following the first growing season, plants should be inspected twice per year for the first 3 years and once annually thereafter.
Inspect for/ Remove Pests	When the wetland is visited	Inspect for beavers, muskrats, or other pests that may inhibit flow patterns or clog the wetland. A professional trapper may need to be hired.
Dam/Embankment Inspection	Annually	A dam safety expert should inspect the embankment.
Trash Removal	Twice a year, once a week, or once a month depending on location	Trash or debris should be removed from the entire wetland area. Trash should be removed from any trash grates or debris collection mechanisms. Trash removal frequency should be tailored to the site and adjacent land use. CSWs draining commercial areas may require more frequent trash cleanup.
Remove Woody Vegetation from Dam Face	Annually	All woody plants should be removed from the dam face or emergency spillway. A dam safety expert may need to be consulted.
Sediment Removal from the Forebay	When the forebay is half full or within 1' of surface	Sediment removal may be more frequent if construction is underway in the drainage area.
Sediment Removal from Deep Pools	When they are half full or within 1' of surface	Deep pools should be dredged before a shift in vegetation or aquatic life occurs due to increased flooding within the wetland.
Sediment Removal from the Outlet Pool	When the outlet pool is half full or within 1' of surface	Sediment in the outlet pool can inhibit water from leaving the CSW, creating unintentional extended flooded conditions.
Measure Sediment in Forebay	Minimum of once a year	A rod or other tool can be used to check sediment accumulation depth.
Removal of Invasive Plants	Twice a year during the first 2 years, once a year (in spring) thereafter	Weeds or other invasive plants should be removed as they crowd and rob native plants of water, sunlight, and nutrients. Invasive species removal will decrease in frequency when native plants have dominated the CSW.
Replanting	Following the second growing season if necessary	If SA coverage has not reached a minimum of 70% following the second growing season, additional planting may be necessary.
Inspect/Unclog Orifice or Outlet Device	Once per month or following a 2" rain event	The outlet structure is clogged when Zone 3 remains flooded for more than 5 days. Check for trash in the drawdown orifice.

promote nitrification through aerobic processes.

Total suspended solids: Plant stems and pool variations create a slower laminar flow that allows the settling of particulates and sediment. This allows the CSW to treat pollutants such as phosphorus, trace metals, and hydrocarbons that are adsorbed to sediment, suspended solids, or to plant tissues. Reduction of TSS is generally at least 80 percent unless the CSW is undersized or has been improperly designed.

Undersized wetlands: Undersized wetlands may increase the velocity of inflow and cause resuspension of sediments and decreased removal of attached pollutants.

Dissolved oxygen: Water discharged from these systems may contain low concentrations of dissolved oxygen (DO) less than one milligram per liter. If this is a concern for downstream water bodies, an aerating structure may be included to create turbulence and increase DO concentrations of water exiting the wetland.

Temperature: If temperature is a concern, the drawdown orifice should draw from the bottom of the outlet structure to ensure that the coolest water is discharged. This can be especially important in protecting aquatic animal communities that require

TABLE 5.14. POLLUTANT REMOVAL TABLE

SEDIMENT	NUTRIENTS		METALS	PATHOGENS
	N	P		
a. 85%	40%	40%	No Data	No Data
b. 80%	30%	40%	50%	70%
c. 80%	30%	40%	50%	70%*
d. 80%	30%	40%	50%	70%*

a. North Carolina Department of Environment and Natural Resources, 2007
 b. City of Auburn, 2011
 c. Georgia Manual, 2001
 d. Iowa State University, 2009

* If no resident waterfowl are present

cooler water temperatures.

Vegetation: CSW plants provide attachment areas and habitat for microorganisms that serve as filtering mechanisms and aid in denitrification. Emergent plants aid in trapping and stabilizing sediment to reduce resuspension of TSS. They also can attract mosquito predators to inhibit mosquito growth. Plant roots assist in microbial breakdown or the chemical transformation of organic matter, heavy metals, and pesticides by releasing oxygen from their roots to create oxidized sediment surrounding their root systems. The rich organic layer formed through plant decomposition fosters beneficial bacterial growth and traps solids. In order to increase pollutant removal potential, it is important to consider and maintain both the health and diversity of plants in these systems.

REFERENCES

- Alabama Department of Environmental Management Field Operations Division – Water Quality Program. “Construction, Noncoal/Nonmetallic Mining and Dry Processing Less than Five Acres, Other Land Disturbance Activities, and Areas Associated with These Activities.” National Pollutant Discharge Elimination System (NPDES) Chapter 335-6-12.*
- Bonilla-Warford, C. M., and J. B. Zedler. 2002. “Potential for Using Native Plant Species in Stormwater Wetlands.” *Environmental Management*. 29:3.
- Burchell, M. R., W. F. Hunt, K. L. Bass, and J. Wright. 2010. *Stormwater Wetland Construction Guidance*. North Carolina Cooperative Extension AG-588-7.
- Carleton, J. N., T.J. Grizzard, N. Godrej, and H. Post. 2001. “Factors affecting the performance of stormwater treatment wetlands.” *Water Research*, 35(6): 1552–1562.
- Carr, D., and B. Rushton. 19912. *Integrating a Herbaceous Wetland into Stormwater Management*. Southwest Florida Water Management District Stormwater Research Program.
- Center for Watershed Protection. 19912. *Pollutant Dynamics Within Storm Water Wetlands: I. Plant Nutrient Uptake Techniques* (1): 4. Silver Spring, MD.
- City of Auburn, AL. 209. *City of Auburn Storm Water Management Manual*.
- Department of Environmental Protection Bureau of Watershed Management. 20012. “Appendix B: Pennsylvania Native Plants.” *Pennsylvania Stormwater Best Management Practices Manual*.
- Dodson, R.D. 1999. *Stormwater Pollution Control: Municipal, Industrial, and Construction NPDES Compliance*. 2nd Ed. New York: McGraw-Hill.
- Atlanta Regional Commission. 2001. *Georgia Stormwater Management Manual*.
- Hammer, D. A. (Ed.). 1989. *Constructed Wetlands for Wastewater Treatment*. Chelsea, MI: Lewis Publishers.
- Hunt, W. F., C. S. Apperson, and W. G. Lord. 20012. *Mosquito Control for Stormwater Facilities*. North Carolina Cooperative Extension AG-588-4.
- Hunt, W. F., and B. Doll. 2000. *Designing Stormwater Wetlands for Small Watersheds*. North Carolina Cooperative Extension AG-588-2.
- Hunt, W. F., and W. G. Lord. 20012. *Maintenance of Stormwater Wetlands and Wet Ponds*. North Carolina Cooperative Extension AG-588-06.
- Hunt, W. F., M. R. Burchell, J. D. Wright, and K. L. Bass. 2006. *Stormwater Wetland Design Update: Zones, Vegetation, Soil, and Outlet Guidance*. North Carolina Cooperative Extension AG-588-12.
- Iowa State University Institute for Transportation. 2009. “General Information for Stormwater Wetlands.” *Iowa Stormwater Management Manual*.
- Jones, M. P. and W. F. Hunt. 2006. *Stormwater BMPs for Trout Waters*. North Carolina Cooperative Extension AG-588-10.
- OKadlec, R. H., and R. L. Knight. 19912. *Treatment Wetlands*. Boca Raton, FL: Lewis Publishers.
- Lichvar, R. W., and P. Minkin. 2007. *Concepts and procedures for updating the national wetland plant list*. US Army Corps of Engineers, Engineer Research and Development Center ERDC/CRREL TN-08-3.
- Moore, T. L., and W.F. Hunt. 209. *Stormwater Wetlands and Ecosystem Services*. North Carolina Cooperative Extension AG-588-22.
- North Carolina Department of the Environment and Natural Resources. 2006. “*Stormwater Wetlands* “(chapter revised 2009). *Stormwater Best Management Practices Manual*. Raleigh, NC: North Carolina Division of Water Quality.
- Stevens, M., and C. Hoag. 2000. *Broad-Leaved Cattail*. Aberdeen, ID: US Department of Agriculture, Natural Resources Conservation Service.
- United States Department of Agriculture and Natural Resources Conservation Service. 19912. *Guidelines for Establishing Aquatic Plants in Constructed Wetlands*. Athens, GA: NRCS.
- United States Environmental Protection Agency. 1999. *Stormwater Technology Fact Sheet: Storm Water Wetlands*. Washington, D.C: Office of Water.
- United States Environmental Protection Agency. 19912. *Protecting Natural Wetlands: A Guide to Stormwater Best Management Practices*. Washington, D.C: Office of Water.

PERMEABLE PAVEMENT

Other names for permeable pavement include modular paving systems, enhanced porosity concrete, porous pavement, and modular plastic permeable paving. Permeable pavement is a pervious surface used in place of traditional concrete or asphalt to infiltrate stormwater.



Permeable pavement provides a volume reduction of stormwater runoff through temporary storage. It can be used to reduce peak flows and promote stormwater infiltration in urbanizing watersheds. The application of permeable pavement reduces impervious surface area runoff, which has been linked to stream bank erosion, flooding, nonpoint source pollution, and other water-quality impairments.

Permeable pavement refers to any pavement that is designed to temporarily store stormwater in a gravel base layer. Stormwater is held in the gravel base layer, or subbase, before leaving the system through exfiltration into surrounding soils or through an underdrain. These systems are suitable for residential driveways, walkways, overflow parking areas, and other low-traffic areas that might otherwise be paved as an impervious surface. Permeable pavement can be less expensive than conventional stormwater management practices (i.e., detention basins) due to the decreased need for curbs and gutters, stormwater ponds, and catch basins. The failure potential is high when these systems are not designed, constructed, or maintained properly.

TABLE 6.1. SITE SELECTION	
Quantity control	Possible
Drainage area	Small
Space required	Small
Works with:	
Steep slopes	No
Shallow water table	No
Poorly drained soils	No

SITE SELECTION

Low-traffic areas: Areas with less than 100 vehicles traveling on them per day are best suited for permeable pavements, as most types currently cannot structurally support constant traffic or heavy vehicles. When pervious concrete is sited on high-traffic areas, surface raveling or degradation can occur due to vehicles frequently driving back and forth over the surface.

TABLE 6.2. GENERAL SIGNIFICANCE	
Construction cost	High
Maintenance	Medium
Community acceptance	High
Habitat	Low
Sun / shade	Either

USDA's online Web Soil Survey (websoilsurvey.nrcs.usda.gov/app/homepage.htm) can be used as a guide to determine the needed soil information for the site, such as the hydrologic soil group (HSG) and depth-to-water table.

TABLE 6.3. SITE SELECTION: CONSTRAINTS AND LIMITATIONS FOR PERMEABLE PAVEMENT

CONSTRAINT	RECOMMENDATIONS
Insufficient subgrade infiltration rate (<0.5"/hr)	Use other SCM; poorly drained soils are not appropriate for permeable pavement.
High traffic areas	Use other SCM that can structurally support heavy vehicles, or check with manufacturer of permeable interlocking concrete pavers (PICPs) for structural support limits.
Slope	Slopes greater than 2 percent are not recommended.
High sediment loads	Permeable pavement should not experience high sediment loads that risk clogging the system.
Heavily landscaped areas adjacent	Maintenance frequency must increase when permeable pavement is sited adjacent to messy vegetation, since the system has a higher potential to clog.
Reduction in total suspended solids (TSS)	Due to the risk of surface clogging, permeable pavement is not currently designed to capture sediment or reduce TSS.

Evaluating soils: Use the USDA Web Soil Survey to identify soil map units and to make initial interpretations for potential uses and limitations of a site. Since most soil map units have inclusions of other soils that may be quite different, detailed evaluations should be made at the proposed site by a professional soil scientist or soil classifier. On-site evaluations should properly identify a soil or the hydrologic soil group (HSG). The final decision for use should be made based on the detailed determination of soil series or HSG. (*For a detailed list of HSG properties, see table A.3 in Appendix A: Stormwater Hydrology.*)




Figure 6.1. Pervious paving diagram. (Graphic courtesy of Dwane Jones, North Carolina State University.)

In-situ soil: Soils should have a minimum infiltration rate of half an inch per hour as determined by an infiltration test at the initial site visit. (See section on Rain Gardens for more information on an infiltration test.) Use an underdrain when

soils have an infiltration rate of less than or equal to one inch per hour. Suitable soils for this practice are well drained and have a texture no finer than a loamy, very fine sand. Sandy soils are preferred for permeable pavements because finer-textured clay soils do not provide enough structural support. To compensate for clay soils, the gravel base layer can be thicker, providing increased structural support. Placing permeable pavement on fine-textured soils (high clay content) can also result in standing water on the surface of the pavement due to inhibited infiltration; this will degrade the surface over time and pose a safety hazard. United States Department of Agriculture (USDA) and Natural Resources Conservation Service (NRCS) hydrologic soil groups (HSG) C and D are not appropriate for permeable pavements, as these usually have greater than 30 percent clay content and are not well drained. Design sites with a high clay content of 20 percent or more with adequate underdrains.

Depth to groundwater: The runoff volume captured by the system should drain away from the underlying soil within 24 to 48 hours. Additionally, the seasonally high water table should be a minimum of two feet below the permeable pavement base to allow water to properly exfiltrate from the system and to avoid leaching of captured pollutants into groundwater. To prevent groundwater contamination, permeable pavement is not recommended to treat runoff from a “hotspot,” industrial, or commercial area that may have potentially high concentrations of soluble pollutants or pesticides.

Commercial or industrial sites: Areas considered unsuitable for treatment using these systems include: commercial plant nurseries, industrial rooftops, fueling stations, marinas, loading or unloading zones, vehicle service or maintenance areas, public works storage areas, auto recycle facilities, and similar locations.

Impervious surface area: Runoff directed to permeable pavement should be from impervious surface areas. The ratio of impervious surface area to the permeable pavement surface area should not be greater than 3:1.

Site-specific constraints: Permeable pavement should be sited at least ten feet downslope from buildings and 100 feet from drinking-water wells.

Slope: Slopes greater than 2 percent are not recommended for permeable pavement. In some jurisdictions, recommendations are less stringent, such as Knox County, Tennessee (no greater than 5 percent) and North Carolina (6 percent slope or less; less than 0.5 percent bottom slope.) Steep slopes can limit storage capacity of

permeable pavement systems; however, partitions or baffles can be used to terrace the subgrade to promote infiltration throughout the entire system.

Adjacent vegetation: Vegetated or other nearby pervious surfaces should be stabilized and not contribute sediment to the permeable pavement surface. Heavily wooded areas adjacent to permeable pavement systems can also be problematic due to excessive debris such as sticks and leaves being ground into the pavement by vehicles and foot traffic. For the same reason, permeable pavement should not be sited near or under extremely messy or high-maintenance vegetation. Designers of these systems should be aware that siting permeable pavement near vegetation results in increased maintenance, especially during fall and winter months.

COMMON PERMEABLE PAVEMENT VARIATIONS

Permeable pavements have similar layers of structural support storage and filtering mechanisms including a choker course, subbase layer (reservoir), filter fabric, and underlying soil. The primary difference in each type of permeable pavement cross section is the top layer or the specific type of porous material selected.

Pervious concrete (PC): PC is a mixture of coarse, washed aggregate, Portland cement, fly ash, and water. The mixture does not contain fine aggregates. Their absence creates interconnected void spaces or pores in the mixture to allow for stormwater infiltration, thus making void content a primary component of PC function. Void space for PC should range from 15–25 percent compared to the 5 percent void space found in traditional concrete. Due to void content, PC does not exhibit compressive strength found in conventional concrete. Following seven days of curing, PC with adequate void content should have a compressive strength of approximately 3,000 pounds per square inch (psi) and an infiltration rate of at least 300 inches per hour. PC is more widely used in warm climates because it is reported to maintain its consistency during extremely hot weather. PC is appropriate throughout the state of Alabama, especially where sandy soils are present.



Figure 6.2. Pervious concrete.

Porous asphalt (PA): PA uses fine and coarse aggregates mixed in a bituminous-based binder. Similarly to PC, infiltration occurs in PA through interconnected

void spaces. It is suitable to climates that experience winter freezing and thawing due to its ability to hasten snow and ice melt, thus reducing the amount of salt used during the winter months. Void content should range from 15–20 percent to ensure adequate infiltration. When PA freezes, the void space is maintained. Rather than forming a solid block, PA freezes into a porous surface. Continuous infiltration of stormwater aids in reducing freezing and thawing within the subbase layers of the PA. This is expected to decrease frost heaving, which is frequently associated with conventional asphalt. PA is not as strong as conventional asphalt; therefore, its placement, design, construction, and installation are essential to its long-term functionality. PA is installed using the same equipment as conventional asphalt. Compaction should be minimized, however, in order to avoid closing pore spaces. Following installation, PA should not receive traffic for 24 to 48 hours. PA is more expensive compared to conventional asphalt due to the extra cost associated with admixtures. PA, however, has demonstrated a lifespan of 30 years, which is double that of conventional asphalt. PA is noted to be less expensive compared to PICPs and PC.



Figure 6.3. Porous asphalt. (Photo courtesy of National Center for Asphalt Technology.)

Permeable interlocking concrete pavers (PICPs):

PICPs are concrete blocks placed with void space between them that is filled with a permeable joint material to encourage infiltration. Void space should range between 8 and 20 percent of the surface area. These systems are more suited to high-traffic areas because they offer the greatest structural strength compared to other permeable pavement types. PICPs do not require any curing and are traffic-ready immediately following installation. The type of PICPs specified is dependent on the strength required by the traffic load of the site. PICPs are available in a variety of shapes, sizes, and colors, and are thus more aesthetically diverse than other permeable pavements. Because the pavers are manufactured and can be installed mechanically, PICPs tend to be more uniform in size and function. Installation is



Figure 6.4. Permeable interlocking concrete pavers.

not weather dependent because there is no plastic mix that must be monitored for consistency or temperature limitations. PICPs are less expensive compared to conventional concrete and asphalt. Installation and supply costs are similar to PC and PA; however, costs spread out over the life of PICPs are less expensive than PC and PA in some markets.

Concrete grid pavers (CGPs): CGPs are concrete forms with surrounding void space filled with a fine-textured aggregate, sandy loam topsoil and turfgrass, or sand to aid infiltration. Void content ranges from 20% – 50% of the surface area and is dependent on the fill media. Turfgrass is used due to its shallow root system and low overall height. In low-traffic situations, CGPs have demonstrated structural support and durability comparable to conventional asphalt.



Figure 6.5. Concrete grid pavers.

Plastic reinforcement grids (PRGs): PRGs are modular plastic grid units that may be round or honeycomb shaped. These plastic grids provide void spaces, which are either filled with gravel or support turfgrass. Void content is dependent on the fill media. Over time, PRGs may shift and become lifted out of the soil, especially in parking areas where rear tires sit.



Figure 6.6. Plastic reinforcement grids.

DESIGN

Permeable pavement is typically designed to treat the first flush of the selected water-quality design storm. The first flush contains the highest concentration of pollutants. (See Appendix A: Stormwater Hydrology for more information on the first flush.) The design storm may be dependent on regulatory requirements.

Components

Pretreatment: Use pretreatment devices such as vegetated swales or filter strips to capture sediment before it enters the permeable pavement surface. (See section on *Grassed Swales, Infiltration Swales, and Wet Swales.*)

PC components: The top layer of PC may be as thick as eight inches depending on the design and site requirements. Coarse aggregate that is roughly 0.375 inch (No. 8 or No. 89 stone) should be used in the mixture. The absence of fine aggregates provides the void content necessary for infiltration. Next, there is a top filter layer of choking stone (0.5-inch diameter aggregate) at a depth of 1 to 2 inches to help stabilize the PC and provide rapid infiltration into the layer below. The next layer is the subbase/reservoir for temporary storage of stormwater. The subbase layer is comprised of 1.5–2.5-inch diameter aggregate (No. 3 or No. 2 stone) and typically ranges from two to four feet deep but can be a minimum of 9 inches. The depth of the subbase layer is based on the desired storage volume and on-site infiltration rates. The bottom filter layer consists of either six inches of sand or two inches of 0.5-inch diameter crushed stone; this layer stabilizes the subbase and protects the underlying soils from compaction. All aggregates used in the PC mixture and other layers should be washed. A layer of filter fabric should be placed before any aggregate layers are laid to discourage the migration of soil particles.

PA components: The first layer is the PA layer. It may be as thick as seven inches, although two to four inches is typical. This layer is followed by a one to two-inch choker course, which provides a level surface and is comprised of small open-graded aggregate. A subbase or base course (reservoir) beneath this layer helps to increase strength and storage capacity of the PA. It is usually 18 to 36 inches deep. Depth of the subbase is dependent on the amount of storage desired and the expected traffic load. The first three to four inches of the subbase should contain 0.75 inch diameter (No. 57) stones to initiate a high infiltration rate into the lower layer of the subbase. The rest of the subbase should contain 0.75–2.5-inch diameter stone. All aggregates used in the PA mixture and other layers should be washed. A layer of geotextile fabric is used as a filter between the subbase and underlying soil, similarly to PC.

PICPs components: The concrete pavers in PICPs are approximately three inches thick. Spacer bars on PICPs are recommended for mechanically installed pavers and for high traffic areas. Pavers installed manually do not require spacer bars. The openings between the pavers are filled with a 0.375-inch (No. 8 or No.89) stone; the bedding course below the pavers is typically a 1.5–2-inch-thick layer of the same size stone. The bedding and joint material should be washed, free of debris, and symmetrically shaped. Below the bedding course is a four-inch layer of 0.75-inch (No. 57) stone to provide an open-graded base. The subbase below is comprised of 2.5-inch (No. 2) stone. This depth varies based on the design and existing soil conditions on site. All aggregates used in the layers of PICPs should be washed. A

layer of filter fabric is placed between the subbase and the underlying soil.

CGPs components: Grid pavers may use masonry sand or a No. 10 stone dust with an eight inches per hour infiltration rate between the grids for stormwater infiltration. If turfgrass is desired between grids, a sandy loam with a minimum infiltration rate of one inch per hour should be used. Below this layer is a one-inch filter layer of masonry sand or No. 10 stone dust. The reservoir layer is a minimum of nine inches and is comprised of 1.5–2.5-inch diameter (No. 3 or No. 2) stone. All stone and sand components should be washed and free of debris. The last filter layer is eight inches of masonry sand followed by a layer of filter fabric.

PRGs components: PRGs are placed over fine-textured gravel or a sandy loam soil when turfgrass is used. The subbase below uses a well-draining, washed aggregate. The depth of the subbase layer is site dependent and may be a minimum of nine inches. Filter fabric is placed between the subbase and underlying soil. The structural specifications for these PRG products are highly varied. Most manufacturers can provide specific design and construction information based on their product specifications.

Underdrain: A perforated underdrain system with cleanouts should be used for soils with infiltration rates less than 0.5 inch per hour. Underdrains are typically used when there is a desire to tie into existing stormwater conveyance networks. Perforated PVC pipes are used for underdrains and placed at the subbase layer. A four-to six-inch perforated or slotted PVC pipe is used




Figure 6.7. Section through pervious concrete.




Figure 6.8. Section through porous asphalt.




Figure 6.9. Section through PICP.

(Schedule 40). A filter fabric “sock” over the underdrain is optional per the design engineer.

Overflow: Stormwater conveyance inlets can be raised above the pavement surface to allow minimal ponding before high flows bypass the permeable pavement system during major storms.

Subbase: The subbase of these systems has the potential to provide enough water storage to reduce stormwater quantity and significantly reduce the peak flow of larger storm events when the subbase is level. This is the layer that the underdrain is placed within. An aggregate base must be used for most permeable pavement types. Aggregates should be washed, bank-run gravel, 1–2.5-inch diameter, with a void space of approximately 40 percent. Alabama Department of Transportation (ALDOT) No. 3 stone and No. 57 stone are acceptable. Crush and run should not be used for the pavement base due to the tendency of fine particles to clog the bottom of the pavement section. This material should have a porosity of approximately 0.32 or greater. Fine particles should not be present, as they will clog the system.

Top course/choker layer/bedding depth: This layer should be a fine gravel or layer of sand, ASTM C-33 concrete sand or ALDOT fine aggregate size No. 10 stone dust, to serve as a filter. Filter fabric is placed under the permeable pavement and above the gravel base around this entire layer.

Interlocking concrete paver infill: The infill is selected based on application and desired infiltration rate. Similar to the top course layer, ASTM C-33 concrete sand or ALDOT fine aggregate size No. 10 sand can be used when no vegetation is desired (infiltration rates of eight inches per hour). If grass cover is desired, a sandy loam soil is recommended; however, the infiltration rate decreases to approximately one inch per hour.




Figure 6.10. Hydrograph showing typical response of flow rate over time during a rain event.




Figure 6.11. Hydrograph showing volume of flow estimated as the area under the flow rate curve during the rain event.

Design Guidance

The following is a series of design steps based on current research, design, and installation. Consult manufacturers or other resources for additional design information.

1. Determine treatment volume or peak flow.

The rational method, as shown in EQN 6.1, is used to calculate

the peak flow, where the estimated design discharge (Q) is equal to the product of the composite runoff coefficient (C), rainfall intensity (i), and watershed area (A). The rainfall intensity (i) is for a designated design storm for the particular geographic region of Alabama where the site is located.

EQN 6.1

$$Q_p = CiA$$

C = Runoff coefficient (dimensionless)
See Table A.2 in Appendix A: on Stormwater Hydrology
 i = Rainfall intensity (in/hr)
 A = Watershed area (ac)

The composite runoff coefficient (C) is based on the land use and surface for the total contributing watershed area. Increased impervious surface cover results in a higher coefficient. (See table A.2 in Appendix A: Stormwater Hydrology) for rational runoff coefficients. (For a more detailed explanation of hydrological calculations, see Appendix A: Stormwater Hydrology.)

2. Calculate the runoff volume.

To calculate a peak flow reduction, or a volume reduction of stormwater, many sources recommend assigning a “reduction in imperviousness” to the pavement or treating the pavement as a percentage of pervious surface. This percent of pervious surfaces assigned is dependent on the quantity of gravel base the

system has and the type of pavement used. For Alabama, if the gravel base depth is greater than six inches of washed stone base, the system will assume a 60 percent credit for reduction in imperviousness. Systems with less than six inches of base will assume a 40 percent credit.

These credit assumptions allow designers to determine the peak runoff volume using either the simple method (EQN 6.2 and 6.3) or the discrete curve number method (EQNs 6.4 and 6.5)

The runoff coefficient (R_v) is calculated for the simple method, EQN 6.2.

<p>EQN 6.2</p> $R_v = 0.05 + (0.9 * I_a)$	<p>R_v = Rational runoff coefficient (in / in) I_a = Percent impervious / total drainage area</p>
--	--

I_a is the percent impervious (%) or impervious area divided by the total drainage area. The peak runoff volume is then calculated using EQN 6.3.

<p>EQN 6.3</p> $V = 3630 * R_d * R_v * A$	<p>R_d = Design rainfall depth (in) R_v = Rational runoff coefficient (in / in) A = Area (ac) V = Peak runoff volume (ft³)</p>
--	--

R_d is the design rainfall depth (in); R_v is the rational runoff coefficient (in/in); and A is area in acres.

To calculate the runoff volume using the discrete curve number method, a curve number (CN) of 61 is assigned for managed grass or the pervious credit, and a CN of 98 is assigned for impervious areas. EQNs 6.4 and 6.5 are used to calculate a maximum potential retention after rainfall begins (S) by using corresponding land use CN. The maximum potential retention after rainfall begins (S) and precipitation depth (P) are then used to calculate the runoff depth (Q).

The runoff depth, Q (in), calculated for both the impervious and pervious drainage area fraction can be multiplied by their respective areas (ac) and summed for a total runoff volume as shown in EQN 6.12.



Figure 6.12. Strike-off and compression at Duck Samford Park, Auburn, AL. (Photo courtesy of Michael Hein.)

<p>EQN 6.4</p> $S = \left(\frac{1000}{CN} \right) - 10$	<p>CN = Land use curve number S = Maximum potential retention after rainfall begins</p>
---	---

<p>EQN 6.5</p> $Q = \frac{(P - (0.2S))^2}{P + 0.8S}$	<p>S = Maximum potential retention after rainfall begins P = Precipitation depth (in) Q = Runoff depth (in)</p>
---	--

Both the simple method (EQNs 6.2 and 6.3) and the discrete curve number method (EQNs 6.4, 6.5, and 6.12.) can be applied using the weighted credits/ ratios to calculate runoff volume, but the system must be designed to handle the peak flow rate, which is calculated using the rational method (EQN 6.1).

<p>EQN 6.6</p> <p>Volume _____ ac - in*3630 = _____ ft³</p>

3. Calculate the depth of subbase.

Calculating the depth of gravel base course (subbase/reservoir) is one of the more important aspects of permeable pavement design, regardless of the type of permeable product selected. The gravel base course should have a minimum of nine-inch depth. This minimum depth does not include the top or choker course layers. The minimum storage requirement of the base layer should be the water-quality volume. The water-quality volume (V) can be calculated using EQNs 2 and 3. Once V is determined, the surface area (SA) and porosity (n) of the base layers can be used to calculate base depth. EQN 6.7 is used to compute the depth of base.

EQN 6.7	v = Peak runoff volume (ft ³)
$d = \frac{V}{SA} * n$	SA = Total surface area of pavement (ft ²)
	n = Porosity of aggregate
	d = Depth of base (ft)

The depth of base (d) is equal to the water-quality volume (V), as calculated using the simple method or the discrete curve number method, divided by the total surface area (SA) of the permeable pavement and then multiplied by the porosity of the aggregate used (n). The porosity value is the void space divided by the total volume of fill material. A minimum value of 0.32 is recommended.


4. Check actual storage.

Once the layers and materials are determined, EQN 6.8 can be used to determine the actual storage of the system. This is a check to ensure that the depth of storage needed for the water-quality storm is met.

EQN 6.8
$Act. Storage = \sum \left(Material (s) * \frac{\% porosity}{100} \right) + \left(thickness * \frac{joint\ space\ \%}{100} * \frac{porosity\ \%}{100} \right)$

It is important to note that the design presented is not complete, but these steps will allow a designer to determine whether the design meets the standards to handle the peak flow in storing the water-quality volume. While pavement capacity has been calculated, structural integrity needs to be determined.

MOVIE 6.1 Permeable pavement case studies.



CONSTRUCTION

Consult industry standards and manufacturer specifications in the implementation of permeable pavement practices.

Compaction: Sequence construction to avoid clogging and compaction that may inhibit functionality of permeable pavements. Avoid compaction of the underlying soil during construction.

Slope: The grade of the subgrade layer should not be less than 0.5 percent (slope) to maintain the storage capacity of the system. If slopes greater than 1 percent must be used for the subgrade, a series of perpendicular barriers or dams can be used to keep the subgrade from washing away.

Please review proper sediment control practices in the Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas:
swcc.alabama.gov

Clogging: Take care to avoid surface clogging of the pavement once installed. If construction begins upslope, erosion and sediment-control best management practices (BMPs) are imperative to reduce sediment entering the permeable pavement. Permeable pavements are not designed to treat concentrated flows or runoff from unstabilized areas. Newly developed residential areas are particularly at risk for sediment clogging due to the construction of new home sites and sequencing of these activities. Never use permeable pavement as a temporary sediment-control measure during construction.

Testing: Conduct any testing prior to installation to determine density, compressive strength, void content, and mixture consistency.

Retrofits: Permeable pavement can be incorporated into an initial site design or as a retrofit alternative to conventional pavement; however, retrofits can be expensive and are generally only suggested when resurfacing is necessary.

Pervious Concrete (PC) Construction

Moisture: The subgrade should be moist (without standing water) at PC placement in order to prevent moisture loss from the bottom of the concrete layer. PC is prone to drying during placement due to the amount of void spaces present.

PC mixture: PC mix can be difficult to place due to its rigidity. An experienced concrete company or contractor is recommended to install permeable pavement, especially PC. The consistency of PC can be tricky; specifically, the amount of water in the mix can be difficult to determine. The mix of fly ash, Portland cement, aggregates, and water makes mixing difficult: this can result in the desire to add water while mixing on-site. When too much water is added, however, the mixture becomes too wet, and pores are likely to become sealed. A dry mixture with too little water cannot bind together and may result in surface raveling later.

Admixtures: PC is difficult to work with due to the absence of sand in the mixture, thus creating necessary void spaces. This causes the mixture to dry out quickly on-site and the time frame to install it becomes slim. A chemical admixture regimen can aid in the mixing, handling, and overall performance of PC. These chemical admixtures include a hydration stabilizer, water-reducing agent, and a viscosity-modifying agent to aid in placement of PC. (See table 2.)

Ready-mix truck: A ready-mix truck with rear discharge and one chute is typically used for PC. The chute should be steep and angled down to facilitate PC

TABLE 6.4.

CHEMICAL ADMIXTURE TYPE	PURPOSE
Polycarboxylate-based midrange water reducer	Minimizes the need to add water on-site and decreases the amount of water needed for the mixture, thus increasing and maximizing the compressive strength of the coarse mixture
Hydration stabilizer	Extends time frame of plasticity by slowing the rate of hydration in the mixture
Viscosity modifying	Lubricates the mixture to aid in discharge from the truck and placement
<i>BURY ET AL., 20012.</i>	

removal from the truck. The mix may need to be manually removed from the chute using shovels or other tools. Using admixtures can alleviate some of the strain associated with mix removal from the truck because these additives increase workability and flow of the mix from the truck.

PC placement: Once placement begins it should be continuous, and the surface should be struck off using a vibrating screed. Temporary boards can be added to the forms so that striking off can be 0.5–1 inch above the forms to compensate for compaction that occurs later. After striking off, PC should be consolidated or compacted to the top of the forms (temporary boards are removed) using a steel or weighted roller. The use of hydraulic roller screeds is common for PC installation. A hydraulic roller screed uses stainless steel tubes that rotate in the opposite direction from where the concrete was placed. It is recommended that consolidation take place within approximately 15 minutes after placement, as PC

can dry out quickly. Edge raveling is avoided by using a float or steel tamp that is approximately 1x1 foot to compact the edges. Having a sufficient construction crew in place is necessary so that one group can be placing and the other group striking off and consolidating.

Curing: PC should be misted following its placement and covered using plastic sheeting for at least seven days to cure. The curing process begins 20 minutes or less following compaction and jointing. Plastic sheeting may be held down using lumber, stakes, or rebar. When not cured properly, PC can be prone to surface deterioration and excessive raveling.

Striping: Once cured, striping of PC can be completed. Striping paint does not appear to reduce infiltration or seal pores.

Control joints: Although cracking of PC is unlikely, control joints can be spaced a minimum of 20 feet apart to combat concrete shrinking, which may lead to surface cracking.

Cutting joints: A rolling joint tool or “pizza cutter” should be used soon after PC is placed. Cutting joints with a saw is not recommended because the slurry created from cutting can clog void spaces, and saw-cut joints generally suffer from surface raveling.

MAINTENANCE

Several preventative maintenance steps, such as proper maintenance access, site selection, and mixture consistency of PC, can be taken to circumvent future maintenance obstacles. Immediately stabilize any eroded areas or soil washout.

Clogging: Over time, some level of clogging is expected to occur from sediments and other materials deposited from vehicles, wind, runoff, and surface deterioration. Regularly performed maintenance activities can preserve infiltration rates. Clogged surfaces are easily noted by pouring a gallon of water on the pavement surface. Clogging does not always result in sealed pores. Clogged (not sealed) permeable pavement is shown to still exhibit infiltration rates exceeding one inch per hour (rates greater than conventional).



Figure 6.13. Placing plastic sheeting over pervious concrete at Duck Samford Park, Auburn, AL. (Photo courtesy of Michael Hein.)



Figure 6.14. Surface raveling, Auburn, AL.



Figure 6.15. “Pizza cutter” joint tool at Duck Samford Park, Auburn, AL. (Photo courtesy of Michael Hein.)

Underlying soils are shown to influence surface infiltration rates of clogged permeable pavements.

Clogged PC or PA: When PC or PA fails due to improper mixture consistency or extreme clogging, 0.5-inch diameter holes can be drilled every few feet to facilitate infiltration; however, holes too close together can damage structural integrity of the pavement.



Figure 6.16. Weeds in PICIP, Orange Beach, AL.

Clogged PICIP: If PICIPs become severely clogged, joint material replacement is necessary to restore infiltration. A vacuum street sweeper can be used to remove joint material to a depth of four inches. Be sure to vacuum a test section to verify that only joint material or aggregate is being removed rather than the gravel base layer.

Maintenance access: Provide a 20-foot-wide maintenance access road or right-of-way for maintenance of permeable pavement. The access road should be stable and strong enough to hold heavy vehicles such as a street sweeper and have a minimum drive path of 12 feet.

Raveling: Slight raveling of surface particles of PC is expected during the first few weeks following installation, but any additional raveling can be problematic for infiltration. As surface particles are loosened, void spaces may be filled with these particles, leading to decreased infiltration rates.

Mechanical street sweepers: Mechanical street sweepers are the most common. They use multiple brushes to loosen particles that are lifted onto a conveyor for temporary storage.

Regenerative air street sweepers: Regenerative air street sweepers are the second most common. They are used to remove surface particles through air that is blown onto the surface of the pavement, thus creating a vacuum between the bottom of the truck and pavement surface.

TABLE 6.5. MAINTENANCE SCHEDULE		
TASK	HOW OFTEN	COMMENTS
Sweep street	Quarterly	Street sweeping removes surface debris that can potentially clog the permeable pavement surface. Quarterly street sweeping is suggested, but increased frequency is recommended.
Inspect for surface deterioration	Quarterly	Conduct inspections once a quarter or following a 0.5" or greater rain event.
Inspect for sediment	Monthly	Confirm that permeable pavement surface is free of sediment and debris.
Remove weeds	When they appear	Eradicate weeds using glyphosate. Hand pulling can disturb joint material in PICIPs.
Mow adjacent land areas	When needed	Collect and remove clippings from the site.
Stabilize surrounding land	When needed	Stabilize surrounding land to minimize sediment entry into the permeable pavement.

Vacuum street sweepers: Vacuum street sweepers are the most expensive street sweeper and, therefore, less common. Vacuum street sweepers have a strong vacuum system that can remove particles from above and below the paver surface.

Preventative street sweeping: Preventative street sweeping should be performed annually at a minimum, but quarterly is better. Street sweeping to prevent clogging eliminates the need for more stringent restorative measures. Preventative street sweeping for PICPs, PC, and PA is generally done using a regenerative air street sweeper.

Restorative street sweeping: A mechanical street sweeper is shown to be effective for restorative cleaning of CGPs filled with sand. Restorative cleaning of PC, PICPs, and PA should be done using a vacuum street sweeper.

Pressure washing: Pressure washing using a narrow, cone-shaped nozzle is recommended for PC, and a wide spray nozzle is recommended for PICPs. In some cases, pressure washing has restored 80–90 percent of permeability.

Power blowing: Power blowing is helpful to remove surface debris such as leaves or other plant material that may have collected on the pavement surface.

Combined forms of maintenance: Pressure washing and vacuum sweeping are frequently performed together for PC maintenance. These regenerative cleaning methods can restore infiltration capacity by 200 percent. Combined pressure washing and power blowing has shown a 200-fold increase in infiltration rates on PC.



Figures 6.17, 6.18, and 6.19. Mixture consistency (top to bottom): A dry mixture, an ideal mixture, and a wet mixture. (Source: Tennis, Leming, and Akers. 2004.)

Nuisance species: Permeable pavements utilizing vegetation and PICPs requires removal of unwanted plants or weeds. Eradicate weeds using glyphosate or other systemic herbicide followed by actual removal of weeds one week later. Pulling weeds by hand without the use of an herbicide can result in dislodging or disturbance of joint material or sand. When PRGs are used with turfgrass, mowed clippings should be bagged and disposed of off-site.

Maintenance agreements: Secure maintenance agreements prior to installation of any type of permeable pavement. Specify equipment availability, labor, and the responsible party. Outline specific maintenance activities and frequency in a maintenance schedule. Site inspections and record keeping are important to document the functionality of permeable pavements. Keep all data sheets in one location for reporting purposes. (*For more information, see Appendix C: Maintenance.*)

POLLUTANT REMOVAL

Unlike other structural low impact development (LID) stormwater control measures (SCMs), permeable pavement does not rely on the use of vegetation for pollutant removal. Any pollutant removal that occurs is due to the volume reduction of surface stormwater runoff. As a result, soluble and particulate pollutants are often removed by these systems through deposition, absorption, and filtration in underlying soil layers. Research has shown permeable pavements to decrease concentrations of heavy metals, motor oil, sediments, and nutrients in stormwater runoff from a site.

Quantity reduction: Due to high surface-infiltration rates, permeable pavements reduce both water quantity and peak discharges. Any surface runoff from permeable pavement should only occur during high-intensity storms when the pavement cannot infiltrate stormwater quickly enough to capture it completely. A North Carolina study examined surface infiltration rates and found that most permeable pavements exhibited infiltration rates greater than two inches per hour. Under these conditions, A storm would need to have an intensity exceeding two inches per hour in order for surface runoff to occur.

Total suspended solids (TSS): TSS reductions were not quantified, because it is not recommended that these systems trap sediment due to their propensity to clog.

Sediment-bound pollutants: Both phosphorus and metals are known to be bound to sediments and will naturally accumulate on the pavement surface.

TABLE 6.6 POLLUTANT REMOVAL				
SEDIMENT	NUTRIENTS		METALS	PATHOGENS
	N	P		
a. No data	No data	No data	No data	No Data
b. - -	80%	80%	90%	- -
c. - -	65%	50%	60%	- -
d. - -	80%	80%	90%	- -
e. - -	80%	80%	90%	Insufficient data
f. 99%	No data	42%	97%*	No data

A. NORTH CAROLINA DEPARTMENT OF ENVIRONMENT AND NATURAL RESOURCES, 2007
 B. CITY OF AUBURN, 2011
 C. GEORGIA MANUAL, 2001 - PERVIOUS CONCRETE
 D. GEORGIA MANUAL, 2001 - MODULAR PAVING SYSTEMS
 E. KNOX COUNTY, 2008
 F. ROSEEN AND BALLESTERO, 2008 - POROUS ASPHALT
 *POLLUTANT REMOVAL IS PRESENTED FOR ZINC.

rather than remaining on the surface where it would be heated by the sun before being discharged into a stormwater conveyance network. Moreover, stormwater stored in the gravel layer subbase or reservoir is held before being released into the surrounding soil or underdrain system, allowing water to cool before being discharged.

Metals are captured in the top one to two inches of the pavement void space. Standard street sweeping should remove most heavy metals when the void space consists of sand. Removal of sediment particles from the surface of permeable pavement improves functionality and infiltration, and can also enhance pollutant removal. In an Auburn University study, surface runoff from impervious areas was found to have five times the amount of TSS compared to the leachate from a PC parking lot on campus, indicating the removal or filtration of sediment particles.

CGPs: Permeable pavements that employ the use of sand as a filter, CGPs for example, are shown to exhibit higher overall total nitrogen reductions.

Underlying soils: Underlying soils can affect pollutant removal efficiency of permeable pavements. In general, sandy soils boast higher infiltration rates but offer less treatment of stormwater pollutants. In contrast, clay soils show decreased infiltration, but their higher cation exchange capacity can aid in pollutant capture. Additionally, bacteria that assist in the treatment process are present not only in the underlying soils but have shown growth in gravel base layers.

Temperature: Although not quantified, water temperature reductions are assumed because runoff is immediately infiltrated into the pavement surface

REFERENCES

- Alabama Soil and Water Conservation Committee. 2009. *Alabama Handbook for Erosion Control, Sediment Control, and Stormwater Management on Construction Sites and Urban Areas*. Montgomery, AL.
- Atlanta Regional Commission. 2001. *Georgia Stormwater Management Manual*.
- Bean, E. Z., W. F. Hunt, and D. A. Bidelsbach. 2006. "Field Survey of Permeable Pavement Surface Infiltration Rates." *Journal of Irrigation and Drainage Engineering* 133(3): 247-2512.
- Brattebo, B. O., and D. B. Booth. 2003. "Long-Term Stormwater Quantity and Quality Performance of Permeable Pavement Systems." *Water Research* 37:4369-43712.
- Bury, M. A., C. A. Mawby, and D. Fisher. Fall 2012. "Making Pervious Concrete Placement Easy Using a Novel Admixture System." *Concrete in Focus*.
- City of Auburn, AL. 2009. *City of Auburn Stormwater Management Design Manual*.
- Dougherty, M., M. Hein, and C. Lebleu. 2009. *Evaluation of Stormwater Quality through Pervious Concrete Pavement*. American Society of Agricultural and Biological Engineers Annual Meeting Proceedings.
- Dougherty, M., M. Hein, B. Martina, and B. Ferguson. 2009. "Quick Surface Infiltration Test to Assess Maintenance Needs on Small Pervious Concrete Sites." *Journal of Irrigation and Drainage Engineering ASCE*: 1-7.
- Gunderson, J. 2007. "Pervious Pavements: New Findings About Their Functionality and Performance in Cold Climates." *Stormwater*.
- Hunt, W. F. 2009. *Maintaining Permeable Pavements*. North Carolina Cooperative Extension AG-588-23W.
- Hunt, W. F., and K. A. Collins. 2007. *Permeable Pavement: Research Update and Design Implications*. North Carolina Cooperative Extension AG-588-9.
- Interlocking Concrete Pavement Institute (ICPI). 2007. *Permeable Interlocking Concrete Pavement: A Comparison Guide to Porous Asphalt and Pervious Concrete*. Herndon, VA.
- Interlocking Concrete Pavement Institute (ICPI). 19912. *Interlocking Concrete Pavers*. Section 23-14-7. Herndon, VA.
- Kevern, J., K. Wang, M. T. Suleiman, and V. R. Schaefer. 20012. *Pervious Concrete Construction: Methods and Quality Control*. National Ready Mixed Concrete Association Concrete Technology Forum, Nashville, TN.
- Knox County Tennessee Stormwater Management Manual*. 2007. Knox County, TN.
- LeFevre, J. 2006. "Pervious concrete is popular concrete." *Concrete InFocus* 6(2): 45-47.
- Mississippi Concrete Industries Association (MCIA). 2002. *Pervious Concrete: The Pavement that Drinks*. Ridgeland, MS.
- North Carolina Department of the Environment and Natural Resources. 2006. "Ch 18: Permeable Pavement" (Revised 2010). *Stormwater Best Management Practices Manual*. Raleigh, NC: North Carolina Division of Water Quality.
- Roseen, R. M., and T. P. Ballestero. May/June 2007. "Porous Asphalt Pavements for Stormwater Management in Cold Climates." *Hot Mix Asphalt Technology*.
- Smith, D. R., K. A. Collins, and W. F. Hunt. 20012. "North Carolina University Evaluates Permeable Pavements." *Interlocking Concrete Pavement Magazine*.
- Stormwater Center (SWC). *Stormwater Management Fact Sheet: Porous Pavement*. Accessed November 2, 2009. www.stormwatercenter.net/Assorted%20Fact%20Sheets/Tool6_Stormwater_Practices/Infiltration%20Practice/Porous%20Pavement.htm.
- Stormwater Manager's Resource Center. www.stormwatercenter.net.
- Tennis, P. D., M. L. Leming, and D. J. Akers. 2004. *Pervious Concrete Pavements*. Skokie, IL: Portland Cement Association. Silver Spring, MD: National Ready Mixed Concrete Association.
- University of New Hampshire Stormwater Center. 2010. 2009 *Biannual Report*.
- United States Environmental Protection Agency. 2009. "Porous Asphalt Pavement." *NPDES Fact Sheet*.
- United States Environmental Protection Agency. 1999. "Porous Pavement." *Stormwater Technology Fact Sheet*. Washington, D.C: Office of Water.
- United States Environmental Protection Agency. 2010. *Surface Infiltration Rates of Permeable Surfaces: Six Month Update (November 2009 through April 2010)*. Edison, NJ: Office of Research and Development, National Risk Management Research Laboratory – Water Supply and Water Resources Division.

GRASSED SWALES, INFILTRATION SWALES, AND WET SWALES

Other names for it include vegetated swale, bioswale, wetland channel, dry swale, wet swale, conveyance channel, reinforced swale, grassy swales, and biofilter. A water-quality swale is a shallow, open-channel stabilized with grass or other herbaceous vegetation designed to filter pollutants and convey stormwater.



Swales are applicable along roadsides and in parking lots, residential subdivisions, and commercial developments. They also are well suited to single-family residential and campus-type developments. Water-quality swales presented in this handbook are designed to meet velocity targets for the water-quality design storm. They may be characterized as wet or dry swales, may contain amended soils to infiltrate stormwater runoff. They are generally planted with turfgrass or other herbaceous vegetation.

SITE SELECTION

Swales can reduce infrastructure costs by eliminating the need for curb-and-gutter and traditional stormwater piping. Any type of swale design can be paired with other structural low impact development (LID) stormwater control measures (SCMs) to increase pollutant load reductions and to capture excess stormwater leaving the swale. Swales are typically paired with level spreaders, filter strips, bioretention cells, constructed stormwater wetlands, or permeable pavement to meet treatment needs. Swales also are used as a stand-alone practice in many applications and work well as retrofits.

Drainage area: Swales are designed as conveyance channels that capture and treat stormwater runoff in smaller drainage areas. Swales are recommended for drainage areas of five acres or less and should capture runoff from approximately 10%–20% of the contributing impervious surface area.

Evaluating soils: Use the USDA Web Soil Survey to identify soil map units and to make initial interpretations for potential uses and limitations of a site. Since most soil map units have inclusions of other soils that may be quite different, detailed

TABLE 7.1. SITE SELECTION	
Quality control	No
Drainage area	Small
Space required	Small
<i>Works with:</i>	
Steep slopes	Yes
Shallow water table	
Poorly drained soils	Yes

TABLE 7.2. GENERAL SIGNIFICANCE	
Construction cost	Low
Maintenance	Low
Community acceptance	High
Habitat	Low
Sun/shade	Either

evaluations should be made at the proposed site by a professional soil scientist or soil classifier. On-site evaluations should properly identify a soil or the hydrologic soil group (HSG). Make the final decision for use based on the detailed determination of soil series or HSG. (*For a detailed list of HSG properties, see table A.3 in Appendix A: Stormwater Hydrology.*)

In-situ soil: The topography and in-situ soil characteristics, particularly the soil texture and hydrologic soil group (HSG), determine the applicability of a wet or dry swale design. Perform an infiltration test to determine infiltration rates. (*For more information on an infiltration test, section on Rain Gardens*). Dry swales (grassed swales and infiltration swales) are appropriate for HSG A and B that are well-drained to moderately well-drained, respectively. (*See table A.3 in Appendix A: on Stormwater Hydrology for more information on HSG properties.*) A dry swale should have an infiltration rate greater than 0.5"/hr and may require that soils be amended to achieve the desired infiltration rate. Infiltration swales also may require that soils be amended to achieve desired infiltration rates. Wet swales are conducive to HSG C or in areas where the water table is close to the soil surface.

TABLE 7.3. SITE SELECTION: CONSTRAINTS & LIMITATIONS FOR SWALES	
Slope	Choose locations with less than 5% slopes, where possible.
Utilities	Call Alabama 811 before construction to locate utilities. (For more information, visit www.al1call.com .)
Limited volume control	If storage volume is a primary objective, you may need to use another SCM.
High sediment loads	Swale location should not experience high sediment loads that may clog the system. When sediment is introduced there is a risk of possible sediment resuspension.
Continuous flow	Locations that will not experience continuous flow and are allowed to drain are recommended for dry swales.
Lower pollutant removal	An infiltration swale is recommended for highest pollutant removal. Increase media/fill material depth for temperature reductions.
Undersized swale, site size constrained	If the site will not support swale size required for design storm treatment, use another SCM or use in conjunction with another SCM. An undersized swale will not adequately reduce total suspended solids.

USDA's online Web Soil Survey (websoilsurvey.nrcs.usda.gov/app/homepage.htm) can be used as a guide to determine the needed soil information for the site, such as the hydrologic soil group (HSG) and depth to water table.

Depth to groundwater: The seasonally high water table should be a minimum of 1' below the bottom of any type of swale, and the swale should never intercept groundwater. If an aquifer or hotspot is present, however, there should be a minimum of 2' between the bottom of the channel and the seasonally high water table. Hotspots are defined as commercial, industrial, or other operations that produce higher levels of stormwater pollutants and/or have concentrated pollutants.

Slope: Swales should be sited so that they have a mild entrance slope to avoid high-velocity flows and channel dimensions that allow for nonerosive velocities (less than 4' per second or fps). The longitudinal slope should not exceed 5% where possible. Longitudinal slope is important to create conveyance but should not increase the velocity of the system greater than 1 fps for a 10-year design storm.

Flow regime: The designer should evaluate grade transitions to consider the flow regime and range of discharges up to the design flow rate. Avoid hydraulic jumps caused by changes in flow regime, since erosion and scouring may occur at locations of undulating flow. Grading to ensure a uniform slope and surface minimizes erosion, sediment resuspension, and additional maintenance.

Turf reinforced matting: Velocities greater than 4 fps may result in eroded grassed swales. Turf reinforced matting (TRM) under the sod can be used to hold turfgrass in place during high flows.

COMMON SWALE DESIGN VARIATIONS

Dry swales: Dry swales consist of grassed swales and infiltration swales. Dry swales are designed to convey or infiltrate only the "first flush" (water-quality volume) or to handle the peak flow volume. (See *Appendix A: Stormwater Hydrology for more information on first flush.*) Dry swales may have underdrains that convey stormwater into an outlet, use an overflow device, or use a combination of these. Dry swales are designed to have standing water for a maximum of 48 hours; however, 24 hours is preferred. Depending on the type of

dry swale, these designs may have shallow open channels over a fill material of well-drained in-situ soils, a 50/50 sand/soil mix, or a bioretention media mix.

Grassed swales: Grassed swales are dry swales planted with turfgrass and are often used along roadsides where mowing is the primary form of maintenance. Grassed swales are typically used for conveyance, but when placed over well-drained soils (or amended soils), these may provide infiltration of runoff and water-quality improvement. In-situ soil can be amended with a 50/50 sand/soil mix to enhance infiltration.

Infiltration swales: Infiltration swales typically have at least 30" of amended soil (50/50 sand/soil mix or bioretention media mix) beneath the bottom of the swale to aid in infiltrating runoff. (See section on Bioretention for more information on the recommended media recipe for targeted pollutant removal.) Infiltration swales that use a bioretention media mix typically have a layer of gravel beneath the media and an underdrain may or may not be utilized. They are dry swales that are planted with native grasses, herbaceous perennials, and small shrubs. Infiltration swales are easily integrated into the landscape and can be attractive and aesthetically pleasing in residential and commercial developments, parking lot islands, and medians. Small woody shrubs can be planted in swale channels when their mature height and width not exceed landscape requirements of the site. Infiltration swales have the greatest pollutant removal potential compared to other swale designs presented in this handbook.

Wet swales: A wet swale design consists of a shallow, open channel that is placed over poorly drained soils or in areas with a shallow water table. Amended soil media is not necessary for wet swales. Wet swales are retention structures that are designed to handle the peak flow event and retain all or a portion of the water-quality volume. By retaining stormwater, wet swales use increased residence time to provide water-quality benefits. They are planted with wetland plants to facilitate pollutant removal.

Pretreatment swales: When used as pretreatment for other SCMs, the swale should be at least 20' in length.

TABLE 7.4. TYPES OF SWALES		
SWALE TYPE	SOIL/MEDIA	COMMENTS
Grassed swale	Well-drained in-situ soil or a 50/50 sand/soil mix	Dry swale planted with turfgrass sod
Infiltration swale	50/50 sand/soil mix or bioretention media mix	Dry swale planted with flood and drought-tolerant vegetation. When a bioretention media is used, a layer of gravel is typically placed below the media and an underdrain may be utilized.
Wet swale	Native poorly drained soils	Planted with wetland vegetation

DESIGN

All swale designs consist of three primary components: pretreatment, swale, and overflow. The size of each of these components is based on the volume or design storm to be treated. Swale location should be based on site topography to allow for the integration of natural drainage patterns within the swale drainage way.

Components

Pretreatment: A forebay, grassed filter strip, or grassed inlet is used as a pretreatment device for swales.

Forebay: The forebay is a pool located at the inlet of a system. It is deepest at the point of runoff entry and shallowest at the exit point. This design dissipates energy throughout the forebay and provides diffuse flow into the swale. A forebay is recommended when there is a single, concentrated flow entering the swale. It serves as a sediment sink for runoff entering the system to prevent clogging of the swale channel and subsequent damage to vegetation.

The forebay should be 18"–30" deep and is designed to be 0.2% of the watershed drainage area. If standing water is a concern, a grassed filter strip

may be used as a pretreatment device. Wet swales typically have a forebay for pretreatment, and stormwater is released into the wet channel.

Grassed filter strip: A minimum width of 4' of grassed filter strip is recommended for the entire length of the swale. (See section on Level Spreaders and Grassed Filter Strips for more information.)

Grassed inlet: A grassed inlet uses the side slopes of the swale as pretreatment. Grassed inlets are planted with dense turfgrass and have a gentle slope of 3:1 or greater (5:1 is recommended) to prevent erosion. A grassed inlet allows water to enter the system from all sides of the swale, which slows stormwater velocity, and serves as a sediment trap for larger particles.

Swale: The swale is designed to be triangular or trapezoidal in shape, with a minimum of 3:1 side slopes (5:1 is recommended), and a length that does not exceed 100'. Whether the swale is designed to be wet or dry, it is ultimately designed as an infiltration, filtration, and conveyance structure.

Additional Components

Underdrain: Infiltration swales may include the use of underdrains to drain the swale within 48 hours and minimize standing-water conditions. Underdrains are corrugated or smooth, wall-perforated pipe. They should be configured to tie in with the overflow or discharge into the stormwater conveyance network. Underdrains are not used in wet swale designs.

Curb cuts: Curb cuts can be used to direct flows into the swale and are easy retrofits to a traditional curb and gutter. Curb cuts do not treat stormwater runoff but can function as the inlet to a swale system while minimizing erosion. (For more information, see section on Curb Cuts.)

Overflow structure: Overflow structures should be designed to safely pass runoff from rainfall events greater than the peak flow event.




Figure 7.1. Grass filter strip cross section.

DESIGN GUIDANCE

Collect information for watershed size, soil texture, HSG, slope, and depth to water table. The design layout or swale location is specific to the site. When determining the best location for the swale, consider site constraints, retrofit opportunities, aesthetics, and maintenance. Swales may be designed to be trapezoidal or triangular. (See *Design Guidance for more information.*)

1. Determine treatment volume or peak flow.

Swales are designed to treat the first flush volume and to control peak flow. The peak flow event is runoff from the primary design storm and is used because it is often the greater of the two.

The Kirpich equation and rational method are used to determine peak flow and to calculate swale geometry to provide sizing recommendations and determine flow equations. The Kirpich equation shown in EQN 7.1, uses the longest length in the watershed (L) and the change in elevation (H) to calculate the time of concentration (T_c).

EQN 7.1

$$T_c = \frac{\left(\frac{L^3}{H}\right)^{0.385}}{128}$$

L = Longest length of water path in drainage area (ft)
H = Change in elevation throughout drainage area or watershed (ft)
T_c = Time of concentration (minutes)

Intensity (i) is derived using the time of concentration (T_c) and a selected design storm. peak flow (Q_p) is calculated using the rational method, EQN 7.2.

EQN 7.2

$$Q_p = CiA$$

C = Rational coefficient (dimensionless) (See Table A.2 in Appendix A: Stormwater Hydrology.)
i = Rainfall intensity (in/hr)
A = Watershed area (ac)
Q_p = Peak flow (ft³/s)

2. Determine swale geometry.

Calculating swale geometry may require several design iterations using Manning's equation (EQN 7.3.) First determine whether the swale will be trapezoidal or triangular; if vegetation other than turfgrass is to be used, a trapezoidal channel is recommended.

EQN 7.3

$$Q_p = \left(\frac{1.486}{n}\right) * A * R^{0.667} * S^{0.5}$$

n = Manning's n (dimensionless) - See Appendix A: Stormwater Hydrology
A = Swale channel cross-sectional area (ft²) based on swale geometry
R = Hydraulic radius (ft)
S = Swale channel slope (ft/ft)




Figure 7.2. Forebay cross section.




Figure 7.3. Infiltration swale with amended soil.




Figure 7.5. Grassed swale.




Figure 7.4. Infiltration swale with bioretention media mix.




Figure 7.6. Wet swale.

Swale geometry affects the swale channel cross sectional area (A), therefore affecting the hydraulic radius (R). Both of these are used to calculate the swale depth (D). Next, the steepness of the side slope (S) is specified. A 5:1 slope is recommended when side slopes are used as pretreatment filter strips to optimize pollutant removal or when mowing is used to maintain vegetation. Side slopes, which are not the same as swale channel slopes, are also used in the calculation of swale channel geometry.

Depth (D) is determined using peak flow (Qp) calculated from EQN 7.2 in Manning's equation, (EQN 7.3.)

Triangular channels: A modified Manning's equation for a triangular channel with 3:1 and 5:1 side slopes is shown in EQNs 7.4 and 7.5.

<p>EQN 7.4 for 3:1 side slopes</p> $Q_p = \left(\frac{1.486}{n} \right) * A * R^{0.667} * S^{0.5}$	<p>EQN 7.5 for 5:1 side slopes</p> $Q_p = \left(\frac{4.62}{n} \right) * D^{2.67} * S^{0.50}$
<p>n = Manning's n (dimensionless) - See Appendix A: Stormwater Hydrology A = Swale channel cross-sectional area (ft²) based on swale geometry R = Hydraulic radius (ft) S = Swale channel slope (ft/ft)</p>	<p>n = Manning's n D = Depth (ft) S = Swale channel slope (ft/ft) Q_p = Peak flow (ft³/s)</p>

Trapezoidal channels: Once D is calculated, side slopes and channel geometry can be altered to calculate the swale width. This iterative process is especially useful when a fixed dimension is necessary.

3. Check channel velocity.

The continuity equation (EQN 7.6) can be used to validate the velocity within the swale and determine if there is a need for turf reinforced matting (TRM) or additional vegetation to prevent erosion and scour within the swale channel. If velocity exceeds 4 fps, TRM is necessary.

EQN 7.6

$$Q = V * A$$

Q = Flow (ft³/s)
V = Average velocity in channel (ft/s)
A = swale channel cross sectional area (ft²), based on swale geometry

4. Determine the number and size of underdrains.

To calculate the number and size of underdrains, EQNs 4.9–4.12 found in the section on Bioretention can be used.

Swale Geometry
(Illustrations are exaggerated)

for triangular swale geometry:
Area, $A = 0.5(b*h)$
Wetted Perimeter, $P = a + b + c$

for trapezoidal swale geometry:
Top Width, $T = b + y(z_1 + z_2)$
 $A = \frac{y}{2}(b + T)$
 $P = b + y(\sqrt{1 + z_1^2} + \sqrt{1 + z_2^2})$

Note: typically $z_1 = z_2$

Design Example

A site in south-central Alabama was chosen for an infiltration swale design. This site has a watershed area of **2.5 acres** with a Kinston soil series and HSG B. Most of the site is impervious with **2.0 acres in concrete and pavement**. Only the impervious portion of the site is to be treated by the swale (2.0 acres).

1. Determine peak flow.

The swale is designed for the peak flow event using the Kirpich equation.

EQN 7.7

$$T_c = \frac{\left(\frac{L^3}{H} \right)^{0.385}}{128}$$

The length (l), width (w), and longest length of water path in the drainage area are 480', 180', and 512', respectively. The **longest length (L)** of water path in the drainage is **512'** and the **change of elevation, (H)**, is **8'**.

Therefore, the **time of concentration** is

$$T_c = \frac{\left(\frac{512^3}{8} \right)^{0.385}}{128} = \frac{605}{128} = 4.7 \text{ min}$$

T_c is 4.7 minutes and will be rounded to the nearest whole number, 5 minutes.

The T_c is used to calculate rainfall **intensity (i)** in the rational method. The design storm or rainfall intensity is determined using the 10-year flow event and closest estimate of the T_c, 5 minutes. The lowest calculated T_c is 5 minutes, so the **10-year, 5-minute intensity (i) is used**. (For more detail on how to determine storm intensity using the intensity-duration-frequency (IDF) curve, refer to Appendix A: on Stormwater Hydrology.)

The rational method (EQN 7.8), is used to determine **peak flow (Q_p)** from the 10-year, 5-minute event.

EQN 7.8 $Q_p = CiA$

A **rational coefficient (C)** of **0.95 for parking lot runoff (impervious)**, **intensity (i)** of **7.36 in/hr** (from appropriate IDF curve, determined using the 10-year, 5-minute event), and an **area (A)** of **2.0 acres** for the impervious surface is used for this equation.

$$Q_p = 0.95 * 7.36 \text{ in/hr} * 2.0 \text{ ac}$$

Converting the intensity, I, 7.36 in/hr to ft/s

$$7.36 \text{ in/hr} \left| \frac{1 \text{ ft}}{12 \text{ in}} \right| = 0.613 \text{ ft/hr} \left| \frac{1 \text{ hr}}{3600 \text{ s}} \right| = 0.00017037 \text{ ft/s}$$

Converting 2 acres into square feet

$$2 \text{ ac} \left| \frac{43560 \text{ ft}^2}{1 \text{ ac}} \right| = 87120 \text{ ft}^2$$

$$Q_p = 0.95 * 0.00017037 * 87120 = 14 \text{ ft}^3/\text{s}$$

Continued on next page

2. determine swale geometry.

A trapezoidal geometry for the swale is desired for maintenance. Calculating the geometry for a trapezoidal swale is often an iterative process; however, in some instances, site constraints limit the dimensions.

For this example, the **swale channel bottom width (b)**, needs to be a **minimum of 4'** to accommodate the desired herbaceous vegetation. A 5:1 side slope is desired; however, site constraints limit the side slopes to 3:1. These site constraints create limited swale geometry. Using the equations to calculate **top width (t)**, **area (A)**, and **wetted perimeter (P)**, the variables in the modified Manning's equation, (EQN 3) can be used to confirm Q_p .

$$\text{EQN 7.9} \quad Q_p = \left(\frac{1.486}{n} \right) * A * R^{0.667} * S^{0.5}$$

For the trapezoidal geometry, **where b is 4' and z is 3' and a depth of 1' is assumed.**

$$T = b + y(z_1 + z_2) \text{ geometry: } T = 4 \text{ ft} + 1 \text{ ft}(3 \text{ ft} + 3 \text{ ft}) = 10 \text{ ft}$$

The top width (T) of 10' is then used to calculate the cross-sectional area. The following equation is used:

$A = \frac{Y}{2} (b + T)$, where y is an assumed depth of 1', b is 4', and T is the calculated 10'.

$$A = \frac{1}{2} (4 \text{ ft} + 10 \text{ ft}) = 7 \text{ ft}^2$$

In order to calculate peak flow using EQN 3, the **hydraulic radius (R)** must also be calculated. **Hydraulic radius (R)** is defined as the **Cross Sectional Area (A)** divided by the **wetted perimeter (P)**.

$$R = \frac{A}{P}$$

Wetted perimeter (P) is first determined. For a trapezoidal channel, **P** is calculated as:

$P = b + y \left(\sqrt{1 + z_1^2} + \sqrt{1 + z_2^2} \right)$, where b is 4', y is assumed to be 1', and $z_1 = z_2 = 3$.

$$P = 4 \text{ ft} + 1 \text{ ft} \left(\sqrt{1 + 3^2} + \sqrt{1 + 3^2} \right) = 10.3 \text{ ft} \quad \text{Therefore, } R = \frac{7.0 \text{ ft}}{10.3 \text{ ft}} = 0.68 \text{ ft}$$

From the channel geometry calculation, the trapezoidal channel variables of **Area (A)** and **hydraulic radius (R)** are **7 ft²** and **0.68'**, respectively.

Additionally, Manning's equation requires a **Manning's n** and **swale channel slope (S)**. Herbaceous vegetation has an estimated Manning's n value of **0.04**, and the **channel slope** of the design example is 0.005 ft/ft.

$$Q_p = \left(\frac{1.486}{0.04} \right) * 7 * 0.068^{0.667} * 0.005^{0.5}$$

$$Q_p = 14.2 \text{ ft}^3/\text{s}$$

Using EQN 3 and the calculated variables, peak flow is calculated as follows:

The calculated Q_p using the Manning's equation, is compared to the peak flow (Q_p) determined by the rational method equation. If the peak flow determined by the Manning's equation is equal to or greater than the peak flow calculated in the rational method, the swale geometry is sufficient for peak flow. However, if peak flow calculated in the Manning's equation is less, then the swale geometry is insufficient, and swale dimensions need to be altered. In this example, due to site constraints, the only available dimension for alteration would be the swale depth.

3. Check Channel Velocity.

The continuity equation (EQN 6) can be used to verify that the velocity in the swale channel does not exceed what the vegetation can sustain without resulting in erosion. $Q = VA$, where Q_p is used to determine the maximum velocity within the designed channel.

The peak flow for the designed system is Q_p , which is determined using the Manning's equation, 14.2 ft³/s.

Continued on next page

Transposed to solve for the maximum velocity:

$$\text{EQN 7.10} \quad Q = V * A \quad Q_p = V_{\max} * A \quad \frac{Q_p}{A} = V_{\max}$$

$$V_{\max} = \frac{14.2 \text{ ft}^3/\text{s}}{7 \text{ ft}^2} = 2.03 \text{ ft/s}$$

Since V_{\max} is less than 4 fps, turf reinforced matting (TRM) is not necessary.

This design example is for an infiltration swale. The soil was amended with a 50/50 sand and existing soil mix to a depth of 3' below the swale bottom and was planted using vegetation described in the vegetation design example. Additionally, a wet swale vegetation plan is shown in the vegetation design example; however, like the vegetation, the SCM engineering and design would change based on channel geometry and site constraints.

CONSTRUCTION

Compaction: Heavy equipment used to excavate the swale should not be operated within the swale channel to minimize compaction. The bottom of the swale should be scarified, chiseled, or ripped prior to placing any media or soil mix to further enhance infiltration, especially when native, well-drained soils are used. If constructed properly, post-construction infiltration rates should be similar to preconstruction infiltration rates.

Erosion and sediment control: Use erosion control blankets if the swale will receive runoff before vegetation is established. (Refer to the Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas for guidance on erosion matting.)

Vegetation: To prevent scour, vegetation should be established prior to diverting runoff into the swale.

Underdrains: If underdrains are desired, consider a gravel layer. The gravel layer is comprised of No. 57 stone at a depth of 2" greater than the diameter of the underdrain pipe.

Bioretention media: Infiltration swales that use a bioretention media should have a minimum infiltration rate of 0.5"/hr. To achieve this, the bioretention media uses 85–88% washed sand, 8%–12% fines, and 3%–5% aged organics. (For more information on targeted pollutant removal using this mix, see section on Bioretention.)

Mulch: Infiltration swales have a 3" layer of double- or triple-shredded hardwood mulch. Hardwood mulch is recommended, but other mulches such as pine bark or pine straw have been successfully used, although they may require more frequent replacement. All mulches float; however, coarser-textured mulches

such as pine bark are more likely to float throughout the swale and clog the overflow device. Mulch should be aged at least six months.

Retrofits: Swales used during construction as components of a site's erosion and sediment-control plan can be retrofitted to function as a water-quality swale. Regrading of the channel and slope may be necessary, as well as complete sediment removal within the channel and the establishment of the proper vegetation.

VEGETATION

Channel vegetation is dependent on the type of swale design (i.e., grassed, infiltration, or wet swale).

Grassed swales: Grassed swales using sod are less likely to encounter establishment issues, as sod provides a quick and dense cover.

Infiltration swales: Infiltration swales support drought-tolerant plants that thrive under brief flooding during and after a rainfall event. Most of these plants have a facultative (FAC) wetland indicator status.

Wet swales: Wet swales utilize wetland plants in the channel and may have turfgrass or native grasses planted on the side slopes. Wet swale channel plants usually have a facultative wet (FACW) or obligate (OBL) wetland indicator status, since the channels of wet swales have standing water present the majority of the time. (*For more information on wetland indicator status, see Appendix D: Vegetation.*)

Seeding: The side slopes can be seeded with native grass if stormwater is conveyed into the swale channel from a forebay pretreatment device or if runoff is diverted until seeds are established. Depending on time of year, temporary seeding of the side slopes may be necessary. Seeding the swale channel or any part of the swale that receives stormwater is not recommended unless paired with an erosion control blanket. (*See the Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas for details regarding erosion control blankets and seeding recommendations.*)

Plant sizes: Most native grasses, herbaceous perennials, and shrubs can be purchased as containerized plants ranging in sizes from plugs or liners (~ 2"–4" pots) up to three-gallons. Using containers provides quick cover, since containers

establish more quickly than seeds. Wet swale plants can be harvested locally or ordered from wetland plant nurseries as plugs or one-gallon containers.

Harvesting plants: Harvesting locally is labor intensive and may require a permit to ensure legality. To harvest, wetland plants are divided, and tubers or rootballs are transplanted on site. While harvested plants are beneficial because of quick establishment and prior adaptation to local climate conditions, invasive plant species can be introduced.

Plant height: Plants for swale channels should never be completely submerged. Plant height in the channel should be no less than the maximum ponding depth. When plants are fully submerged or bend to accommodate high flows, swale channel roughness is reduced, resulting in higher flow velocities and reduced filtering contact of plants.

Plant establishment: Infiltration swale vegetation can be installed any time of the year when using containerized plants. Installing plants during the summer, however, requires more frequent irrigation until plant establishment, regardless of the size plant used. High temperatures and decreased rainfall during summer months reduce the chance for plant survival. Fall installations are also appropriate, as this is the ideal time of year for division or transplant of most perennial plants and a milder climate is experienced during this season. Wet swale plants should be installed from April to October.

Turf Establishment: For June to September installation, irrigate newly planted turf at planting so that the surface does not dry out. Water sod daily for the first one to two weeks to keep it evenly moist. As the sod begins to grow new roots, irrigation frequency can be decreased, but a larger volume of water should be applied at each watering. Supplement rainfall so that turfgrass receives about 1"–1.5" per week from all irrigation sources. Turfgrass sod planted during dormancy requires less irrigation for establishment. In some cases, a dormant planting will not need any supplemental irrigation because rainfall during these months is sufficient for turf to establish. Dormant plantings may benefit from irrigation however, during spring months when sod begins to produce new growth.

TABLE 7.5. INFILTRATION SWALE PLANT LIST				
BOTANICAL NAME	COMMON NAME	HABIT	PREFERS	COMMENTS
<i>Asclepias tuberosa</i>	butterfly weed	herbaceous perennial	sun	Used as host and nectar source for monarch butterfly
<i>Baptisia alba</i>	white false indigo	herbaceous perennial	sun to part shade	
<i>Clethra alnifolia</i>	summersweet clethra	deciduous shrub	sun to part shade	Sixteen Candles is a good dwarf.
<i>Conoclinium coelestinum</i>	mistflower	herbaceous perennial	sun to part shade	Wayside Form is a good compact growth cultivar.
<i>Echinacea purpurea</i>	purple coneflower	herbaceous perennial	sun to part shade	Long bloom season
<i>Eragrostis spectabilis</i>	purple lovegrass	native grass	sun	Compact native grass
<i>Gaillardia pulchella</i>	firewheel	herbaceous perennial	sun	Very heat and drought tolerant
<i>Fothergilla gardenii</i>	dwarf witchalder	deciduous shrub	sun to part shade	Not tolerant of extended flooding
<i>Hypericum densiflorum</i>	bushy St. Johnswort	deciduous shrub	sun	Creel's Gold is a good dwarf.
<i>Ilex glabra</i>	inkberry holly	evergreen shrub	part shade	Shamrock is a good dwarf.
<i>Ilex verticillata</i>	winterberry	deciduous shrub	sun to part shade	Red Sprite is a good dwarf.
<i>Ilex vomitoria</i>	dwarf yaupon holly	evergreen shrub	sun to part shade	Stokes' or Schillings are good dwarfs.
<i>Itea virginica</i>	sweetpire	deciduous shrub	sun to part shade	Little Henry is a good dwarf.
<i>Liatris spicata</i>	gayfeather	herbaceous perennial	sun to part shade	Narrow form
<i>Lindera benzoin</i>	spicebush	deciduous shrub	sun to part shade	

continued on next page

Botanical Name	Common Name	Habit	Prefers	Comments
<i>Morella cerifera</i>	wax myrtle	evergreen shrub	sun to part shade	Tom's Dwarf is a good dwarf.
<i>Muhlenbergia capillaris</i>	muhly grass	native grass	sun to part shade	Very drought tolerant
<i>Panicum virgatum</i>	switchgrass	native grass	sun to part shade	Flood and drought tolerant
<i>Physostegia virginiana</i>	obedient plant	herbaceous perennial	sun to shade	Can be aggressive
<i>Rudbeckia fulgida</i>	orange coneflower	herbaceous perennial	sun to part shade	Long bloom season
<i>Schizachyrium scoparium</i>	little bluestem	native grass	sun to part shade	
<i>Sorghastrum nutans</i>	Indiangrass	native grass	sun to part shade	
<i>Stokesia laevis</i>	Stokes' aster	herbaceous perennial	sun to part shade	Long bloom season
<i>Tradescantia virginiana</i>	spiderwort	herbaceous perennial	sun to shade	
<i>Vernonia gigantea</i>	giant ironweed	herbaceous perennial	sun	
<i>Vernonia noveboracensis</i>	New York ironweed	herbaceous perennial	sun	
<i>Viburnum dentatum</i>	arrowwood	deciduous shrub	sun to part shade	
<i>Viburnum nudum</i>	possumhaw	deciduous shrub	sun to part shade	

TABLE 7.6. WET SWALE PLANT LIST				
Botanical Name	Common Name	Habit	Prefers	Comments
<i>Carex crinita</i>	fringed sedge	grass-like, evergreen	part shade	Can be divided
<i>Hibiscus moscheutos</i>	rosemallow	herbaceous perennial	sun to part shade	Attracts birds, hummingbirds, and ducks
<i>Iris virginica</i>	southern blue flag iris	herbaceous perennial	sun	Do not plant the nonnative invasive yellow flag iris (<i>I. pseudacorus</i>); <i>I. versicolor</i> is the Northern blue flag iris.
<i>Juncus effusus</i>	common rush	grass-like, evergreen	sun to part shade	Can be divided
<i>Lobelia cardinalis</i>	cardinal flower	herbaceous perennial	Sun to shade	Butterfly and hummingbird attractant; self sows
<i>Peltandra virginica</i>	arrow arum	herbaceous perennial	part shade	Attracts birds
<i>Pontederia cordata</i>	pickerelweed	herbaceous perennial	sun to part shade	Attracts dragonflies
<i>Sagittaria latifolia</i>	duck-potato	herbaceous perennial	sun to part shade	Starchy rhizomes attract ducks and snapping turtles; colonizing
<i>Saururus cernuus</i>	lizard's tail	herbaceous perennial	part shade to shade	Colonizing; dominates during drought
<i>Sysyrinchium angustifolium</i>	blue-eyed grass	herbaceous perennial	sun to part shade	If allowed to dry out, will decline
<i>Sparganium americanum</i>	bur-reed	herbaceous perennial	sun to part shade	Tolerates flowing water

TABLE 7.7. TURGRASS LIST FOR GRASSED SWALES, SWALES SIDE SLOPES AND GRASSED INLETS			
Name	Prefers	Drought Tolerance	Comments
Bermudagrass	sun	excellent	Tolerates foot traffic; spreads above and below ground; fast growth rate; use statewide
centipedegrass	sun to part shade	good	Slow growing; sensitive to some herbicides (check label); may be susceptible to cold injury in north, AL
St. Augustinegrass	sun to shade	good	Adapted better to the bottom third of the state; spreads aboveground; fast growing; can be sensitive to herbicides; most shade-tolerant turf; used in central and south, AL
zoysiagrass	part shade	excellent	Used statewide; most cold tolerant of warm season turfgrasses; slow growing

**Adapted from Han and Huckabay, 2007. (See References for full attribution.)*

Vegetation Design Guidelines

- Swales are long and linear. Because of this, it can be helpful to sketch channel vegetation in 10' or 20' sections.
- Low-growing perennials, grasses, and shrubs are planted in the channel if not grassed.
- Swale side slopes are planted with turfgrass or native grass.
- Low-maintenance native grasses are sometime/s used because mowing is needed only once per year.
- Nonturfgrass swale vegetation should have varied seasonal interest and growth patterns.
- Dwarf cultivars are suitable for smaller channel widths.

Infiltration Swale Design Example

An infiltration swale is designed to capture runoff from the backside of a parking lot. In this example, the channel is 4' wide. Visibility from the road and parking lot may limit the use of taller-growing vegetation in the channel. This vegetation plan can be used for an infiltration swale using a 50/50 sand/soil mix or a bioretention media mix.

This design was sketched using a circle template and drawn to scale to reflect mature plant sizes. Woody shrubs used are dwarf cultivars with a maximum width of 4'. (For more information on cultivars, see Appendix D: Vegetation.)

The length of the infiltration swale is 50'. Because of this, it is helpful to draw a vegetation plan only for a couple of 10' sections that can be repeated throughout the length of the swale. The side slopes can be planted with Bermudagrass used as pretreatment into the swale.




Figure 7.7. Infiltration swale.

Wet Swale Design Example

For this example, a wet swale is located downslope of a trash compactor site. A forebay is utilized as pretreatment. The channel width is 3' and the swale is 50' in length. Wetland vegetation is planted in the channel with some herbaceous and semievergreen species. Panicum virgatum (switchgrass) is planted on the side slopes since the site is mowed only once per year. Due to the site location at a trash compactor site, weekly trash cleanup is needed to remove stray trash and large items from the forebay and channel.



Figure 7.8. Wet swale.




Figure 7.9. Wet swale.

MAINTENANCE

Long-term functionality of swales is directly equivalent to the frequency in which maintenance is performed. Although maintenance of infiltration swales can be more frequent, it is still considered less expensive over its life cycle, compared to traditional curb and gutter maintenance.

Trash and litter: Swales in commercial or industrial settings tend to collect more litter and may need monthly or even weekly trash removal for aesthetics and to avoid clogging.

Sediment removal: Accumulated sediment can form sandbars that inhibit flow patterns and have the potential to be re-suspended, transported throughout the swale, and eventually transported off site. Excess sediment can also smother swale vegetation. For small channel widths, sediment is best removed by hand using a flat shovel and metal rake. If excessive sediment clogs the swale often, check upslope for loose or bare soil areas that need to be stabilized.

Plant maintenance: Where plant aesthetics are important, more frequent plant maintenance is required. Wet swales and infiltration swales using a mixture of native grasses, small shrubs, and herbaceous perennials should not be mowed or cut back more than once a year. Maintain vegetation at the maximum height appropriate to the plant and site requirements, striving for a dense cover. Install additional plants when plant replacement is needed.

Mowing: Grassed swales with turfgrass require mowing during the growing season. Remove clippings from the swale to minimize clogging and nutrient release. Maintain turfgrass at a height no lower than 5" or the design depth. At lower mowing heights, velocities are not adequately slowed in the swale channel, and plants may become completely submerged causing damage and possibly mortality.

Nuisance species: Remove unwanted plants or weeds, from the swale channel and side slopes. In wet swales, cattails (*Typha latifolia*) can become a nuisance as they quickly displace other native plant species to form dense monocultures. Moreover, cattails promote mosquito infestation and have high mosquito counts. Use herbaceous plants that attract mosquito predators such as dragonflies in wet-swale applications to minimize mosquito populations.

TABLE 7.8. MAINTENANCE SCHEDULE

Task	How Often	Comments
Erosion inspection	During and after major storm events for first 2 years, annually thereafter	Repair ruts, holes, or gullies with soil and vegetation cover.
Inspection	After 0.5" or greater rainfall event	Visually inspect all components, including any pretreatment device, channel, overflow structure, and vegetation, for damage.
Trash removal	At least annually; twice a year is better	Trash removal frequency depends on location of the swale.
Sediment removal from the channel	When it reaches 4"	Remove sediment from the channel when it reaches a depth of 4" or when vegetation is covered.
Sediment removal from the forebay	Site dependent	Remove sediment and other debris from the forebay when the storage volume is greatly decreased or when the forebay is half full.
Turfgrass mowing	Every other week in growing season	Mow more often during the growing season; dense, low-growing vegetation is best to maintain diffuse flow. Maintain turfgrass at a height no lower than 5" or the design depth.
Native grasses mowing	Annually	Mow most native grasses before new growth appears in spring.
Herbaceous and woody vegetation pruning	Annually	Collect leaves dropped from deciduous shrubs and herbaceous plants to decrease clogging of mulch or any damming that might occur in the channel. Prune woody shrubs based on the May Rule (see Appendix D: Vegetation).
Invasive plants removal	Twice a year	Remove weeds or other invasive plants, as they crowd and rob native plants of water, sunlight, and nutrients.
Mulch replacement	Every 2 years	Infiltration swales require mulch removal and replacement. Replenish bare areas as they occur.
Irrigation	During plant establishment	Channel vegetation requires irrigation during plant establishment. The frequency is largely dependent on the time of year of plant installation and precipitation. Plants should not require any irrigation beyond establishment.
Plant replacement	When dead plants are noted	Replace sod or other plants when they are choked out by sediment. Replant as needed to maintain dense cover.



Figure 7.10. Pickerelweed is planted to attract dragonflies, Phenix City, AL.

POLLUTANT REMOVAL

Swales are most effective when channels are broad, slopes are not steep or flat, and vegetation is dense. The ability of swales to reduce runoff volumes is largely dependent on the drainage area size, surrounding land use, slope, underlying soil, and vegetation density and type. Swales remove pollutants primarily through sedimentation but also through infiltration, filtration, and biofiltration. As with most LID practices, increased removal efficiencies are dependent on their design, soils, vegetation, and maintenance.

Enhancing pollutant removal: Dense vegetation increases the pollutant removal capabilities by increasing runoff contact time. Coupled with small storm events and well-drained soils, the pollutant removal efficiency may be increased even more.

Check dams: Checking dams or other depressional storage areas within the channel can aid in enhancing pollutant removal by improving storage and slowing runoff from steep longitudinal slopes on-site.

In-situ soil: Infiltration swales with a bioretention media mix typically have higher pollutant removal capabilities due to the specialized soil media designed to filter pollutants. Function and treatment capabilities are increased when in-situ soils

TABLE 7.9. POLLUTANT REMOVAL TABLE

	Sediment	Nutrients		Metals	Pathogens
		N	P		
Grassed swale	a. 35%	20%	20%		Low
	b. 80%	50%	50%	40%	No data
Enhanced swale	c. 80%	50%	50%	40%	No data
	c. 80%*	40%*	25%*	20%*	
	d. 50%	20%	25%	30%	Insufficient data

a. North Carolina Department of Environment and Natural Resources, 2007

b. City of Auburn, 2011

c. Georgia Manual, 2011

d. Iowa State University, 2008

* Represents data for a wet swale. All others are for dry swales.

are well drained. It has been reported that alkaline soils may facilitate the retention of metals in the swale.

Phosphorus: A soil media with a low phosphorus concentration and high phosphorus sorption is recommended so that phosphorus is not exported from the system.

Wet swales: Native wetland plants are used in the channel, to uptake nutrients and promote biological processes that filter excess nutrients and other pollutants. Wet swales function similarly to a small, shallow constructed stormwater wetland. These linear wetland areas foster anaerobic conditions favorable to nutrient cycling processes such as denitrification.

Seasonal variations: Seasonal pollutant removal efficiency variations are expected in swales due to winter dormancy of vegetation. Note that plant dieback and subsequent reduced plant cover can result in increased erosive forces during wet weather associated with winter months; thus can lead to downstream sedimentation.

Vegetation: For increased pollutant removal efficiency, a mix of herbaceous, deciduous, and evergreen vegetation is recommended for all types of swales; however, each project site may have different aesthetic value and needs associated with it.

REFERENCES

- Alabama Soil and Water Conservation Committee. 2009. *Alabama Handbook for Erosion Control, Sediment Control, and Stormwater Management on Construction Sites and Urban Areas*. Montgomery, AL.
- Atlanta Regional Commission. 2001. *Georgia Stormwater Management Manual*.
- California Stormwater Quality Association. 2003. *California Stormwater BMP Handbook: New Development and Redevelopment* Ch TC-30. Menlo Park, CA.
- City of Auburn, AL. 209. *City of Auburn Stormwater Management Design Manual*.
- Han, D., and E. Huckabay. 2007. *Selecting Turfgrasses for Home Lawns*. Alabama Cooperative Extension System ANR-0092.
- Hunt, W. F. 1999. *Urban Stormwater Structural Best Management Practices (BMPs)*. North Carolina Cooperative Extension AG-587.
- Hunt, W. F., C. S. Apperson, and W. G. Lord. 2012. *Mosquito Control for Stormwater Facilities*. North Carolina Cooperative Extension AG-588-4.
- “Grass Swales.” *Iowa Stormwater Management Manual*, Ch 2I-2. Iowa State University. 2007. Ames, IA: Transportation Institute.
- “Dry Swales.” *Iowa Stormwater Management Manual*, Ch 2I-2: Iowa State University. 2010. Ames, IA: Transportation Institute.
- Lichvar, R. W., and P. Minkin. 2007. *Concepts and procedures for updating the national wetland plant list*. U.S. Army Corps of Engineers, Engineer Research and Development Center ERDC/CRREL TN-08-3.
- North Carolina Department of the Environment and Natural Resources. 2006. *Stormwater Best Management Practices Manual*, “Grassed Swale” ch 14, (chapter revised 2009) and “Stormwater Wetlands” ch 9, (chapter revised 2009). Raleigh, NC: North Carolina Division of Water Quality.
- Pennsylvania Department of Environmental Protection. 2012. *Pennsylvania Stormwater Best Management Practices Manual*, Ch 12.4.7. Harrisburg, PA: Pennsylvania Bureau of Watershed Management.
- Stevens, M., and C. Hoag. 2000. *Broad-Leaved Cattail*. Aberdeen, ID: US Department of Agriculture, Natural Resources Conservation Service.
- University of Florida. 2007. “Bioswales/Vegetated Swales Fact Sheet.” University of Florida Extension, Program for Resource Efficient Communities. *Florida Field Guide for Low Impact Development*.
- United States Environmental Protection Agency. 1999. *Stormwater Technology Fact Sheet: Vegetated Swales*. Washington, D.C: Office of Water.
- Virginia Department of Forestry. 2007. *Rain Gardens Technical Guide*. Charlottesville, VA: Virginia Department of Forestry.

LEVEL SPREADERS AND GRASSED FILTER STRIPS

Level spreaders are devices that create diffuse or sheet flow that is evenly distributed or dispersed to decrease flow velocity and discourage erosive forces associated with concentrated flows.

Other names for it include water spreader, grass filters, grassed buffer strips, filter strips, engineered buffer strips, and engineered filter strips. Most commonly, level spreaders are paired with grassed filter strips, riparian buffers, or a combination of the two to provide pollutant removal. The primary purpose of a level spreader is to disconnect impervious surfaces by creating nonerosive stormwater connectivity with grassed filter strips.



A grassed filter strip is a linear strip of dense vegetation that receives sheet flow of stormwater runoff from a nearby impervious surface or level spreader in order to reduce peak discharge rates, encourage sediment deposition, and provide limited infiltration. Grassed filter strips are planted with turfgrass, which is easy to maintain and blends seamlessly into urban landscapes. Grassed filter strips are most effective when combined with level spreaders.

SITE SELECTION

Evaluating soils: Use the USDA Web Soil Survey to identify soil map units and to make initial interpretations for potential uses and limitations of a site. Since most soil map units have inclusions of other soils that may be quite different, detailed evaluations should be made at the proposed site by a professional soil scientist or soil classifier. On-site evaluations should properly identify a soil or the hydrologic soil group (HSG). Make the final decision for use based on the detailed determination of soil series or HSG. (For a detailed list of HSG properties, see table A.3 in Appendix A: Stormwater Hydrology.)

Poorly drained soil: An underdrain is recommended when infiltration rates are < 1"/hr. (See section on Rain Gardens for information on infiltration testing.)

Practice pairing: The purpose of a level spreader is to create diffuse flow; therefore, the level spreader is commonly paired with another stormwater control measure (SCM) to provide pollutant removal. Runoff from an impervious drainage area may be directed to level spreader and grassed filter strip systems, or they may receive overflow from another SCM such as a swale or bioretention cell.

Riparian buffers: Level spreader/grassed filter strip systems are commonly sited upslope of riparian buffers, where they create sheet flow of stormwater and reduce peak flows into streamside forests.

Quantity control	No
Drainage area	Small
Space required	Small
<i>Works with:</i>	
Steep slopes	No
Shallow water table	No
Poorly drained soils	Yes

Construction cost	Low
Maintenance	Low
Community acceptance	High
Habitat	Medium
Sun/Shade	Either

TABLE 8.3. SITE SELECTION: CONSTRAINTS AND LIMITATIONS FOR LEVEL SPREADERS AND GRASSED FILTER STRIPS

Slope	Slopes greater than 6% do not allow for adequate treatment in grassed filter strips.
Utilities	Call 811 before construction to locate utilities. (For more information visit www.al1call.com .)
Large drainage areas	Draining larger watersheds requires longer level spreaders that are difficult to construct and are less efficient.
High sediment loads	Avoid high sediment loads if possible, particularly on sites with active construction.

Drainage area: Level spreaders are intended to capture runoff in small watersheds; flow volumes from larger watersheds require longer level spreaders that are difficult to construct.

Velocity: Direct no more than 10' per second (fps) into a level spreader/grassed filter strip system. Diffuse flow occurs at velocities of less than 2 fps. Turf reinforced matting (TRM) is recommended if velocities are greater than 4 fps. A flow splitter to divert larger flows to a swale or other SCM can be incorporated.

Slope: Grassed filter strips are designed for areas with a 2%–6% slope. A slope greater than 6% is too steep for effective stormwater treatment, and a slope less than 2% may result in standing water.

Filter strip width: A minimum width of 25' is recommended for grassed filter strips.

Local ordinances: Consult local government stream buffer regulations and ordinances prior to design and construction of these systems.

DESIGN

Collect information for watershed size, in-situ soil, hydrologic soil group (HSG), slope, and depth to water table. The design layout or level spreader location is specific to the site. When determining the best location for the level spreader/grassed filter strip system, consider constraints, retrofit opportunities, and aesthetics.

The level spreader/grassed filter strip system consists of four primary components: forebay, channel, level spreader lip, and the grassed filter strip. The size of each of these components is based on the volume or design storm to be captured.

Components

Forebay: A forebay is used as a pretreatment device for level spreader systems. A forebay is a pool that is used for initial storage and as a sediment trap for runoff entering the system, it prevents clogging of the channel behind the level spreader lip. The forebay for this system should be 12"–18" deep and used only in situations where standing water is not considered a safety concern. It is deepest at the point of runoff entry and shallower at the point of exit, which allows for energy dissipation within the forebay. If soils on site are poorly drained (<1"/hr), an underdrain may be needed below the forebay to prevent standing water for extended periods of time. Design the forebay to be 0.2% of the watershed drainage area.

Level spreader channel/

blind swale: The level spreader channel or "blind swale" (because of terminal ends) is located directly upslope of the level spreader.

This swale is designed so that

water fills the channel and spreads evenly over the level spreader, creating diffuse flow into the grassed filter strip. The swale is constructed of existing earth and may be lined with turfgrass. In urban settings, a concrete channel may be desired for ease of trash and sediment removal. In clayey soils, an underdrain may need to be installed beneath the swale.




Figure 8.1. Straight level spreader plan view.




Figure 8.2. Convex level spreader plan view.

Level spreader: The level spreader is a poured concrete weir-constructed level (0% slope). It is placed on an appropriate concrete footer. The level spreader should be designed and constructed to remain level. Level spreaders may be straight or convex in plan view, but not concave. This is primarily to prevent concentrated flows downslope.

Level spreader lip: The lip of the level spreader on the downslope side should be at least 3" higher than the existing grade.

Filter fabric: Downslope of the level spreader, a minimum 3'-wide strip of geotextile filter fabric and 3" layer of aggregate stone should be applied. Nonwoven 40-oz fabric is recommended but should be selected based on in-situ soil conditions. The stone can be No. 57, No. 1, or designer preference.




Figure 8.3. Level spreader cross section.

Grassed filter strip: A grassed filter strip is graded to have a consistent and uniform slope. The filter strip is planted with turfgrass, and the length of the filter strip may be dependent on local government stream buffer regulations.

Design Guidance

1. Determine peak flow.

Level spreaders are designed to treat peak flow. The peak flow event is the primary design storm used to design the level spreader channel. The Kirpich equation and rational method are used to determine peak flow (Q_p) and to calculate level spreader channel geometry. The Kirpich equation shown in EQN 8.1 uses the longest length in the drainage area (L) and the change in elevation (H) to calculate the time of concentration (T_c).

EQN 8.1

$$T_c = \frac{\left(\frac{L^3}{H}\right)^{0.385}}{128}$$

L = Longest length of drainage area or watershed (ft)
 H = Change in elevation throughout drainage area or watershed (ft)
 T_c = Time of concentration (minutes)

EQN 8.2

$$Q_p = CiA$$

C = Rational coefficient (dimensionless)
 See Table A.2 in Appendix A: Stormwater Hydrology
 i = Rainfall intensity (in/hr)
 A = Watershed area (ac)
 Q_p = Peak flow (ft³/s)

Using the time of concentration (T_c), a design storm can be determined and the rainfall intensity (i) derived. If T_c is 4.6 minutes, round to the nearest given unit of time, 5 minutes. Peak flow (Q_p) is calculated using the rational method, (EQN 8.2.)

$$Q_p = \text{Peak flow (ft}^3/\text{s)}$$

2. Determine the level spreader channel geometry.

Calculating level spreader channel geometry may require several design iterations using Manning's equation (EQN 8.3). Triangular channels are easy to construct and work well in small drainage areas treated by level spreaders. If a trapezoidal level spreader channel geometry is desired, please refer to section on Grassed Swales, Infiltration Swales, and Wet Swales.

The level spreader channel cross-sectional area (A) and hydraulic radius (R) are affected by level spreader channel geometry.

Side slope: A 5:1 side slope is recommended; however, a 3:1 is acceptable.

Channel slope: The level spreader channel slope is not the same as site slope or side slopes. The channel slope is the slope in the bottom of the level spreader channel and should be as flat as possible. Since the level spreader channel employs a blind swale, the channel slope should be minimal to avoid erosion, scour, and potential breach of the level spreader channel.

Depth (D) is determined using peak flow (Qp) calculated from EQN 8.2 in Manning's equation (EQN 8.3).

A modified Manning's Equation for a triangular channel with 3:1 and 5:1 side slopes is shown in EQNs 8.4 and 8.5. A modified Manning's Equation

EQN 8.3

$$Q_p = \left(\frac{1.486}{n} \right) * A * R^{0.667} * S^{0.5}$$

n = Manning's n (dimensionless) – for more information see Appendix A: Stormwater Hydrology
A = Swale channel cross-sectional area (ft²) based on swale geometry
R = Hydraulic radius (ft)
S = Swale channel slope (ft/ft)

for a triangular channel with 3:1 and 5:1 side slopes is shown in EQNs 8.4 and 8.5.

Once D is calculated, side slopes and channel geometry are used to calculate the swale top width (b). The continuity equation, (EQN 8.6) can be used to validate the velocity within the level spreader channel and determine if there is

EQN 8.4 for 3:1 side slopes

$$Q_p = \left(\frac{2.71}{n} \right) * D^{2.67} * S^{0.50} \quad D = \left(\frac{Q_p * n}{2.71 * S^{0.5}} \right)^{\frac{1}{2.67}}$$

EQN 8.5 for 5:1 side slopes

$$Q_p = \left(\frac{4.62}{n} \right) * D^{2.67} * S^{0.50}$$

n = Manning's n
D = Depth (ft)
S = Swale channel slope (ft/ft)
Q_p = Peak flow (ft³/s)

a need for turf reinforced matting (TRM) or additional vegetation to prevent erosion and scour within the swale channel. If velocity (V) exceeds 4 fps, TRM is necessary.

EQN 8.6

$$Q = V * A$$

Q = Flow (ft³/s)
V = Average velocity in channel (ft/s)
A = Swale channel cross-sectional area (ft²) based on swale geometry

Design Example

1. Determine peak flow.

A residential site in northwest Alabama is used for this design example. The level spreader is treating a small 1 acre parking lot that holds a pool house.

A level spreader and grassed filter strip capture parking lot runoff prior to entering a riparian buffer on the backside of the property. For this example, a triangular level spreader channel is designed, and turfgrass is planted in the grassed filter strip. The design of the concrete footer, level spreader detail, and grassed filter strip dimensions are not included in this example.

The level spreader channel is designed for the peak flow event using the Kirpich equation (EQN 8.7).

EQN 8.7

$$T_c = \frac{\left(\frac{L^3}{H} \right)^{0.385}}{128} \quad T_c = \frac{\left(\frac{400^3}{4} \right)^{0.385}}{128} = \frac{594}{128} = 4.6 \sim 5 \text{ min}$$

The longest length in the drainage area (L) is 400', and the change of elevation (H) is 4'.

Therefore, the time of concentration is

The Tc is used to calculate rainfall intensity (i) in the rational method (peak flow equation). The design storm or rainfall intensity (i) is determined using the 10-year flow event and closest estimate of the Tc. Since the lowest calculated Tc is 5 minutes, the 10-year, 5-minute intensity is used. (*For more detail on how to determine storm intensity, refer to Appendix A: Stormwater Hydrology.*)

To determine peak flow (Qp) from the 10-year, 5-minute event, the rational method (EQN 8.8) is used.

A rational coefficient (C) of 0.95 for parking lot runoff (impervious) and Intensity (i) of 6.2 in/hr (from appropriate IDF curve) are determined using the 10-year, 5-minute event. Area (A) of 1 acre for the impervious parking lot is used.

EQN 8.8

$$Q_p = C I A$$

Converting the intensity (i) 6.2 in/hr to ft/s:

$$Q_p = 0.95 * 7.2 \text{ in/hr} * 1.0 \text{ ac}$$

$$7.2 \text{ in/hr} \left| \frac{1 \text{ ft}}{12 \text{ in}} \right| 0.6 \text{ ft/hr} \left| \frac{1 \text{ hr}}{3600 \text{ in}} \right| = 0.00016666 \text{ ft/s}$$

Converting 1 acre into square feet: $1 \text{ ac} \left| \frac{43,560 \text{ ft}^2}{1 \text{ ac}} \right| = 43,560 \text{ ft}^2$

Therefore, the level spreader channel needs to be able to handle peak flows of 6.8 cfs.

EQN 8.9 $Q_p = CiA$
 $Q_p = 0.95 * 0.00016666 * 43560 = 6.8 \text{ ft}^3 / \text{s}$

2. Determine the level spreader channel geometry.

The level spreader channel has 3:1 side slopes and a triangular shape. Manning's equation (EQN 8.10) can be used to confirm the calculated geometry.

EQN 8.10 $Q_p = \left(\frac{1.486}{n} \right) * A * R^{0.667} * S^{0.5}$

Since the level spreader channel has these dimensions (3:1 side slopes and triangular shape), a modified Manning's equation (EQN 8.11) can be used to calculate channel depth (D).

EQN 8.11 $D = \left(\frac{Q_p * n}{2.71 * S^{0.5}} \right)^{\frac{1}{2.67}}$

Using the calculated Q_p , a Manning's n 0.03 for grass and a slope of 0.005 ft/ft (0.25 ft/50 ft), a level spreader channel depth (D) can be calculated.

$$D = \left(\frac{Q_p * n}{2.71 * S^{0.5}} \right)^{\frac{1}{2.67}} = \left(\frac{6.8 * 0.03}{2.71 * 0.005^{0.5}} \right)^{0.375} = \left(\frac{0.204}{0.192} \right)^{0.375} = 1 \text{ ft}$$

Using a calculated depth (D), of 1', a channel top width (b) can be determined by multiplying D by the side slope and 2 as shown: $b = 1 \text{ ft} * 3 * 2 = 6 \text{ ft}$

Using the area of a triangle equation as shown in EQN 8.12 and 6' as the calculated base, $A = 0.5 * b * h$, where $b = 6 \text{ ft}$ and $h = D = 1 \text{ ft}$, area can be calculated as $A = 3 \text{ ft}^2$

Using peak flow (Q_p) and the calculated area (A) of 3 ft^2 , the continuity equation (EQN 8.6) can be used to verify that the velocity in the level spreader channel does not exceed what can be sustained by vegetation without causing erosion.

$Q_p = V_{max} * A$, where Q_p is used to determine the maximum velocity (V_{max}) within the designed channel.

$$Q_p = V_{max} * A, \quad \frac{Q_p}{A} = V_{max} = \frac{6.8 \text{ ft}^3/\text{s}}{3 \text{ ft}^2} = 2.3 \text{ ft/s}$$

Since V_{max} is less than 4 fps, TRM is not necessary in the channel. The channel and filter strip will be planted with bermudagrass sod. See the Vegetation section below for information on turf establishment.

Swale Geometry

(illustrations are exaggerated)
for triangular swale geometry:

EQN 8.12

$$A = 0.5(b * h)$$


$$P = a + b + c$$

for trapezoidal swale geometry:

$$T = b + y(z_1 + z_2)$$

$$A = \frac{y}{2} (b + T)$$

$$P = b + y \left(\sqrt{1 + z_1^2} + \sqrt{1 + z_2^2} \right)$$



Note: typically $z_1 = z_2$

CONSTRUCTION

Construction sequencing ensures that water-quality improvement is the primary function of the level spreader and grassed filter strip. Prior to construction, the designer should examine ground contours and specify that the level spreader be parallel to contours to minimize grading.

Existing riparian buffers: The designer should visit the site to confirm that the width of the level spreader and grassed filter strip system does not encroach on an existing riparian buffer or wetland areas.

Erosion and sediment control: Protect the level spreader system from sediment deposition and runoff during construction to prevent erosion, compaction, and clogging of the system.

Compaction: Operate equipment outside of the proposed grassed filter strip to prevent compaction. Loosen any compacted soil to a depth of at least 4". Install sod on the filter strip.

Level spreader channel: Following completion of the grassed filter strip, construct the level spreader channel according to the design depth.

Level spreader lip: It is recommended that the level spreader lip be constructed using concrete for long-term functionality. Earthen level spreader lips are erodible and likely to encourage vegetation growth on the lip, which inhibits sheet flow. Moreover, earthen and gravel lips often fail in urban settings.

Level spreader: Cast the level spreader in place using industry standards for concrete, and construct it on undisturbed soil whenever possible. Build forms to cast the level spreader. The top of the forms should be level and approximately 3" higher than soil downslope. Level the surface of the level spreader lip using a screed such as a wooden dowel or other tool. Allow the level spreader to set up overnight and should be protect it during this process. Once forms are removed, the remaining level spreader channel configuration can be constructed.

Underdrain: An underdrain may be necessary under the level spreader channel and forebay if in-situ soil drainage is poor (<1"/hr). Underdrains are corrugated or

Please review proper sediment control practices in the Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas (swcc.alabama.gov/).

smooth-wall perforated pipe. They should be configured to tie in with overflow or discharge into the stormwater conveyance network.

Forebay: Lastly, construct the forebay typically using a small excavator. Once the forebay is complete, sod the level spreader channel.

Topsoil: If soils on site are poor and lack organic matter, topsoil can be added at a depth of 6" in the filter strip and on any other slope created by grading to aid in plant establishment. Topsoil can be harvested on-site during construction or brought in from an external source.

Soil testing: Prior to planting, collect a soil sample for a soil test to determine any fertilizer or lime requirements needed for plant establishment. Submit the soil sample to the Auburn University Soil Testing Laboratory or other comparable soil testing lab. The grassed filter strip may be fertilized at planting based on soil test recommendations. It should not be fertilized following initial fertilization, however, as this can result in the export of nitrogen and phosphorus from the filter strip. *(For more information on soil test protocols, see <http://www.aces.edu/pubs/docs/A/ANR-0006-A/index2.tmpl>.)*

Sod installation: Similarly to grassed swales, establish grassed filter strips using sod rather than seed. Sod should be cut fresh and installed as soon as it is delivered, preferably in the early morning before temperatures rise. Install sod horizontally across a slope. Alternate the seams of sod similar to a brick pattern to ensure stability and reduce erosion. *(Refer to the Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas ([swcc.alabama.gov](http://www.swcc.alabama.gov)), for more information on sod installation.)* Sod may be harvested on-site, temporarily stored in the shade, and kept evenly moist until planting.

Irrigation systems: Irrigation systems should be calibrated (see *Alabama Smart Yards Manual, chapter 3* at http://www.aces.edu/pubs/pubstemplate.php?content=http://www.aces.edu/pubs/docs/A/ANR-1359/ASY_chapter3.html

to minimize excess irrigation applications. A common mistake made during plant establishment is applying a small volume of water too frequently.

VEGETATION

Vegetation for the level spreader channel and filter strip should be a dense coverage to be effective. Although not native, turfgrass is utilized because it is fine textured, promotes diffuse flow when maintained at a low mowing height, can be sodded for quick cover, and is easy to maintain.

TABLE 8.4. TURFGRASS LIST*

NAME	PREFERS	DROUGHT TOLERANCE	COMMENTS
Bermudagrass	sun	excellent	Tolerates foot traffic; spreads above and below ground; fast growth rate; use statewide
centipedegrass	sun to part shade	good	Slow growing; sensitive to some herbicides (check label); may be susceptible to cold injury in northern AL
St. Augustinegrass	sun to part shade	good	Spreads above ground; fast growing; can be sensitive to herbicides; most shade tolerant turf; use in central and southern AL
zoysiagrass	Sun to part shade	excellent	Use statewide; most cold tolerant of warm- season turfgrasses; slow growing

*Adapted from Han and Huckabay, 2008a. See References for full attribution.

Specify turfgrass for the portion of the filter strip immediately following the run of aggregate (No. 57, No. 1, or designer preference). Warm-season turfgrasses that actively grow during warmer months and are dormant during the winter are available in Alabama. Generally, turfgrass will not perform well under fully shaded conditions. As with other LID practices such as bioretention and grassed swales, turfgrass selected for grassed filter strips should be tolerant of brief flooding and, most importantly, drought. *(See table 9.4 for a Turfgrass List.)*

Turf establishment: For June to September installation, irrigate newly planted turf at planting and water daily for the first one to two weeks to keep it evenly moist. As the sod begins to grow new roots, irrigation frequency can be decreased, but a larger volume of water should be applied at each watering. Supplement rainfall so that turfgrass receives about 1"–1.5" per week from all irrigation sources. Dormant plantings however, may benefit from irrigation during spring months when sod begins to produce new growth. Sod flourishes best when installed in the spring; this gives the turf an entire growing season to get established before the winter months arrive and the grass goes dormant. Sod establishes better when it is not going into or coming out of dormancy (i.e., not in late fall or late winter).

MAINTENANCE

Sediment removal: Built-up sediment can inhibit sheet flow by forming sandbars and dams throughout the filter strip or grassed channel. Remove sediment, trash, and debris twice a year (minimum) from the level spreader channel, forebay, and vegetated filter strip. Accumulated sediment covers up vegetation, chokes it out, and results in plant die-off.

Plant maintenance: Replace dead plants to maintain a consistent cover. Some areas may need to be resodded after accumulated sediment is removed. Also remove plants growing on the run of aggregate (No. 57, No. 1, or designer preference) and in the forebay, as these can inhibit flow patterns.

Turf maintenance: Grassed filter strips require typical turfgrass maintenance including thatch removal and aeration, (*For more information on these activities, see Appendix D: Vegetation.*) Keep grassed filter strips at an even, low, dense

growth where diffuse flow is desired. Turfgrass requires mowing at least once a month (every other week is better) during the growing season. A general rule of thumb is never to remove more than one third of the leaf during mowing. Turfgrasses such as Bermudagrass respond well to frequent mowing. Do not mow immediately following a rain event or when the ground is saturated; this prevents ruts that can cause areas of compaction or reconcentration of diffuse flow.

POLLUTANT REMOVAL

Level spreaders provide minimal pollutant removal. When paired with a grassed filter strip, however, these systems receive reductions in total suspended solids (TSS) and nutrients such as nitrogen and phosphorus.

Vegetation: The grassed filter strip reduces pollutants through infiltration and filtration processes associated with plants and soil. Dense vegetation cover is expected to increase pollutant removal efficiency, which is why turfgrass is recommended for these practices.

Sedimentation: Grassed filter strips are more effective at reducing runoff velocities and TSS concentrations when stormwater enters from a water-spreading device such as a level spreader or flat surface that encourages sheet flow. When grassed filter strips are used as a stand-alone SCM, they reduce TSS loads

TABLE 8.5. MAINTENANCE SCHEDULE

Task	How Often	Comments
Erosion inspection	During and after major storm events (0.5" or greater) for the first 2 years, annually thereafter	Inspect for eroded areas and determine that flows are properly distributed into the filter strip. Check for gully formation in the channel and grassed filter strip.
Inspection	After 0.5" or greater rainfall event	Visually inspect all components, including the level spreader lip, channel, and grassed filter strip, for any damage.
Sediment and Trash Removal	At least annually, twice a year preferred	Remove deposited sediment, especially at inlet areas, such as the forebay, where it is most likely to collect. Remove sediment annually or after a 2-yr, 24-hour storm event.
Turfgrass mowing	Every other week in growing season	Mow more often during the growing season. Dense, low-growing vegetation is best to maintain diffuse flow. Maintain at a height of 3" to 6".
Thatch removal	As needed	Remove thatch when the thatch layer is 0.75" or thicker and when grass is actively growing. (<i>For more information, see Appendix D: Vegetation.</i>)
Aeration	As needed	Core aeration is needed when turfgrass becomes compacted and infiltration slows. Aerate only following spring green up or when grass is actively growing in summer months.
Plant removal	Annual minimum	Remove all plants growing on the level spreader lip, in the forebay, or in the run of aggregate stone downslope of the lip.

TABLE 8.6 GRASSED FILTER STRIP POLLUTION REMOVAL

Sediment	Nutrients		Metals	Pathogens
	N	P		
a. 40%	30%	35%	No data	No data
b. 50%	20%	20%	40%	No data
c. 50%	20%	20%	40%	Insufficient data

See References for full attribution:

- a. North Carolina Department of Environment and Natural Resources, 2007
- b. City of Auburn, Stormwater Water Management Manual 209.
- c. Georgia Stormwater Management Manual, 2001.

because their primary pollutant removal mechanism is sedimentation. As sediment drops out, other pollutants attached to sediment particles, such as phosphorus and metals, are removed. Pollutant removal relies heavily on slowing the velocity of stormwater in the filter strip to facilitate sedimentation. Sedimentation is noted to increase with increasing filter strip widths. Although an average of 25'–30' is recommended for filter strips, longer strips are likely to have higher pollutant removal efficiencies.

REFERENCES

- Atlanta Regional Commission 2001. *Georgia Stormwater Management Manual*.
- City of Auburn, AL 209. *City of Auburn Stormwater Management Design Manual*.
- Han, David, and Ellen Huckabay. 2007. *Selecting Turfgrasses for Home Lawns*. Alabama Cooperative Extension System, ANR-92.
- Han, David and Ellen Huckabay. 2007. *Bermudagrass lawns*. Alabama Cooperative Extension System ANR-29.
- Hathaway, Jon M., and William F. Hunt. 2012. *Level Spreaders: Overview, Design, and Maintenance*. North Carolina Cooperative Extension AGW-588-09.
- Hathaway, Jon M., and William F. Hunt. 2007. "Field evaluation of Level Spreaders in the Piedmont of North Carolina." *Journal of Irrigation and Drainage Engineering*. Jul/Aug. 538–542.
- Knight, E.M.P., W. F. Hunt, and R.J. Winston. March/April 2007. "Side-by-Side Evaluation of Four Level Spreader-Vegetated Filter Strips and a Swale in Eastern North Carolina." *Journal of Soil and Water Conservation*.
- Lee, K. H., T. M. Isenhardt, and R. C. Schultz. 2003. "Sediment and Nutrient Removal in an Established Multi-Species Riparian Buffer." *Journal of Soil and Water Conservation* 58(1): 1.
- Minnesota Pollution Control Agency. 2000. *Protecting Water Quality in Urban Areas*. Saint Paul, MN.
- North Carolina Department of the Environment and Natural Resources. 2006. "Level Spreaders" (chapter 8 revised 2010). *Stormwater Best Management Practices Manual*. Raleigh, NC.: North Carolina Division of Water Quality.
- Winston, R. J., and W. F. Hunt. 2010. *Level Spreader Update: Performance and Research*. North Carolina Cooperative Extension AGW-588-21W.
- Winston, R. J., W. F. Hunt, W. G. Lord, and A. C. Lucas. 2010. *Level Spreader Update: Design, Construction, and Maintenance*. North Carolina Cooperative Extension AGW-588-20W.
- Yu, S. L., M. A. Kasnick, and M. R. Byrne. 1993. "A Level Spreader/Vegetated Buffer Strip System for Urban Stormwater Management." *Integrated Stormwater Management*, Eds. R. Field, M. L. O'Shea, and K., Chin. Boca Raton, FL: Lewis Publishers.

RAINWATER HARVESTING

Rainwater harvesting is the collection of rainwater for reuse, typically from a rooftop. Other names for it include rooftop runoff management, and stormwater collection system.





Figure 9.1. J.C. Morse rain barrel, Auburn, AL.

Rainwater harvesting can be used as a form of rooftop runoff management to reduce runoff from impervious surfaces. Rooftop systems typically collect stormwater through a connection to a rain gutter system. Rainwater harvesting systems may be above or below ground systems and can be large or small depending on the site, application, and intended use. When designed and used properly, these systems are an excellent way to save water, energy, and money.

Rain barrels: These are systems used for small-scale applications such as residential areas.

Rain barrels are generally 50–60 gallons and can be connected to one another to collect larger volumes of water. Rain barrels work well as a residential stormwater collection system but rarely contribute to sizeable watershed-wide runoff reductions due to their limited volume collection. However, targeted promotion of rain barrel use raises awareness of stormwater runoff issues. Rain barrels can help homeowners to reduce localized stormwater runoff issues and erosion in their yards.

More information about rain barrels can be found on the Alabama Cooperative Extension System page <http://www.aces.edu/urban/RainwaterCollection/Workshops.php>

Cisterns: These are larger storage tanks that are better suited to commercial or agricultural settings where large volumes of water need to be collected.

Cisterns are discussed in this handbook and can be used above- or belowground to collect rainwater and store it for later use. Cisterns may range from less than 100 gallons to more than 10,000 gallons in size. The water is intended for nonpotable water uses. Water collected by these systems may be used for flushing toilets, irrigation, vehicle washing, and laundry. It is recommended that the harvesting system be labeled and identified as nonpotable water to prevent any confusion and to deter anyone from consuming collected water.

Large cisterns typically need to be purchased directly from a supplier. Due to their size and weight, freight charges can be costly.

SITE SELECTION

Aboveground cisterns:

Aboveground cisterns are easier to install and maintain, are comparatively less expensive, but can be regarded as unsightly.

Belowground cisterns:

The primary benefit of a below ground cistern is that it is out of sight and does not take up valuable land. However, belowground cisterns require the addition of a pump, can be harder to maintain after installation, and are generally more difficult to install because they require excavation and significant structural support. Underground cisterns should not be sited adjacent to buildings due to intensive construction and excavation during installation, which can damage foundations.

TABLE 9.1. SITE SELECTION	
Quantity control	Yes
Drainage area	Small
Space required	Small–Medium
<i>Works with:</i>	
Steep slopes	No
Shallow water table	Yes
Poorly drained soils	Yes

Downspouts: Locate cisterns near gutter downspouts to make installation modifications easier.

Evaluating soils: Use the USDA Web Soil Survey to identify soil map units and to make initial interpretations for potential uses and limitations of a site. Since most soil map units have inclusions of other soils that may be quite different, detailed evaluations should be made at the proposed site by a professional soil scientist or soil classifier. On-site evaluations should properly identify a soil or the hydrologic soil group (HSG). Make the final decision for use based on the detailed determination of soil series or HSG. (For a detailed list of HSG properties, see Table A.3 in Appendix A: Stormwater Hydrology.)

In-situ soils: Do not site cisterns where underlying soils are unstable.

Underground utilities: Do not site cisterns over underground utilities or septic systems.

Water use: Locate cisterns in the vicinity where the harvested rainwater will be used; this will alleviate the need to transport water over long distances.

DESIGN

It is important that cisterns are designed to capture the correct volume of stormwater for on-site needs and the available collection area. When harvested rainwater goes unused, cisterns overflow and can no longer reduce runoff or collect stormwater.

TABLE 9.2. GENERAL SIGNIFICANCE	
Construction cost	Medium
Maintenance	Medium
Community acceptance	Medium–High
Habitat	--
Sun/shade	---



Figure 9.2. Rainwater harvesting system at Boykin Community Center, Auburn, AL.

Components

First flush diverter: This is a pretreatment device designed to collect and dispose of the first inch of runoff from a rooftop system. The first inch of runoff has the highest concentration of pollutants from atmospheric deposition and other contaminants collected in the runoff process. Once capacity is met, a valve closes to allow the remaining runoff to move through the routing system and into the cistern. In many cases, the first flush diverter valve is made up of a ball and choked section of pipe. The first flush chamber fills, which causes a ball to float and restrict flow into the first flush chamber. The collected water is slowly released from a check valve at the bottom of the chamber. The rate at which the first flush releases is determined by the size of the check valve opening. The diverter should discharge to a stormwater control measure (SCM) or vegetated area for treatment. First flush diverters are especially beneficial when rainwater collected is used to irrigate edible plants or crops.

Rain heads: These can be attached to the gutter system to filter debris before water enters the cistern. These devices have mesh screening so that water passes easily through them, while blocking leaves and other particulate matter. The mesh screening sits roughly at a 45° angle so that debris can be easily discarded to the ground. Incorporating a rain head can help to reduce cistern maintenance. Rain heads are also useful for the prevention of mosquitoes when 1 mm or smaller screen is used.



Figure 9.3. Rain head and first flush diverter system, Summerdale, AL.

Call 811 to locate utilities before you begin any type of excavation:
www.al1call.com.

Cistern: These are made of hard plastic, galvanized metal, concrete, or fiberglass. White or light colored cisterns are not recommended due to their propensity to foster algae growth; however, these can easily be painted. Base cistern selection on material, size, and whether it will be located above- or belowground. Plastic cisterns are lightweight, aesthetically appealing, and have minimal assembly. Plus, any modifications can be made using standard tools. Metal cisterns are usually constructed of corrugated or galvanized metal, are commonly made from discarded grain bins, and may require an internal waterproof bladder to minimize leaks.

Structural support: Gravel, concrete, or stone foundations are recommended as structural support of cisterns, especially in situations where underlying soils cannot support the weight.

Underground cisterns: These will most likely require anchoring by backfilling sand or gravel around the cistern.

Overflow: As the cistern reaches capacity, it needs a mechanism to release excess water collected. The overflow should accommodate the same flow rate



Figure 9.4. Rainwater is harvested and used to irrigate a rain garden during plant establishment at Cary Woods Elementary School, Auburn, AL.

as the gutter system, which is a 100-year, one-hour storm event. For Alabama this can range between 3.25" to 4.5" of rain depending on location within the state. (See Appendix A: *Stormwater Hydrology for more information.*) It is recommended that the cistern be sized such that overflow is no more than 14% of annual average historical rainfall. Overflow is ideally directed into another SCM. It should always discharge to a vegetated or natural area, however, not to an impervious surface where it will create more runoff. As a general recommendation, overflow pipes for 1,000 ft² of rooftop should be a minimum of 2.5" diameter; rooftops > 3,000 ft² should have overflow pipes with a minimum diameter of 4".



Figure 9.5. Rain head clean of debris.

Outlet: Install a faucet or outlet pipe at the bottom of an aboveground cistern so that water can be easily retrieved. The outlet should be approximately 6" from the bottom of the cistern to allow for sediment collection in the cistern base. Install a bulkhead fitting to prevent leaks, since the faucet will experience high water pressure. The bulkhead fitting should be installed from the inside of the cistern; it is generally cost-effective and safer for the cistern vendor to install it.

Gutters: Larger quantities of water can be collected when multiple downspouts contribute to the cistern. Some gutters may need to be piped to the cistern. If piping is not an option, gutters can be tied together and directed to a single downspout. This can lead to structural failure, however, and unintended overflows during heavy storms.

Pumps: The addition of a pump helps to draw water from the cistern and can increase utilization in cases where constant pressure is needed. If the cistern is housed belowground, it requires a pump to move the water. Recommended pumps for cisterns are usually low-head and high-flow centrifugal pumps. These pumps are generally inexpensive, available in various flow rates and heads, and easy to install. Submerge the pump in the bottom of the cistern to make the priming process easier.



Figure 9.6. The rainwater collection system can be a discrete part of buildings and landscapes. Cary Woods Elementary School, Auburn, AL.

Pump selection: Select a pump based on the flow rate and total head desired.

The flow rate is the rate at which the water moves through the pipe and it is usually expressed in gallons per minute (gpm). Total head is the amount of energy needed to push the water through the pipe. It is measured in pounds per square inch (psi).

Secondary water supply: This may be set up to provide supplemental water to the system during drought conditions, if desired for irrigation.

DESIGN GUIDANCE

The design calculation of a rainwater-harvesting system volume is quite simple. Additional design is required if the system is underground (e.g., buoyancy calculations are needed) and may be necessary for overflow sizing, pump sizing, and irrigation purposes.

The cistern volume required (V_{req}) to capture rooftop runoff can be estimated using EQN 9.1.

$$EQN 9.1 \quad V_{req} = SA_{roof} * R_d$$

SA_{roof} = Surface area of roof or flat plane (ft²)
 R_d = Rainfall depth (in) or 1-yr storm event

Often a factor of safety (FoS) is also added to the equation to ensure critical volumes are captured. A FoS of 1.2 is suggested.

$$EQN 9.2 \quad V = V_{req} * FoS$$

MAINTENANCE

Sediment and debris: The most common maintenance concern is keeping debris and sediment out of the cistern. Roof maintenance is imperative to minimize sediment and debris loads, such as roof shingle particles, from entering the cistern. It is important to maintain gutters to minimize debris entering or clogging the inlet of the cistern. Sediment builds up in the bottom 6" of the cistern and may need to be cleaned out after a few years. A valve can be installed at the cistern base to regularly drain away built-up sediment.

Rain head: Use of a rain head aids in reducing sediment and debris in the cistern. Clean the rain head periodically so that flow into the first flush diverter and cistern is not inhibited. Also clean mosquito screens of blocked debris, especially during warm weather conditions when mosquito breeding is likely to occur.

First flush diverter: This may clog and cause water to remain in it for long periods of time. As this occurs, it may be necessary to remove the bottom portion of the **diverter and discard any built-up debris.**

Pump: Check pump function regularly and perform any maintenance based on the manufacturer's recommendations.

Safety: Never enter the cistern for any type of maintenance due to risks associated with drowning and toxic gas exposure.

TABLE 9.3 MAINTENANCE SCHEDULE		
TASK	HOW OFTEN	COMMENTS
Clean out first flush diverter	Routinely	Should be performed regularly, preferably after each rainfall event.
Clean rain head	Routinely	Should occur frequently to prevent clogging.
Inspect gutter connections	Quarterly or after heavy rainfall events	Check for any damage and remove any trash or vegetation debris.
Unclog Gutters	Routinely	When gutters become clogged, water may back up and inhibit flow into the cistern. Gutter screens can be installed to prevent future clogging.
Check system for clogging	When unnecessary overflows occur	The system may be clogged when the cistern overflows following a rain event less than or equal to the design rainfall.
Inspect	After 0.5" or greater rainfall event	Visually inspect all components of the rainwater harvesting system for damage or clogging. This is especially important for any pipes or gutters used in the system.
Remove sediment from cistern	Every 3 years or as needed	Remove sediment from the bottom 6" of the cistern.

POLLUTANT REMOVAL

Rainwater harvesting can reduce flooding and stream erosion problems due to the reduction in stormwater volume entering stormwater conveyance networks. The cistern captures rooftop runoff that contains nutrients from rain and atmospheric deposition, which aids in reducing nonpoint source pollution.

REFERENCES

- Hunt, W. F., and L. L. Szpir. 2012. *Permeable Pavements, Green Roofs, and Cisterns*. North Carolina Cooperative Extension AG-588-012.
- Jones, M. P., and W. F. Hunt. 2012. *Choosing a Pump for Rainwater Harvesting*. North Carolina Cooperative Extension AG-588-07.
- Jones, M. P., and W. F. Hunt. 2007. *Rainwater Harvesting: Guidance for Homeowners*. North Carolina Cooperative Extension AGW-588-9.
- North Carolina Department of the Environment and Natural Resources. 2006. *Stormwater Best Management Practices Manual*. Ch 19: "Rooftop Runoff Management" Raleigh, NC: North Carolina Division of Water Quality.
- North Carolina Division of Water Quality. 2007. *Technical Guidance: Stormwater Treatment Credit for Rainwater Harvesting Systems*. Raleigh, NC: North Carolina Division of Water Quality.
- Texas Water Development Board. 2012. *The Texas Manual on Rainwater Harvesting*. 3rd Ed. Austin, TX: Texas Water Development Board.

GREEN ROOFS

Green roofs are landscaped roofs that use a specialized growing substrate, storage, drainage mat, and vegetation that is tolerant of extreme climates experienced on rooftops. Other names for it include vegetated roof cover, vegetated roof tops, roof gardens, landscaped roofs, eco-roofs, and living roofs.



Green roofs mitigate stormwater runoff, reduce the heat island effect of impervious surfaces from rooftops, extend roof membrane life, conserve energy, reduce noise and air pollution, provide wildlife habitat in urbanized settings, and improve fire resistance of buildings. These systems have been used in Europe for decades and are becoming more prevalent in the U.S. as stormwater retention practices that provide aesthetic value. As a stormwater control measure (SCM), green roofs are more effective at reducing runoff volumes resulting from small storms rather than providing pollutant load reductions from impervious surface runoff.

TABLE 10.1. SITE SELECTION	
Quantity control	Possible
Drainage area	Small
Space required	Medium-Large
<i>Works with:</i>	
Steep slopes	No
Shallow water table	No
Poorly drained soils	No

TABLE 10.2. GENERAL SIGNIFICANCE	
Construction cost	High
Maintenance	Medium
Community acceptance	High
Habitat	Low
Sun/shade	Sun to Part Shade

Long-term investment: Green roofs are considered a long-term investment because they are one of the most expensive structural low impact development (LID) practices per square foot to construct. Depending on the depth of substrate and volume of runoff retained, vegetated roofs can be quite heavy. Construction alone is considered an expensive capital cost when building-structure reinforcement is needed. Although green roofs are an expensive practice, the layer of vegetation and substrate protect the roof membrane from ultraviolet (UV) radiation and harsh temperatures, and they can extend the lifespan of roofing membranes. In the absence of green roofs, roofing membranes experience sharp temperature fluctuations that cause them to expand and contract, resulting in damage and eventual replacement. Data from Europe have shown green roofs to double the life span of roofing membranes.

SITE SELECTION

Footprint: Green roofs are used on industrial, commercial, and residential rooftops. The installation of a green roof is well suited to ultra-urban areas because it offers stormwater benefits and ecosystem services but does not require additional land usage.

TABLE 10.3. SITE SELECTION: CONSTRAINTS AND LIMITATIONS FOR GREEN ROOFS	
Constraint	Recommendations
Water Quality	If pollutant load reductions are the primary objective, use another SCM
Slope	A roof slope of 8% or less is recommended and flatter slopes work best
Limited Volume Control	Green roofs may have reduced capacity for large quantity retention; no curve number (CN) is assigned and Discrete Curve Number Method cannot be used
Roof Pitch	Pitches greater than 1:12 do not function for water quantity treatment
Building Code	State and local building codes may prevent retrofit or use of green roof

Slope: The ability of a green roof to retain rainwater decreases with increasing roof slope; flat roofs are typically used. A roof slope of 8% or less is recommended when green roofs are planned for water-quantity or potential water-quality benefits. Green roofs at < 2% slope are not recommended because of poor drainage resulting in standing water that can damage vegetation and increase the need for structural support.

Retrofits: Not all retrofit applications require structure reinforcement. It is critical to consult with a structural engineer to determine this early in the planning process. Most flat-roofed buildings can bear the load of an extensive green roof retrofit. Consider building height, location, sun exposure, and wind exposure when planning a green roof installation or retrofit. Surrounding buildings may shade the green roof surface, potentially impacting vegetation selection and evapotranspiration rates. A shaded green roof retains water for longer periods of time and could result in stress to the building structure because of heavy, water-soaked substrate.

Common Green Roof Variations

Intensive green roofs: Intensive green roofs are similar to landscapes found at ground level. Intensive green roofs have a substrate depth usually > 8" and can support a diverse plant community with deeper root systems. Although intensive green roofs are generally more attractive due to their garden-like appearance, they are also more expensive and require the building to support the increased weight of the substrate depth. Maintenance tends to be more expensive for this type of green roof due to overall aesthetics and maintenance required by the diverse plant community. Intensive green roofs can be designed to accommodate foot traffic and used as an outdoor space with garden paths throughout. Visitor access not only makes aesthetics an important amenity, but it also means that safety concerns




Figure 10.1. Green roof cross section. Illustration courtesy of Russell Harrington, Auburn University, Master of Landscape Architecture.

should be addressed early in the design process. Extreme temperatures of green roofs can be a hazard for humans using it as a recreational space.

Extensive green roofs: An extensive green roof installation is more common because it is ideal for retrofits and less expensive. An extensive green roof system requires less structural support because its substrate depth is usually < 8". The typical substrate depth ranges from 3"–5" thick with 4" of substrate recommended in the Southeast. Extensive green roofs offer all the environmental benefits associated with intensive green roofs but are designed to be low maintenance and do not usually allow public access. These systems can provide undisturbed habitat for insects, birds, and microorganisms because access is limited.

DESIGN

This handbook focuses on the design and construction of extensive green roofs due to growing popularity and decreased costs.

Components

Substrate: A green roof substrate should be relatively lightweight, retain nutrients for plant growth, and be persistent. Do not use topsoil because it is too heavy and remains too wet. Consider instead a lightweight mineral compound such as shale, slate, clay, or terra cotta. The substrate should hold approximately 40%–60% water by weight and have a bulk density (dry) range of 35–50 lb/ft³. Though vegetation roots and shoots intercept rainfall, the substrate should manage the release rate of stormwater. A target water holding capacity of 40%–60% is ideal for plant survival and to release and drain enough water to maintain the appropriate weight on the building structure. Capture volumes ranging from 0.5" to 1.2" have been reported on green roofs.

Substrate depth: Substrate depth is largely based on local climate and precipitation patterns. Although research out of Michigan shows substrate depths of at least 2.75" can successfully support succulents and provide adequate coverage, 4" of substrate is recommended in Alabama to support succulents and perennials. Note: when irrigation is installed, decreased substrate depths have been successful.

Substrate organic matter: Organic matter in the substrate should be 15% or less. High organic matter components are not recommended because of increased decomposition resulting in substrate shrinkage. Substrate replacement is

expensive and not practical; therefore, the substrate components should have minimal decomposition rates.

Fertilizer: Some fertilization is needed for plant establishment. Too much, however, can result in nutrient leaching and increased levels of nutrients in stormwater runoff. Controlled release fertilizers (CRF) have shown to be effective for plant establishment at rates as low as 3.5 oz per 20ft² (13N–6P–11K).

Compost: Other research has utilized low rates of compost (up to 20%) in the substrate mix to provide nutrients and organic matter. High rates of compost in green roof substrate may leach nitrogen and phosphorus, which can be problematic in nutrient-sensitive watersheds. Future research at the University of Alabama at Birmingham is planned to analyze water-quality impacts associated with the use of both compost and fertilizer.

Filter fabric: A layer of geotextile filter fabric is placed between the substrate and drainage mat. The filter fabric protects the drainage mat by preventing the substrate from clogging it and deterring root growth into the mat and roof surface.

Drainage mat: The drainage mat, layer, or net prevents water from ponding by conveying it off the roof to protect and preserve the roof surface. Rapid drainage of the substrate reduces the weight of the green roof. The drainage mat selected should adequately drain the roof from the design storm. Drainage mats should drain at a rate of 15 gal/min/ft or higher.

Membrane/waterproof liner: The impermeable roof membrane is made of tar or another waterproofing liner that creates watertight conditions between the drainage mat and the building structure. This layer is similar to conventional roofing liners. If the membrane contains organic matter, there is danger of roots penetrating it and eventually growing into the underlying structure.

Design Guidance

The green roof design presented in this handbook is limited for Green Roofs because of structural standards that limit their application. Consult a licensed structural engineer to verify the use of a green roof. Structural upgrades can be cost-prohibitive to a project.

Roof weight: Consider green roof weight during the design process. Scrutinize the weight of saturated media, live or dead loads, and any snow accumulation to

ensure that structural support requirements are met. Dead loads for green roofs consist of the substrate, drainage mat, and water in the pore spaces. These loads must meet state and local building codes. The State of Alabama conforms to the International Building Code (IBC). Under IBC Table 1606.1, roofs used for gardens or assembly purposes must be designed for a 100 pounds per square foot (psf) uniform live load. The substrate used must have the capacity for rainfall retention and must balance runoff retention with loading (weight).

Calculate runoff volume

The discrete curve number Method cannot be used because a curve number has not been specified for green roofs.

The simple method can be used, however, to calculate the volume of water necessary for water quantity and volume reduction. The simple method uses two equations (EQNs 10.2 and 10.3) to calculate the runoff coefficient. The design must support both the runoff volume and the peak flow rate.

Typically, when calculating the runoff coefficient (R_v), impervious fraction (I_a) is determined as the impervious area divided by total area. In this case, however, the impervious fraction (I_a) is 50% of the impervious fraction for a standard roof; this is a standard assumption for green roof design.

Once the runoff coefficient (R_v) is calculated, it can be used in EQN 10.3 to determine the total runoff volume (V).

The hydrologic properties specific to the substrate or growing medium are used to determine the capacity for rainfall retention. Porosity, moisture content at field capacity, moisture content at wilting point, and saturated hydraulic conductivity (K_{sat}) are all needed to determine water retention and the rational runoff coefficient.

R_d is the design rainfall depth (in), R_v is the rational runoff coefficient (in/in), and A is area in acres.

EQN 10.1 $Q_p = CiA$

C = Runoff coefficient
 i = Rainfall intensity (in/hr)
 A = Watershed area (ac)
 Q = Peak flow (ft³/s)

EQN 10.2 $R_v = 0.05 + 0.9 * I_a$

R_v = Runoff coefficient
 I_a = Impervious fraction

EQN 10.3 $V = 3630 * R_d * R_v * A$

V = Peak runoff volume (ft³)
 R_d = Design rainfall depth (in)
 R_v = Runoff coefficient
 A = Rooftop area (ft²)

Forty percent by weight or greater retention is needed to intercept and retain the water-quality storm event. This characteristic is imperative for peak attenuation. A runoff hydrograph and numerical modeling can be approximated using these properties. For storms larger than the design storm, runoff will occur; downspouts should be designed accordingly.

CONSTRUCTION

Check membrane: Prior to installation, check the waterproofing membrane to ensure that it is leak-free. Although this may be a time-consuming task, it should be done as a preventative maintenance measure. If leaks to the membrane are found following installation, complete vegetation and substrate removal may be required to mitigate leaks.

Preventing root penetration: Membranes or waterproof liners specific to green roof applications should contain a root deterrent chemical or metal foil at membrane seams. Although not required, a copper-based root retardant can also be included in the filter fabric to prevent root growth beyond the substrate layer.

Irrigation: Install irrigation for plant establishment and periods of extreme drought. Hand watering or overhead irrigation has been used effectively during plant establishment, but irrigation for seasonal drought conditions should use microirrigation emitters. Soil moisture probes or sensors can be an inexpensive investment for the irrigation system to ensure that irrigation only occurs during extreme drought conditions.

Roof access: Frequent roof access is necessary for inspection and maintenance operations following installation. Substrate loading and unloading or plant replacement to and from the rooftop surface may be labor intensive. Exterior or interior elevators are helpful to carry materials to the roof. A blower truck or shingle lift can be used for one- three-story buildings.

Safety: Safety can be a concern both during construction and after installation due to the possibility of a fall. Safety issues may include high temperatures, being trapped on the roof, and decreased roof structure integrity causing injury.

VEGETATION

Plant characteristics: Vegetation suggested for extensive green roofs are native perennials, grasses, or succulents. Plants for these systems are typically low growing, quickly established, and cold, heat, and drought tolerant.



Figure 10.2. Examples of green roof vegetation at the University of Alabama at Birmingham, Birmingham, AL.

Vegetation selection can be difficult due to decreased rooting depth available to plants. Green roof plants that are readily established, spreading, and propagate easily have shown to be successful. Annual and perennial plants can be used, although perennial plants are preferred as the sustainable choice. Other preferred characteristics include persistent plants that live-long, self-propagate, or reseed themselves.

Stress tolerance: Selecting plants for green roofs can be difficult due to the extreme weather conditions experienced on a rooftop. Required stress tolerances result in vegetation that is low growing, compact, mat forming, tough foliated, and any other characteristics that allow plants to efficiently avoid drought. Most green roof vegetation needs to tolerate mildly acidic and poor soil conditions present in the growing substrate.

Irrigation: Irrigation of extensive green roofs is not required, but irrigation has proved effective in aiding plant establishment as well as plant survival during periods of long-term drought. The initial cost of irrigation system installation is usually less than replacing vegetation.

Plant placement: Vegetation near gutters and downspouts may remain wet for longer periods of time. These areas should include plants that are tolerant of extended wet conditions. Consult a horticulturist or landscape architect for specific vegetation recommendations.

Additional Vegetation Design Guidelines

- Plant areas of the green roof that will remain wet or dry for longer periods of time with the appropriate species for these conditions.
- Contact the nursery or plant supplier prior to green roof design to determine species and quantities that are available.
- Although native species are preferred for LID practices, a mixture of nonnative succulents and native perennials may be necessary to ensure adequate coverage.
- Follow plant label instructions for spacing recommendations.

TABLE 10.4. GREEN ROOF PLANT LIST*

(This is a suggested plant list for green roofs in Alabama.)

Botanical Name	Common Name	Native	Habit	Seasonal Irrigation
<i>Antennaria plantaginifolia</i>	pussytoes	yes	perennial	yes
<i>Coreopsis auriculata</i>	mouse-ear tickseed	yes	perennial	yes
<i>Elymus hystrix</i>	eastern bottlebrush grass	yes	grass	yes
<i>Phemeranthus calcaricus</i>	limestone fameflower	yes	perennial	yes or no
<i>Phlox bifida</i>	starry glade phlox	yes	perennial	yes
<i>Sedum album</i> 'jelly bean'	jelly bean' white stonecrop	no	succulent	yes or no
<i>Sedum album</i> 'France'	France' white stonecrop	no	succulent	yes or no
<i>Sedum kamtschaticum</i>	orange stonecrop	no	succulent	yes
<i>Sedum rupestre</i> 'Angelina'	Angelina' stonecrop	no	succulent	yes or no
<i>Sedum spurium</i> 'Fuldaglut'	Fuldaglut' two-row stonecrop	no	succulent	yes or no
<i>Viola egglestonii</i>	Eggleston's violet	yes	perennial	yes

*Adapted from Price et al., 209.

- Succulents appear to be more suited to extensive green roof environment, but native perennials and grasses can be used in conjunction to provide aesthetic appeal.

MAINTENANCE

Access: Maintenance can prove difficult simply due to the location of the practice. Access to the roof is imperative. Walkways or paths for maintenance purposes are recommended for ease of plant inspection, weeding, or irrigation system maintenance.

Vegetation maintenance: Plant maintenance is expected since the majority of the green roof will be covered by vegetation. Remove and replace dead plants during early spring. Allow dead vegetation to remain over winter months as cover for the roof before being replaced in the spring. Most vegetation for green roofs will undergo winter dormancy but should experience bud break when temperatures warm. Maintenance professionals and horticulturists can assist in determining whether plant replacement is necessary.

Troubleshooting roof ponding: Because the green roof is designed to retain stormwater, leaks are possible and may be challenging to repair. If ponding occurs on the substrate surface, the source of ponding should be quickly determined. Substrate or surface ponding can damage vegetation through extended saturation that may promote fungal growth and plant dieback. In addition, sediment tends to collect in the outlet, causing it to clog, and should be periodically cleaned out to avoid roof flooding. Ponding may also occur due to clogging of the gutters or drainage layer. Complete substrate removal and replacement should be a last resort and only occur when all other ponding causes have been refuted.

POLLUTANT REMOVAL

Practice pairing: Green roofs are not currently considered a stand-alone water-quality practice primarily because there are no documented reductions in nutrients and other pollutants. Routing green roof discharges into other structural SCMs such as bioretention, however, has the potential to provide both water quantity and quality treatment.

Retention: Green roofs can be utilized to effectively decrease runoff and peak flows through the retention of stormwater. Rooftop runoff can be even further reduced through evapotranspiration, especially during small storms when the

majority of rain absorbed is released back into the atmosphere. Discharge or runoff from the green roof should occur only when the growing medium or substrate has reached field capacity.

Nutrient leaching: Higher percentages of compost in the substrate can lead to nutrient leaching. Even with low rates of 15% compost, both nitrogen and phosphorus can leach and be significantly higher compared to rainfall from a conventional rooftop. It is possible that determining the ideal recipe or formula for the growing media may eventually result in water-quality benefits or, at the very least, a leveling off of nutrient leaching.

Energy use reduction: A reduction in energy consumption is provided because green roofs insulate the building through the use of vegetation and substrate that dissipates solar radiation to buffer temperature extremes. Green roofs cool through an increase of reflectivity, or albedo. Heat reduction can be high as 70%–90% during the summer. Energy savings may be even greater for retrofitted green roofs on buildings that have poor insulation.

Noise reduction: Green roofs also reduce external noise; five inches of green roof media can reduce noise from building surroundings by 40 decibels.





Figure 10.3. Urban green roof concept.

REFERENCES

- Castleton, H. F., V. Stovin, S. B. M. Beck, and J. B. Davidson. 2010. "Green Roofs: Building Energy Savings and Potential for Retrofit." *Energy and Buildings* 42:1582–1591.
- Getter, K. L., D. B. Rowe, J. A. Anderson. 2006. "Quantifying the Effect of Slope on Extensive Green Roof Stormwater Retention." *Ecological Engineering* 31:225–231.
- Getter, K. L., and D. B. Rowe. 20012. "The Role of Extensive Green Roofs in Sustainable Development." *HortScience* 41(5):1276–12812.
- Getter, K. L., and D. B. Rowe. 2009. "Substrate Depth Influences Sedum Plant Community on a Green Roof." *HortScience* 44(2):401–406.
- Getter, K. L., D. B. Rowe, and B. M. Cregg. 2009. "Solar Radiation Intensity Influences Extensive Green Roof Plant Communities." *Urban Forestry and Urban Greening* 8:269–281.
- Gregoire, B. C., and J. C. Clausen. 209. "Effect of a Modular Green Roof on Stormwater Runoff and Water Quality." *Ecological Engineering* 37:963–969.
- Hunt, W. F., and L. L. Szpir. 20012. *Permeable Pavements, Green Roofs, and Cisterns*. North Carolina Cooperative Extension AG-588–23W.
- Köhler, M. 2003. *Plant survival research and biodiversity: Lessons from Europe*. Paper presented at the First Annual Greening Rooftops for Sustainable Communities Conference, Awards and Trade Show; 20–30 May 2003, Chicago.
- Lui, K., and J. Minor. 20012. *Performance evaluation of an extensive green roof*. Washington, DC: Green Rooftops for Sustainable Communities.
- Monterusso, M. A., D. B. Rowe, and C. L. Rugh. 20012. "Establishment and Persistence of Sedum spp. and Native Taxa for Green Roof Applications." *HortScience* 40(2):391–3912.
- Moran, A., B. Hunt, and J. Smith. 20012. *Hydrologic and Water Quality Performance from Green Roofs in Goldsboro and Raleigh, North Carolina*.
- North Carolina Department of the Environment and Natural Resources. 2006. "Rooftop Runoff Management." *Stormwater Best Management Practices Manual*. ch 19: Raleigh, NC: North Carolina Division of Water Quality.
- Oberndorfer, E., J. Lundholm, B. Bass, R. Coffman, H. Doshi, N. Dunnett, S. Gaffin, M. Köhler, K.K.Y. Lui, and B. Rowe. 2006. "Green Roofs as Urban Ecosystem: Ecological Structures, Functions, and Services." *Bioscience*. 57(10): 823–833.
- Price, J. G., S. A. Watts, A. N. Wright, R. W. Peters, and J. T. Kirby. 209. "Irrigation Lowers Substrate Temperature and Enhances Survival of Plants on Green Roofs in the Southeastern United States." *HortTechnology*. 21(5): 586–592.
- Price, J. G. 209. Personal communication via email on November 16, 209.
- Rowe, D. B., M. A. Monterusso, and C. L. Rugh. 20012. "Assessment of Heat Expanded Slate and Fertility Requirements in Green Roof Substrates." *HortTechnology*. 16(3) 471–476.
- Snodgrass, E. C., and L. L. Snodgrass. 20012. *Green Roof Plants A Resource and Planting Guide*. Portland, OR: Timber Press.
- United States Environmental Protection Agency. 2007. *Stormwater Menu of BMPs: Green Roofs. National Pollutant Discharge Elimination System*. Washington, D.C.
- VanWoert, N. D., D. B. Rowe, J. A. Anderson, C. L. Rugh, and L. Xiao. 20012. "Watering Regime and Green Roof Substrate Design Affect Sedum Plant Growth." *HortScience* 40(3):659–664.

RIPARIAN BUFFERS

Riparian buffers are permanently vegetated transition zones that connect upland areas to streams. Other names for it include filter strips, streamside vegetation, streamside forest, aquatic buffers, corridors, greenways, riparian zones, engineered buffers, buffer strip, water pollution hazard setbacks, vegetated buffers, and biological buffer zones.



Prior to development, most streams in the Southeast had naturally occurring riparian buffers. These streamside forests slow runoff velocity, create diffuse flow, and reduce nonpoint source (NPS) pollution concentrations before runoff enters nearby streams or other water bodies. Buffers filter pollutants from agricultural, urban, suburban, and other land cover through natural processes such as deposition, infiltration, adsorption, filtration, biodegradation, and plant uptake. Riparian buffers also stabilize stream banks and provide food and shelter to wildlife, connecting otherwise fragmented wildlife communities in a watershed. Riparian buffers are often recommended as part of a holistic watershed management plan aimed at reducing NPS pollution.

SITE SELECTION

Riparian buffers are sited adjacent to surface waters such as perennial, intermittent, and ephemeral streams. To be considered an LID practice, a riparian buffer should be restored and enhanced. Restored riparian buffers work well in high-density urban areas, such as residential subdivisions, and can be used in conjunction with other stormwater control measures (SCMs) that help reduce flashy urban flows.

Permanent easements: A long-term or permanent easement is recommended to protect the restored buffer from development, clearing, or unnecessary extensive plant maintenance that might limit buffer functionality.

Right-of-way: The restored riparian buffer should not be in a current right-of-way (ROW) for sewer, power, or other infrastructure.

TABLE 11.1. SITE SELECTION	
Quantity control	No
Drainage area	Small–Medium
Space required	Medium–Large
<i>Works with:</i>	
Steep slopes	No
Shallow water table	Yes
Poorly drained soils	Yes

TABLE 11.2. GENERAL SIGNIFICANCE	
Construction cost	Medium
Maintenance	Low
Community acceptance	High
Habitat	Medium-High
Sun/shade	Sun to Part Shade

TABLE 11.3 SITE SELECTION: CONSTRAINTS AND LIMITATIONS FOR RIPARIAN BUFFERS

Constraint	Recommendations
Width	Effectiveness is minimized in buffers < 25' wide.
Slope	Preferred < 6%; may need to be wider if > 6%.
Flow	Flow should not be concentrated. Use a level spreader to disperse concentrated flow entering the buffer; flow entering the buffer should also not exceed 3 cubic feet per second (cfs).
Sediment	Does not work with high sediment inputs.
Right-of-way/ established buffer	Only replaces impaired buffers; must have an access easement.

Buffer width: Buffer width may be a function of surrounding land use, land availability, or topography and may vary throughout the watershed. Check local ordinances on buffer width, as these regulations can vary across the state from 25 to 150 feet. Narrower buffers can be just as effective as wider buffers in removing sediment in environments where rainfall events are consistently light. Buffers in regions that experience heavy or frequent rain events in urbanized settings may require wider buffers to adequately reduce sediment and other pollutants.

Slope: Slope can greatly affect buffer width. A slope of less than six percent is recommended to slow runoff through riparian buffers. Steeper slopes may require larger buffer widths due to increased runoff velocities that decrease residence time in the buffer and reduce infiltration or filtration. It is generally noted that increased buffer width can help to reduce sediment loads.

Flow: Flows into the buffer should not exceed three cubic feet per second.

DESIGN

The design of restored riparian buffers includes site selection, determining the dimension of the buffer, and proper vegetation selection and placement. Improvements to riparian buffers may include replanting native vegetation to reduce erosion and eradicating invasive plants.

Components

Pretreatment: A grassed filter strip for pretreatment is encouraged but not required for restored riparian buffer functionality. Grassed filter strips can aid in nutrient and sediment load reductions by reducing runoff velocities and dissipating energy. Grassed filter strips are planted with turfgrass for ease of maintenance and to create diffuse flow into the buffer to allow sediment to settle out of suspension.

Practice pairing: Restored riparian buffers often are paired with other structural SCMs, such as level spreaders, to aid in creating diffuse flow into the riparian buffer.

Dimension: A restored riparian buffer typically has two zones with an optional third zone. A minimum 100-foot buffer width is recommended for stream protection; however, some areas of Alabama recommend smaller widths.

Zone 1: This is closest to the water body and is designed to create, preserve, and protect physical and ecological functions. This floodplain zone is crucial to the physical and ecological integrity of the stream ecosystem. It often has wetland characteristics and critical habitats. Zone 1 should have restricted human use and be planted with native vegetation that protects stream-bank stability. This zone may range from 25 to 30 feet wide perpendicular to the stream or water body. It is primarily made up of a mix of wetland herbaceous and woody vegetation.

Zone 2: This is the transition area between the upland and Zone 1. Zone 2 is the primary treatment area for pollutant removal. This zone is designed to infiltrate runoff and promote filtration of pollutants. The width of this zone ranges from 20 to 50 feet perpendicular to the stream additional to Zone 1, depending on stream and floodplain characteristics. Woody vegetation is the primary vegetation in this zone. Intrusions into this zone should be minimized.

A two-inch layer of organic mulch, such as a hardwood mulch or pine straw, may be used to aid in plant establishment.

Zone 3: An optional transition to a 25-foot-wide filter strip of grassed or herbaceous plant species is recommended to create diffuse flow into Zone 2. Zone 3 is typically planted with native grasses.

CONSTRUCTION

Construction of a restored riparian buffer should consider stream channel stabilization, vegetation, soil preparation, floodplain or buffer stabilization, and planting.

Permits: Proper permits must be obtained if stream channel stabilization is needed.

Stream channel stabilization: This combines vegetative and structural techniques. Two recommended vegetation techniques to stabilize stream banks are the use of live stakes and brush mattresses. Structural measures or in-stream features, such as rock vanes, log vanes, or sills, may be necessary to improve stream-bank stability. Hard-armoring stream banks using riprap or gabion baskets are not as desirable compared to more natural biological engineering techniques, but it can be used in situations where applicable. Consult a biological or agricultural engineer when stream-channel stabilization is necessary.

Invasive plant removal: The amount of site preparation is dependent on the amount of existing native vegetation and the need for invasive plant removal. Conduct a vegetation assessment inventory prior to construction to identify both native and invasive plants on-site. Vegetation treatment and soil preparation may require the use of herbicides or mechanical elimination of invasive plants. (See *Appendix D: Vegetation for more information on invasive plant removal.*)




Figure 11.1. Riparian Buffer diagram.

TABLE 11.4. RECOMMENDED LIVE STAKE SPECIES	
Botanical Name	Common Name
<i>Cephalanthus occidentalis</i>	buttonbush
<i>Cornus amomum</i>	silky dogwood
<i>Itea virginica</i>	sweetspire
<i>Salix sericea</i>	silky willow
<i>Sambucus canadensis</i>	elderberry
<i>Physocarpus opulifolius</i>	ninebark

Live stakes are woody stakes (0.5" diameter) harvested and installed during the winter months. Live stakes should produce roots and shoots following one growing season. Live stakes are recommended for stream-bank stabilization and are planted at the toe of the slope where they intercept stream-base flow.

For more information on installing live stakes, visit www.aces.edu/extcomm/timelyinfo/Ag%20Soil/2012/March/2012Live_Stakes.pdf




Figure 11.2. Schematic section illustration.



Figure 11.3. Ida Belle Young, Montgomery, AL.

TABLE 11.5. ZONE 1 PLANTS		
Botanical Name	Common Name	Type
<i>Acer saccharinum</i>	silver maple	tree
<i>Alnus serrulata</i>	hazel alder	shrub
<i>Asimina triloba</i>	pawpaw	shrub
<i>Aronia arbutifolia</i>	red chokeberry	shrub
<i>Arundinaria gigantea</i>	river cane	grasslike
<i>Asclepias incarnata</i>	swamp milkweed	herb
<i>Betula nigra</i>	river birch	tree
<i>Carex sp.</i>	sedge	herb
<i>Cephalanthus occidentalis</i>	buttonbush	shrub
<i>Chamaecrista fasciculata</i>	patridge pea	herb
<i>Chasmanthium latifolium</i>	inland sea oats	grass
<i>Clethra alnifolia*</i>	summersweet	shrub
<i>Fagus grandifolia</i>	beech	tree
<i>Euonymus americanus</i>	hearts-a-bustin	shrub
<i>Fraxinus pennsylvanica</i>	green ash	tree
<i>Helianthus angustifolius*</i>	swamp sunflower	herb
<i>Hibiscus moscheutos</i>	rosemallow	herb
<i>Ilex glabra</i>	inkberry	shrub
<i>Ilex verticillata</i>	winterberry	tree
<i>Illicium floridanum</i>	Florida anise	shrub
<i>Itea virginica*</i>	sweetspire	shrub
<i>Juncus sp.</i>	rush	herb
<i>Lindera benzoin</i>	spicebush	shrub
<i>Liquidambar styraciflua</i>	sweetgum	tree
<i>Liriodendron tulipifera</i>	tulip poplar	tree
<i>Lobelia cardinalis</i>	cardinal flower	herb
<i>Nyssa aquatica</i>	swamp tupelo	tree
<i>Panicum virgatum*</i>	switchgrass	grass
<i>Platanus occidentalis</i>	sycamore	tree
<i>Prunus serotina</i>	black cherry	shrub
<i>Quercus bicolor</i>	swamp white oak	tree
<i>Quercus lyrata</i>	overcup oak	tree
<i>Quercus shumardii</i>	Shumard oak	tree
<i>Quercus michauxii</i>	swamp chestnut oak	tree
<i>Taxodium distichum</i>	bald cypress	tree
<i>Viburnum dentatum</i>	arrowwood	shrub
<i>Viburnum nudum*</i>	possumhaw	shrub
<i>Viburnum obovatum</i>	Walter's viburnum	shrub

*Can be used in Zone 1 or Zone 2.
Zone 1 plants experience floodplain conditions. The zone is planted with trees, shrubs, and perennials that tolerate periodic inundation.

TABLE 11.6. ZONE 2 PLANTS

BOTANICAL NAME	COMMON NAME	TYPE
<i>Aesculus pavia</i>	red buckeye	shrub
<i>Asclepias tuberosa</i>	butterfly weed	herb
<i>Asimina parviflora</i>	dwarf pawpaw	shrub
<i>Callicarpa americana</i>	beautyberry	shrub
<i>Calycanthus floridus</i>	sweetshrub	shrub
<i>Cercis canadensis</i>	redbud	shrub
<i>Coreopsis lanceolata</i>	tickseed	herb
<i>Hamamelis vernalis</i>	witchhazel	shrub
<i>Hamamelis virginiana</i>	witchhazel	shrub
<i>Lindera benzoin</i>	spicebush	shrub
<i>Magnolia virginiana</i>	sweetbay	tree
<i>Schizachyrium scoparium*</i>	little bluestem	native grass
<i>Sorghastrum nutans*</i>	Indiangrass	native grass
<i>Panicum virgatum*</i>	switchgrass	native grass

* CAN BE USED IN OPTIONAL ZONE 3.

ZONE 2 IS GENERALLY CONSIDERED AN UPLAND AREA THAT RARELY IS FLOODED. PLANTS BEST SUITED FOR THIS ZONE ARE SHRUBS AND PERENNIALS.

TABLE 11.7. COMMON INVASIVE PLANTS FOR RIPARIAN BUFFERS IN ALABAMA

Botanical Name	Common Name	Type
<i>Ailanthus altissima</i>	tree of heaven	tree
<i>Albizia julibrissin</i>	mimosa	tree
<i>Hedera helix</i>	English ivy	vine
<i>Imperata cylindrica</i>	cogongrass	grass
<i>Ligustrum sinense</i>	Chinese privet	shrub/small tree
<i>Lonicera japonica</i>	Japanese honeysuckle	vine
<i>Lygodium japonicum</i>	Japanese climbing fern	vine
<i>Pueraria montana</i> var. <i>lobata</i>	kudzu	vine
<i>Rosa multiflora</i>	multiflora rose	shrub
<i>Triadica sebifera</i>	Chinese tallow	tree

Invasive plant removal: Look for and remove invasive plants from the riparian buffer, especially during plant establishment. As buffers colonize with native shrubs, trees, and herbaceous plants, invasive plant removal frequency may decrease; however, annual to semiannual surveys for invasive plants are critical for management of these undesirable plants. (See Appendix D: Vegetation for more information on invasive plant management.)

Plant establishment: Chisel or rip any compacted soil before adding topsoil necessary for plant establishment and plant growth. Add soil amendments such as lime and fertilizer based on soil test results.

Erosion and sediment control: Areas of bare soil must be stabilized immediately using native grasses, permanent seeding, and erosion control blankets (if necessary) following any soil disturbance. This is according to the *Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas* (<http://conservealabama.gov/uploads/general/2014-ESC-Handbook-Vol-1.pdf>). Vegetation species used in stabilization should not compete with proposed native planting within the buffer.

VEGETATION

Habitat value: Vegetation has the vital role of stabilizing soil and providing habitat to wildlife in streamside forests. It is recommended to plant riparian buffers with a variety of woody and herbaceous vegetation to maximize wildlife benefit, species richness, and nutrient uptake efficiency. Leaves and twigs provide woody debris, or detritus, to the stream and are a food source to aquatic insects. Bird communities in diverse, planted, or restored riparian buffers are reportedly similar to established natural buffers. Vegetation that provides wildlife with a viable food source should be selected for the buffer. (See Appendix D for the Alabama Native Plant List.)

Herbaceous plants: Herbaceous vegetation is best planted in the spring, after the last frost.

Native grasses: Tall, stiff, fine-textured native grasses such as switchgrass (*Panicum virgatum*) have deep roots compared to turfgrass. They work well to stabilize riparian buffers and provide diffuse flow.

Dormant plantings: Woody vegetation, including live stakes, bare roots, and containers, benefit from winter installation. (See Appendix D: Vegetation for more information.)

Summer plantings: If summer plantings are a necessity, monitor plants closely for signs of drought stress and irrigate if necessary.

Plant establishment: Newly planted vegetation needs time to adjust to the shock of being transplanted. It is recommended that transplants be watered twice a week for the first six weeks after planting, especially in the growing season.

TABLE 11.8. MAINTENANCE SCHEDULE

TASK	HOW OFTEN	COMMENTS
Irrigate	After planting and during severe drought	Twice per week for six weeks after planting.
Replace dead vegetation	Annually	Diseased or infested vegetation should be removed.
Check for stream-bank erosion or incision	Annually	May need to replant vegetation or look upstream for causes of erosion.
Inspect	After 0.5" or greater rainfall event	Visually inspect all zones of the buffer for erosion or damage.
Mow turfgrass	More often in summer months	Grass should not be cut below 3"–5" and can be grown to a maximum of 12".
Check for invasive plants	Annually	See Appendix D: Vegetation for invasive plant management guidance.

Tagging plants: During planting, it may be helpful to tag or flag plants so they are easier to locate for maintenance purposes or vegetation survival monitoring.

MAINTENANCE

Primary maintenance tasks of riparian buffers are associated with vegetation and erosion. Perform maintenance such that minimal impact occurs to the buffer itself, particularly Zone 1 closest to the stream.

Nuisance species: Wildlife may hinder plant establishment as they browse. Inspect for this damage and correct when possible.

Plant replacement: Replace plants when mortality occurs. Dead plants provide favorable environments for insects and diseases to overwinter and should be removed. Over time, plant succession will occur naturally, and plant communities in the buffer may shift.

Livestock access: When buffers are adjacent to agriculture, fences should be maintained and repaired as needed to control livestock access to the stream.

Erosion: Fill in gullies resulting from concentrated flow and repair any resulting stream- bank erosion.

Mulch: Do not remove natural leaf litter from the buffer, as this provides necessary organic matter to the soil. After establishment, plants provide leaf litter and twigs for a natural organic mulch layer in the buffer.

Thinning trees: Trees can be thinned in the buffer, but trees with a trunk diameter greater than two inches should not be removed. Proper tree density or cover should be present before trees or undergrowth are thinned.

POLLUTANT REMOVAL

Although restored riparian buffers alone cannot provide complete surface runoff treatment (quality and quantity), buffers can filter various pollutants, particularly nutrients and sediment. Streamside vegetation transforms nutrients such as nitrogen and phosphorus into less harmful forms through nutrient cycling, plant uptake, and microbial processes.

Reduced runoff: Restored riparian buffers provide passive volume control as stormwater is slowed by vegetation and allowed to infiltrate to groundwater.

Buffer width: Wider buffers are generally noted to be more effective in removing pollutants, such as nutrients and sediment from surface runoff, although removal effectiveness is dependent on soil type, texture, hydrology, and biogeochemistry of underlying soils.



TABLE 11.9. POLLUTANT REMOVAL TABLE				
Sediment	Nutrients		Metals	Pathogens
	N	P		
a. 60%	30%	35%	-----	Medium
b. 85%	30%	40%	~50%	~70%

a. North Carolina Department of Environment and Natural Resources, 2006.
b. City of Auburn, Storm Water Management Manual. 209.

Total suspended solids: Suspended solids and turbidity are reduced through soil stabilization and erosion prevention, which can improve water quality of receiving streams. Dense grass cover in Zone 3 is shown to be effective in filtering sediment due to increased roughness.

Nitrate removal: Increased nitrogen reduction in wider riparian buffers is due to greater root surface area and increased nitrogen uptake through plant roots and microbial processes. Soils with subsurface anaerobic (without oxygen) conditions promote denitrification, which results in greater nitrate removal but may result in decreased infiltration. Grass-only buffers are less effective at reducing nitrogen than forested buffers.

Vegetation: Vegetated riparian buffers shade streams, reducing water temperatures that, in turn, increase dissolved oxygen concentrations and improve water quality.

Plant roots: Plant variety offers diversity in root morphology, which can be beneficial in soil stabilization. Riparian buffers stabilized with deeply rooted vegetation help retain soil during large rain events by reducing erosion and sedimentation. Taprooted plants and other deeply rooted species uptake nutrients from deeper soil horizons, stabilizing these deeper soil layers, while fibrous rooted species influence surface-soil horizons. Use woody plant species for stabilization, as these are generally more deeply rooted compared to herbaceous plants. Native grasses are an exception to the rule. For example, switchgrass (*Panicum virgatum*) has been shown to have roots as deep as 10.8 feet at maturity.

Evergreen vegetation: The presence of evergreen vegetation is desirable for nutrient removal because these plants retain their leaves and do not return nutrients to the soil during the autumn months. Fast-growing plant species are suggested for areas where nutrient removal is the primary goal.



Figure 11.4. The combination of trees, shrubs and grasses in this riparian buffer reduces sediment and other attached pollutants entering the stream. Photo courtesy of USDA NRCS.

REFERENCES

- Castelle, A. J., A. W. Johnson, and C. Conolly. 1994. "Wetland and Stream Buffer Size Requirements — a Review." *Journal of Environmental Quality* 23(5):878–894.
- City of Auburn. 2009. *City of Auburn Storm Water Management Design Manual*.
- Dabney, S. M., K. C. McGregor, L. D. Meyer, E. H. Grissinger, and G. R. Foster. 1993. "Vegetative Barriers for Runoff and Sediment Control" *Integrated Resources Management and Landscape Modification for Environmental Protection*. St. Joseph, MI: ASAE. J. K. Mitchell (ed.) p 60–70.
- Dosskey, M. G., P. Vidon, N. P. Gurwick, C. J. Allan, T. P. Duval, and R. Lowrance. 2010. "The Role of Riparian Vegetation in Protecting and Improving Chemical Water Quality in Streams." *Journal of the American Water Resources Association*.
- Lee, K. H., T. M. Isenhardt, R. C. Schultz. 2003. "Sediment and Nutrient Removal in an Established Multi-Species Riparian Buffer." *Journal of Soil and Water Conservation* 58(1):1–9.
- Ma, Z., C. W. Wood, and D. I. Bransby. 2000. "Impacts of Soil Management on Root Characteristics of Switchgrass." *Biomass and Bioenergy* 18:105–112.
- Mayer, P. M., S. K. Reynolds, T. J. Canfield, and M. D. McCutchen. 2012. *Riparian Buffer Width, Vegetative Cover, and Nitrogen Removal Effectiveness: A Review of Current Science and Regulations*. Cincinnati, OH: National Risk Management Research Laboratory, Office of Research and Development.
- Minnesota Pollution Control Agency. 2000. *Protecting Water Quality in Urban Areas*. Saint Paul, MN.
- National Research Council. 2002. *Riparian areas: Functions and strategies for management*. Washington, DC: National Academy Press.
- Natural Resource Conservation Service. 2001. *Conservation Practice Standard: Riparian Buffer* (Code 391).
- North Carolina Department of the Environment and Natural Resources. 2006. "Riparian Buffers" ch 112. *Stormwater Best Management Practices Manual*. Raleigh, NC: North Carolina Division of Water Quality.
- Simon, A., and A. J. C. Collison. 2002. *Quantifying the Mechanical and Hydrologic Effects of Riparian Vegetation on Streambank Stability*.
- Smith, T. A., D. L. Osmond, C. E. Moorman, J. M. Stucky, and J. W. Gilliam. 2007. "Effect of Vegetation Management on Bird Habitat in Riparian Buffer Zones." *Southeastern Naturalist* 7(2):277–287.
- Sudduth, E. B. and J. Meyer. 2012. "Effects of Bioengineered Streambank Stabilization on Bank Habitat and Macroinvertebrates in Urban Streams." *Environmental Management* 38(2): 218-2212.
- Environmental Protection Agency. 19912. *Ecological restoration: a tool to manage stream quality* EPA/841/F-95-006. Washington, DC: Office of Water.
- US Environmental Protection Agency. 20012. *Riparian/Forested Buffer Fact Sheet*. Washington, DC: Office of Water.
- Vidon, P. G. F., and A. R. Hill. 2004b. *Landscape Controls on Nitrate Removal in Stream Riparian Zones*. Water Resources Research 40, W0320, doi: 10.1029/2003WR002473.
- Wenger, S. 1999. *A Review of the Scientific Literature on Riparian Buffer Width, Extent and Vegetation*. Athens, GA: Office of Public Service and Outreach. University of Georgia.
- Young-Mathews, A., S. W. Culman, A. Sanchez-Moreno, A. T. O'Geen, H. Ferris, A. D. Hollander, and L. E. Jackson. 2010. *Plant-Soil Biodiversity Relationships and Nutrient Retention in Agricultural Riparian Zones of the Sacramento Valley, California, Agroforest Systems* 80:41–60.19.

RAIN GARDENS

A rain garden is a shallow depression in a landscape that captures water and holds it for a short period of time to allow for infiltration, filtration of pollutants, habitat for native plants, and effective stormwater treatment for small-scale residential or commercial drainage areas. Rain gardens use native plants, mulch, and soil to clean up runoff.



As urbanization increases and pervious surfaces decrease, rain gardens are an excellent practice to promote infiltration of up to 30 percent more stormwater than traditional lawns. Residential stormwater management can often help homeowners save money on lawn irrigation when lawns are converted to rain gardens. These areas are designed to capture three to six inches of runoff after a storm, which allows water to infiltrate and return to groundwater rather than be discharged to a stormwater conveyance network.

SITE SELECTION

Potential rain garden locations: Rain gardens can be located throughout the landscape to disconnect impervious surfaces and treat runoff from rooftops, driveways, sidewalks, existing landscapes, or a combination of these surfaces. Rain gardens are most effective at reducing stormwater runoff when disconnecting two impervious surfaces such as a rooftop and a street.

Practice pairing: Rain gardens can also be connected to other residential stormwater control measures (SCMs) for more effective stormwater treatment. For example, rain barrels can be used to capture rooftop runoff, and overflow from these barrels can be directed to rain gardens and used as a water source. Consult a landscape designer or other professional for projects that incorporate curbing or curb cuts, storm drains, any type of underdrain, or when drainage areas are larger than 2,000 square feet.

Pinch point: Locate the rain garden between the runoff source (rooftop, driveway, etc.) and the destination of runoff, also known as the “pinch point.” A pinch point is an area in which water is already converging, moving through, or exiting a property.

TABLE 12.1. SITE SELECTION

Quantity control	No
Drainage area	Small
Space required	Small
Steep slopes	Yes
Shallow water table	Yes
Poorly drained soils	Yes

TABLE 12.2. GENERAL SIGNIFICANCE

Construction cost	Low
Maintenance	Low
Community acceptance	High
Habitat	Medium–High
Sun/Shade	Sun to Part Shade

Observe the site: It is often helpful to watch water-flow patterns throughout the landscape on a rainy day. Snapping a few photos will help note problem areas. Look for eroded areas and sediment accumulation both in the landscape and at curbs. Check where gutters, downspouts, or roof valleys deposit roof runoff as potential rain garden locations.

Collecting from a rooftop: A good rule of thumb is to place rain gardens approximately ten feet downslope of the downspout. A simple swale or rock-lined ditch can be used at the roof drip line as the inlet to the rain garden to direct stormwater if gutters or downspouts are not available.

Planning for overflow: Consider how runoff will enter the garden, how it will be captured and held, and how it will exit the rain garden during heavy rain events. Alabama frequently experiences high-intensity storms rather than slow, soaking rain events. Because of this, overflow of the rain garden should be expected. Direct overflow to grassed or vegetated areas and never to the home foundation or to a neighbor’s property.

Infiltration test: An infiltration test is performed to determine the optimal rain garden location. Using a post-hole digger, auger, or other tool, dig at least two four-to-six inch diameter holes, approximately one foot deep in each potential rain garden location. Fill each hole with water and let drain completely to prime the hole for



Figure 12.1. Example of infiltration testing.

more accurate results; this is especially important during drought conditions. Next, fill the hole so that water is within one inch of the top of the hole. Use a ruler or other measuring tool to monitor the depth of the water. Record the start time in order to calculate the drain time. Monitor the amount of time required for water to infiltrate completely. Check the hole once an hour for at least four hours. The rate of drain time determines the most appropriate type of rain garden for the landscape (see table 12.3).

For more information on soil test protocols, go to the Alabama Cooperative Extension System website at www.aces.edu/pubs/docs/A/ANR-0006-A/index2.tmp. Soil samples can be sent to the Auburn University Soil Testing Lab (www.aces.edu/anr/soillab) or to other soil testing facilities to be analyzed.

Follow-up infiltration test:

Once a specific location and rain garden type are determined, an additional deeper infiltration test can be performed if there are any concerns about hard pans, bedrock, or other constraints that may limit stormwater percolation. Dig two to three holes at a depth of two feet and fill with water, similar to the standard infiltration test described above. These holes should drain within 48 hours to ensure that the rain garden does not create a mosquito breeding ground.

TABLE 12.3. INFILTRATION RATE		
INCHES/HOUR	DRAIN TIME	RAIN GARDEN TYPE
> 1 inch	< 12 hours	Standard rain garden
≥ 0.33 to ≤ 1 inch	12–36 hours	Zoned rain garden
< 0.33 hours	> 36 hours	Wet rain garden



Figure 12.2. Standard rain garden.

Soil test: Perform a soil test using the soils from the holes dug for the infiltration test. Soil sample boxes, information sheets, and other supplies for soil testing are available from the local county Extension office. A soil test should be performed to determine lime and nutrient recommendations for initial plant establishment and quality. Many plants prefer

specific pH ranges, and the soil test will recommend lime requirements if an increase in pH is necessary for optimal plant growth.

In-situ soil: Ponding depth is also a function of in-situ soil. Slower-draining soils should be designed with decreased ponding depths compared to well-drained soils. The time required to draw down or infiltrate this volume of water directly affects vegetation selection.




Figure 12.3. Wet rain garden.

TYPES OF RAIN GARDENS

Rain gardens can be designed in a variety of ways and may use different shapes, vegetation, and sizes to meet the needs of a particular site. All rain gardens should hold water after a rain event and infiltrate collected water within 36 to 48 hours. The primary differences in rain garden type refer to the time required for the rain garden to draw down the volume of stored water after a rain event, which is determined by the infiltration test.

Standard rain garden: A standard rain garden uses a uniform ponding depth (3 inches or 6 inches) of water across the entire base of the rain garden. Native soils are used and can be amended if necessary based on the infiltration rate found by the infiltration test. In these systems, the bottom of the rain garden area is raked level with no variation in elevation within the rain garden footprint.

Wet rain garden: If existing soils are more clayey and an infiltration test confirms that a particular site within the landscape does not draw down in 36 hours, a wet rain garden may be necessary. Poorly drained soils do not limit the use of a rain

TABLE 12.4. SITE SELECTION: CONSTRAINTS AND LIMITATIONS FOR RAIN GARDENS	
House foundation	Do not locate within 15 feet of building foundations with basements; otherwise five feet from the foundation is acceptable.
Slope	Rain gardens should not be located on slopes > 12 percent due to the inability to hold runoff in the rain garden without a really steep berm; flatter slopes will also require less digging
Septic system and drain field	Locate > 25 feet from septic system and upslope of the drain field
Utilities	Call 811 when selecting a site for the rain garden and before construction to locate utilities (for more information, visit: www.al1call.com); rain gardens should not be placed within five feet horizontally or one foot vertically from utilities
Seasonally high water table	If the seasonally high water table is within two feet of the bottom of the rain garden, a different location should be chosen for a standard rain garden or a wet rain garden should be considered
Large flow volumes	Decrease percentage of impervious area for treatment
Wellhead	Should be located at least ten feet from wellhead
Shaded areas	Locate in full sun to part shade if possible; dense shade will cause the rain garden to remain wet longer than intended and can promote mosquito breeding
Soggy areas in the landscape	Soggy areas are not good locations for a rain garden; consider capturing runoff before it settles in these spots of the yard.
Existing trees	Rain gardens should not be located within the drip line of existing trees so that tree roots are left undisturbed and water they uptake will not affect runoff the rain garden should capture
Existing retaining wall	Do not locate a rain garden upslope of a functional retaining wall; encouraging water to collect in these areas could damage the retaining wall structure
Heavy foot traffic	Foot traffic compacts soil and may damage plants; consider locating the rain garden in areas where pedestrians do not frequent or incorporate footpaths around the rain garden

garden in the landscape but may require a more specific vegetation plan to ensure plant survival, aesthetics, and mosquito prevention. Wet rain gardens can have standard (flat across the bottom) or zoned (variable) topography.

Zoned topography: Zoned topography provides changes in elevation so that some areas within the rain garden pond more or less, thus requiring a more diverse plant community with aquatic plants occupying deep pools and vegetation that prefers drier conditions in higher areas.

Design Steps

1. Determine subwatershed boundaries.

Consider your property and the source(s) of runoff for the rain garden.

- How does rainwater move on your property?
- Do you receive runoff from your neighbor's property?
- Are there areas that stay wet for long periods of time following a rain event?
- Have you examined pinch points on site? (See *section on Site Selection for more information.*) Treating the entire area may require the use of multiple rain gardens, especially if you receive runoff from neighboring properties as well as your own.

2. Estimate the amount of impervious area (IA).

Calculate the square footage of impervious surfaces (IA) within the boundaries you establish. Include all portions of rooftops, driveways, sidewalks, roadways, etc., that drain to the rain garden. If two roof areas drain to a single downspout that is used to direct flow, these roof areas are added together.

Curb cuts: If the rain garden collects roadway runoff, determine the flow pattern. In areas where a curb is present, a curb cut is needed. Contact the local municipal or county office if a curb cut is needed but not already in place.

Grassed filter strip: When there are no curbs, a two-inch-minimum grassed filter strip and optional one-foot-wide notch filled with rock is recommended to help slow runoff, trap sediment, and prevent erosion into the rain garden.

3. Choose a runoff capture depth and ponding depth.

The amount of rainfall treated by the rain garden is the runoff capture depth. Typically, the rain garden should treat the "first flush" or the first inch of rainfall, which has higher concentrations of pollutants in




Figure 12.4. Rain garden design components.

comparison with runoff later in the storm. (See Appendix A: Stormwater Hydrology for more information on stormwater runoff calculations.)

Ponding depth: The rain garden ponding depth refers to the depth at which water ponds in the rain garden before overflowing. Typically ponding depths are three or six inches. Either of these depths can be used in sandy soils, but a three-inch ponding depth is appropriate for clayey soils, as these drain more slowly.

4. Determine the size of the rain garden.

Sizing Rain Gardens

<p>EQN 12.1</p> <p>For a 3" Ponding Depth:</p> $\text{Rain Garden Size} = \frac{IA}{10}$	<p>EQN 12.2</p> <p>For a 3" Ponding Depth:</p> $\text{Rain Garden Size} = \frac{IA}{20}$
---	---

A good rule of thumb is to design the rain garden so that it is twice as long as it is wide perpendicular to the flow into the garden. Using the desired ponding depth and the total impervious area (IA), the size of the rain garden can be determined with the following equations:

5. Design a berm and/or overflow weir.

A berm is sufficient for rain gardens that are treating less than 2,000 square feet of IA.

EQN 12.3 Sizing Overflow Weir

For a rain garden over 2,000 square feet:

$$\text{Length of Overflow Weir} = \frac{IA}{2000}$$


Call a professional: If designing a rain garden with a drainage area greater than 2,000 square feet, consult an engineer or professional landscape architect (PLA) for weir or overflow design options. The length of the overflow weir can be determined by EQN 12.3.

Design Example

A residential rooftop is 50' x 40', for a total of **2,000 ft² of IA**. Half of the runoff from the rooftop is directed to the rain garden. The owner prefers **3" of ponding** due to clayey soils on-site.

Roof area = 2,000 ft², treating half of the rooftop
 Impervious area (IA) to be treated = 1,000 ft²
 Ponding depth = 3"

Using the rain garden sizing EQN 1, the rain garden is sized to be approximately 100 ft².
 Optional dimensions include 8' x 12' and 5' x 20'.



CONSTRUCTION

Below are construction steps for a standard rain garden.

1. Prepare the site.

Cost: A do-it-yourself (DIY) rain garden typically ranges from \$3 to \$5 per square foot depending on soil conditions, plant species and size, and planting density. Plant costs are the major expense associated with a DIY hand-dug rain garden. The installer can save on plant costs if a neighbor or friend already has suitable plants that require division. Depending on the size of transplants, however, dsat least one growing season is usually required before a plant size is reached that rivals one purchased.

Utilities: Locate utilities before digging the rain garden. Call 811 at least two working days prior to any construction. Outline the area of disturbance,

including the rain garden and some allowance outside of the rain garden, using white landscape marking paint to help 811 determine whether the rain garden installation will encroach on any existing underground utilities. In general, do not place rain gardens within five feet horizontally or one foot vertically from underground utilities.

Erosion and sediment control: Active construction activities can increase sediment loading in runoff that will clog the rain garden rendering it ineffective. Rain gardens should be designed to fit into the landscape but should not be constructed until all ongoing construction and land disturbance are complete in the drainage area.

Construction timeline: Rain garden construction is generally more efficient in early spring because digging is easier due to seasonal rainfall. Plants also benefit from an early spring planting due to less stress, milder temperatures, and a better chance for establishment. Summer and fall installations can work but may require more frequent irrigation and care until establishment. Most container sizes can be installed at any time of year as long as adequate irrigation is provided. (*For more information on plant sizes see Appendix D: Vegetation.*)

2. Excavate the site.

Excavation depth: The rain garden excavation is based on the chosen ponding depth of three or six inches for the design and whether or not your soil requires soil texture amendments. Note: When construction is complete and mulch is placed in the rain garden, there will be three or six inches of empty space in the garden for storage of the rain that is captured. Without the ponding depth, or water storage space, the rain garden is not able to capture the desired amount of runoff and will overflow more often than intended. (*See Rain Garden Excavation Depth graphics.*)

Topsoil: Topsoil is the first four to six inches of soil that is removed and set to the side to be incorporated with any necessary soil texture and quality amendments before placing plants in the rain garden. Topsoil is usually darker than deeper soil layers and contains high organic matter content that is great for plant establishment and nutrient availability.

Excavated soil: Soil that is removed can be stockpiled and placed in other parts of the landscape or can be used to make a berm when excavation is complete.

Compacted soils: If native soils are compacted or a hard pan is reached when digging, up to 8 inches of soil (including topsoil) may need to be removed or tilled from the soil layer of the rain garden so that plant roots can grow.

Sod removal: To remove sod, a shovel, sod cutter (rented from local hardware store), or a backhoe can be used. Set aside turfgrass sod for use on the rain garden buffer, berm, or other bare areas of the landscape. Keep sod with roots intact, in the shade, and evenly moist until replanting.

3. Shape the rain garden.

Buffer and slope: Once the rain garden is excavated to the desired depth, work the sides of the bowl to create a gentle slope that connects the rain garden to the existing grade or ground level of the landscape. A 3:1 slope works well to provide a gradual change in grade between the rain garden and the buffer.

Soil texture amendments: Soil texture amendments may be necessary to improve the soil's ability to infiltrate water in the rain garden. Amendments are generally a combination of yard compost or other organic matter and coarse sand. Infiltration rates of 1.5 inches per hour or greater do not require any soil amendments. For every 100 square feet of rain garden, a cubic yard or a three-inch layer of soil texture amendments is recommended.

Soil-quality amendments: Soil quality amendments such as any lime or fertilizer (indicated by soil test results) should be incorporated into topsoil. Animal waste compost is not recommended due to typically high nutrient content.

Backfill: Next, use a rake, shovel, or rototiller to break up topsoil that was set aside. This topsoil is mixed with soil amendments (if necessary) and placed back in the rain garden. Begin by mixing in one inch" of soil-texture amendments and soil-quality amendments with some topsoil to create a mix that is about 50/50 topsoil and amendments. If topsoil is poor quality on-site, reduce the amount of topsoil added to the amendments for rain garden backfill. Work this soil mixture back into the existing soil in the rain garden until approximately two or three inches have been added. Check the depth with a yardstick or ruler to make sure it has not been overfilled. Rake and smooth out the soil so the bottom is level. This will prevent ponding in lower areas. At this point, the empty space should equal the desired ponding depth plus a mulch depth of three inches.

Mulch quantity in cubic feet = 0.25 feet*
 x length of rain garden (ft) x width of rain garden (ft)
 *0.25 feet= 3 inches of mulch.

A general rule of thumb is 0.5 cubic yards of mulch for every 50 square feet of rain garden. Bagged mulch is usually sold in cubic feet; however, if ordering a large quantity, keep in mind that it is sold by cubic yards and will need to be converted accordingly. Small, tender perennial plants can be protected during mulch placement by placing containers over plants to ensure that the mulch layer does not unintentionally cover them. Mulch should be aged at least six months so it does not rob nitrogen from plants trying to establish. Triple- or double-shredded hardwood mulch is recommended for rain gardens because it has a decreased tendency to float away. However, hardwood mulch can be difficult to find in Alabama, especially when large quantities are needed. Pine bark or straw has been used successfully but may require more frequent replacement to maintain a three-inch mulch layer. Cypress mulch is not recommended as it is harvested from cypress wetlands and is not sustainable.

4. Prepare the inlet, berm, and overflow.

Inlet: To prevent erosion at the inlet, a one-foot-wide strip of gravel, rocks, or concrete splash pad can be added to slow down and evenly disperse the flow of water into the rain garden. This is especially helpful when there are no gutters or a gutter extension cannot be incorporated. More rocks can always be added later if erosion occurs.




Figure 12.6. Building a berm before digging.




Figure 12.7. Building a berm after digging.

Berm: Mound the berm on the downhill side of the rain garden where the overflow will exit. A berm is not usually necessary when a rain garden is installed on a level landscape. Mound the berm as high as the uphill grade of the rain garden (see diagram below). Native grasses or turfgrass sod can be grown (or repurposed) on the berm to provide cover and stabilize berm soil.

Overflow: A low spot or notch can be created on the berm to serve as the overflow. Stabilize the overflow area of the berm with landscape fabric, stone, or turfgrass to prevent erosion. Landscape fabric is used to deter weed growth in the overflow, and the notch should be filled with three to six inches of stone. Be sure that the overflow directs water leaving the rain garden to a vegetated area and away from any structures.

VEGETATION

Plant characteristics: Rain garden type determines which vegetation to use.

Generally, plants for rain gardens should be able to withstand periodic wet and dry periods. Most standing water in a standard rain garden should infiltrate within 24 hours. During extended periods of rainfall, however, plants that are unaccustomed to these conditions may suffer. Likewise, periods of extreme drought may also injure plants that are not drought tolerant. Plants selected for all types of rain gardens should be evergreen or perennial and have sturdy root systems at planting.

Native plants: Native plants are adapted to local environmental conditions and are considered to be low maintenance, since they require less fertilizer, water, and pest control inputs, and are usually able to persist during periods of low rainfall or drought once established. Using native plants can also help meet ecological site goals such as providing wildlife habitat, food sources, or breeding sites.

Butterfly attractors: Many rain garden plants attract butterflies. A combination rain garden and butterfly garden can be created with appropriate plant selection.

For more information regarding wetland indicator status, see Appendix D: Vegetation.

Edible plants: When using edible plants, eat at your own risk. Rain gardens capture pollutants from impervious surfaces, which may be absorbed by plants and held in the tissues.

Standard rain garden: A standard rain garden includes plants that prefer moist and dry conditions that have a facultative (FAC or FACW) wetland indicator status, indicating they are found in both wetland and nonwetland areas.

Wet rain garden: A wet rain garden utilizes wetland plants that are better suited to mostly wet conditions with facultative (FACW) and obligate (OBL) wetland indicator status.

Zoned wet rain garden: A wet rain garden with zoned topography should have a mixture of plants for dry, moist, and wet conditions based on the topography of the rain garden.

Right plant, right place: Place plants more suited for wet conditions in the center of the rain garden, as this is the area that typically remains wet the longest. In general, place plants that prefer drier conditions on the slope or perimeter of the rain garden. Be sure to plant accordingly based on preferred sunlight and water requirements.

Plant spacing: The plant budget often drives plant spacing. Dense planting or using larger containers is more expensive. Perennials may be spaced two or more feet apart to lower plant costs. Some property owners, however, may prefer an instant landscaped look. In this case, herbaceous perennial plants are usually spaced more closely. This is not only more expensive, but may lead to

additional maintenance in the future as plants spread to colonize an area and encroach on one another's space. Plants can compete for moisture, nutrients, and sunlight, so it's best to resist the urge to overplant.

Seasonal interest: Plan for seasonal interest by including plants that bloom at various times of year. Consider including species that are evergreen or have showy fall color. A Seasonal Interest Calendar can be created to show times of year when plants are most visually interesting to ensure year-round aesthetic value.

RAIN GARDEN PLANT LIST

The following plant list contains plants native to Alabama that are appropriate for standard and wet rain gardens.

Botanical name: This column indicates the genus and species assigned to each plant. Botanical or scientific names should always be used to prevent confusion, because only one plant is assigned that particular name; many plants share the same common name, which causes confusion. (For example, the common name possumhaw could indicate *Ilex decidua* or *Viburnum nudum*.) (For more information, see *Botanical Names in Appendix D: Vegetation*.)

Common name: This column is the name applied to a plant based on its botanical name, appearance, or some other characteristic of the plant.

TABLE 12.5. SEASONAL CHART

Botanical Name	Spring	Summer	Fall	Winter
<i>Conoclinium coelestinum</i>				
<i>Clethra alnifolia</i>				
<i>Fothergilla gardenii</i>				
<i>Ilex verticillata</i>				
<i>Itea virginica</i>				
<i>Lindera benzoin</i>				
<i>Morella cerifera</i>				
<i>Muhlenbergia capillaris</i>				
<i>Rudbeckia fulgida</i>				
<i>Stokesia laevis</i>				
<i>Vernonia gigantea</i>				
<i>Viburnum nudum</i>				



Figure 12.8. Determining plant spacing for a small rain garden. Pioneer Museum, Troy, AL.

TABLE 12.6. RAIN GARDEN PLANT LIST				
Botanical Name	Common Name	Type	Soil Comments	Prefers
<i>Acorus calamus</i>	sweetflag	herbaceous grass	acidic, wet	2, 3: sun to part shade
<i>Asclepias incarnata</i> *	swamp milkweed	herbaceous perennial	any	3: sun or part shade
<i>Amsonia tabernaemontana</i>	eastern bluestar	herbaceous perennial	sandy	3: part shade
<i>Baptisia alba</i>	white wild indigo	herbaceous perennial	sandy to rocky, tolerates clay	1, 2: sun
<i>Carex crinita</i>	fringed sedge	grasslike	any	2, 3: part shade to shade
<i>Carex hystericina</i>	bottlebrush sedge	grasslike	any	3: part shade
<i>Carex lurida</i>	lurid sedge	grasslike	any	3: part shade
<i>Carex tribuloides</i>	blunt broom sedge	grasslike	any	2, 3: part shade
<i>Chasmanthium latifolium</i>	river oats	herbaceous perennial	any	2: part shade
<i>Conoclinium coelestinum</i> *	blue mistflower	herbaceous perennial	any	2: sun to part shade
<i>Clethra alnifolia</i> *	summersweet	shrub	any	2, 3: sun or part shade
<i>Coreopsis auriculata</i> *	lobed tickseed	herbaceous perennial	rich, acidic	2: part shade
<i>Coreopsis lanceolata</i> *	tickseed	herbaceous perennial	any	1, 2: sun
<i>Coreopsis nudata</i>	Georgia tickseed	herbaceous perennial	rich, acidic	2, 3: part shade
<i>Echinacea purpurea</i> *	coneflower	herbaceous perennial	sandy	1, 2: sun or part shade
<i>Eupatoriadelphus fistulosus</i> *	joe Pye weed	herbaceous perennial	acidic, moist, or wet	2, 3: sun
<i>Helianthus angustifolius</i>	swamp sunflower	herbaceous perennial	any	2, 3: sun to part shade
<i>Hibiscus coccineus</i>	scarlet rosemallow	herbaceous perennial	any wet	3: sun
<i>Hibiscus moscheutos</i> *	crimson-eyed rosemallow	herbaceous perennial	moist, alkaline	2, 3: sun to part shade
<i>Ilex glabra</i>	inkberry	shrub	sandy, acidic, peaty	1, 2: sun or part shade
<i>Ilex verticillata</i> *	winterberry	small tree	any, acidic	1, 2: sun or part shade
<i>Itea virginica</i>	sweetspire	shrub	any, acidic	1, 2, 3: sun or part shade
<i>Juncus effusus</i>	common rush	grasslike	any, wet	2, 3: sun or part shade

TABLE 12.6. RAIN GARDEN PLANT LIST (CONTINUED)				
Botanical Name	Common Name	Type	Soil Comments	Prefers
<i>Lobelia cardinalis</i> *	cardinal flower	herbaceous perennial	any, will tolerate limestone based soils	2,3 Sun to Part Shade
<i>Muhlenbergia capillaris</i>	muhly grass	herbaceous grass	sandy or sandy loam	1,2 Sun or Part Shade
<i>Phlox carolina</i> *	Carolina phlox	herbaceous perennial	sandy, loam, acid, will tolerate some lime	2 Sun to Part Shade
<i>Phlox divaricata</i> *	blue woodland phlox	herbaceous perennial	any	2 Part Shade
<i>Physostegia virginiana</i> *	obedient plant	herbaceous perennial	humus rich soils	1,2,3 Sun to Shade
<i>Pontederia cordata</i>	pickerelweed	herbaceous perennial	any	3 Sun to Part Shade
<i>Rudbeckia fulgida</i>	orange coneflower	herbaceous perennial	sandy	1,2 Sun or Part Shade
<i>Sisyrinchium angustifolium</i>	blue eyed grass	grass	poor to average moist soils	2,3 Sun to Part Shade
<i>Stokesia laevis</i> *	Stoke's aster	herbaceous perennial	well drained acid sand preferred	1,2 Sun or Part Shade
<i>Vernonia noveboracensis</i> *	Ironweed	herbaceous perennial	tolerates clay and acidic soils	1,2 Sun
<i>Viburnum nudum</i>	possumhaw	shrub	prefers acid mucky soils, but is adaptable	1,2,3

*Attracts butterflies, hummingbirds, or both

1. prefers dry conditions and can tolerate drought conditions; to be used on buffer, slope, or berm of standard rain garden and wet rain gardens with zoned topography.
2. prefers moderate or moist conditions and can tolerate occasional inundation. Plants labeled 2 are appropriate for the center of standard rain garden designs or wet rain gardens with zoned topography.
3. prefers wet conditions and is appropriate for wet rain gardens and deep pools of wet rain gardens with zoned topography.

Sun – at least 6 hours of full sun per day.
Part Shade – 3 to 5 hours without direct sun per day.
Shade – less than 2 hours of direct sun per day.

Type: This column indicates the plant's growth habit (shrub, tree, herbaceous perennial or grass, fern, etc.).

Soil comments: Many plants have a pH range or type of soil they will perform best in; this column shows any soil preferences each plant may have.

Prefers: This column shows moisture and light requirements for each plant. (See *Table for moisture and light requirement definitions.*)

Vegetation Design Guidelines

- Consider mature plant sizes, particularly if the rain garden is sited where visibility is a concern.
- The design plan should reflect mature plant sizes. Every square foot of the rain garden will not be covered at planting, but over time the area will naturally fill.
- Large trees are generally not recommended due to the size and canopy cover, which can outcompete and shade out other plants. If you desire the size contrast offered by trees, consider training a shrub such as wax myrtle (*Morella cerifera*) into a tree form.
- Consider the direction a rain garden will be viewed. If it will be viewed from one side (i.e., the rain garden is located in the back of the yard), it may be appropriate to place taller plants in the back. If the rain garden will be viewed from two or more sides (i.e., the rain garden is sited in the front yard), taller plants should be placed in the center of the rain garden.

Create a Landscape Design

Sketch it out: Sketch the rain garden area to help visualize how it will look after planting. A circle template (purchased from the school supply section) can be used to create a bird's-eye or plan view of the rain garden sketched to scale. You need to establish an appropriate scale to use (often decided by your available paper size), such as one inch equals one foot. Start by sketching out the footprint of the rain garden. If using a 1" = 1' scale, a 10 x 20 foot rain garden would be sketched on paper to an actual size of 10 x 20 inches. (See *section on Bioretention for examples of sketched-out landscape designs.*)

Grouping plants: Plants are usually grouped in clumps of three, five, or seven to avoid monocultures (plantings with only one plant species).

Maintenance access: Be sure to include space between different plantings for maintenance access as well as any reseeding of perennial plants.

For more information on creating a landscape design, contact the local county Extension office.

Calculating Plant Quantity

Another design option (used in design examples 1 and 2, which follow) is to calculate a plant quantity. Creating a landscape drawing is best, but a plant quantity can also be calculated so that plants can be ordered and placed on the day of planting. Calculating plant quantity helps to avoid over- or underpurchasing of plants and overcrowding plants. When plants are purchased, nursery tags denote preferred plant spacing for each species as well as plant height, soil characteristics, and light requirements. Species-specific spacing should always be used when that information is available, but the suggested spacing based on plant type in this handbook provides good general recommendations.

Divide the space: It is sometimes easiest to divide the area into a mixture of smaller shapes that have easily calculated areas. For example, a rectangular rain garden can be divided into smaller squares, circles, or rectangles. This makes it easier to calculate the quantity of each plant for each part of the rain garden.

Spacing guidelines: Plants can be spaced based on plant type, and a plant quantity for each section of the rain garden can be calculated. This is especially helpful if the rain garden will consist mostly of grasses and perennials, because two-foot spacing is appropriate for most species of both plant types. By using this method, the total amount of plants needed is known, and the rain garden plant selection can be based on what is available at the local nursery.

As a general rule for rain gardens, plant spacing guidelines based on plant types can be used as seen in table 12.7.

TABLE 12.7. PLANT SPACING GUIDELINES

PLANT TYPE	SPACING
Herbaceous perennials	1.5'–2'
Grasses	2'–3'
Shrubs	4'–5'

**Note: These spacing guidelines are meant to create masses of each plant type with sweeps of color. For more space between each plant, increase the spacing.*




Figure 12.9. Illustration of rectangular and triangular spacing with plants.

Spacing patterns: Plant quantity is calculated based on the square feet needed per plant, which is based on whether you plan to arrange plants on a rectangular or triangular grid pattern. For rectangular spacing, the space between plants and between rows is the same. Triangular spacing is generally more visually appealing, as it creates a mass-planting look in which plants are equally spaced within row but the rows are staggered.

An equation can be used to calculate plant quantity based on the selected spacing pattern.

$$\text{Quantity} = \text{area (ft}^2\text{)} \div \text{square feet needed per plant.}$$

So for a 100 square-foot rain garden planted with herbaceous perennials on two-foot spacing in a rectangular spacing pattern, how many plants would be needed?

Rectangular Spacing Equation

$$\text{ft}^2 / \text{plant} = (x)(x) = x^2$$

$$\text{Quantity} = \frac{\text{Area (ft}^2\text{)}}{\text{ft}^2 / \text{plant}}$$

Triangular Spacing Equation

$$\text{ft}^2 / \text{plant} = YX$$

$$Y = X(0.866)$$

$$\text{ft}^2 / \text{plant} = [X * 0.866]$$

$$\text{Quantity} = \frac{\text{Area (ft}^2\text{)}}{\text{ft}^2 / \text{plant}}$$



$$\text{Quantity} = \frac{100 \text{ ft}^2}{4 \text{ ft}^2 / \text{plant}} = 25 \text{ plants}$$

$$\text{Quantity} = \frac{100 \text{ ft}^2}{3.4 \text{ ft}^2 / \text{plant}} = 29 \text{ plants}$$









When using this equation, you will almost never come up with a whole number. Since half of a plant cannot be installed, you must decide whether to round up or down. Units of area should be consistent; therefore, if your spacing is in inches, the area should be converted to square inches.

Vegetation Design Example 1 Standard Rain Garden

This rain garden vegetation plan was designed for a front yard with showy plants and seasonal interest. The design calls for a three-inch ponding depth and an 8 x 12 foot (96 square feet) rectangle on a triangular spacing pattern. The slope and buffer are planted with repurposed turfgrass.




Plant List

Plant Common Name	Spacing (ft)	Area (ft ²)	ft ² /plant	Quantity
 crimson-eyed rose mallow	3	24	6.8	3
 muhly grass	2	6	3.4	2
 muhly grass	2	6	3.4	2
 muhly grass	2	6	3.4	2
 purple coneflower	1.5	6	2	3
 purple coneflower	1.5	6	2	3
 orange coneflower	1.5	6	2	3
 orange coneflower	1.5	6	2	3
Stokes' aster	1.5	6	2	3
Stokes' aster	1.5	6	2	3
Stokes' aster	1.5	6	2	3
Stokes' aster	1.5	6	2	3

Vegetation Design Example 2

Wet Rain Garden

This rain garden vegetation plan was designed for a residential backyard. The design calls for a three-inch ponding depth and an 8 x 12 foot (96 square feet) rectangle on a triangular spacing pattern with standard (level) topography throughout the garden. The slope and buffer of this rain garden are planted with muhly grass.



Plant List











Plant Common Name	Spacing (ft)	Area (ft ²)	ft ² /plant	Quantity
 common rush	2	6	3.4	2
 common rush	2	6	3.4	2
 common rush	2	6	3.4	2
 common rush	2	6	3.4	2
 cardinal flower	1.5	12	2	6
 cardinal flower	1.5	12	2	6
 sweetflag	2	6	3.4	2
 sweetflag	2	6	3.4	2
 swamp milkweed	1.5	12	2	6
 scarlet rosemallow	3	2	6.8	3



Figure 12.10. Rain garden at Pioneer Museum, Troy, AL.

MAINTENANCE

Sediment and debris removal: Rain gardens collect surface runoff from impervious surfaces and, as a result, tend to trap sediment and other debris. Although sediment deposition means that the rain garden is functioning, this sediment should be removed periodically. Sediment in the rain garden can cover plants, hindering their growth. It can create a favorable environment for weed seeds to germinate. And it can clog mulch void space, which may keep the rain garden from drying out between rain events. Remove trash and other inorganic items from the rain garden as they collect.

Mulch replacement: Leaves degrade and mulch decomposes to replenish organic matter to the soil. Maintain mulch at three inches and replace bare areas as needed. Full mulch removal and replacement should occur every two to three years or when mulch has become matted, thus preventing adequate infiltration of stormwater. Mulch depth should never be in excess of three inches. Applying excess mulch limits the storage volume of the rain garden and can potentially lead to problems associated with root rot of plants.

Pruning: Shrubs benefit from annual pruning to encourage bud break and to help maintain plant shape and form. Prune plants based on the May Rule (see *Appendix D: Vegetation*). Seed heads and spent flowers can be left on herbaceous perennials for winter interest and as a food source for wildlife. It is sometimes helpful to leave the seed heads so that these plants are not mistaken as weeds in the spring when new shoots begin growing. Leaving the seed heads can also encourage these plants to reseed themselves.

REFERENCES

- Bailey, D. A., and M. A. Powell. 1999. *Installation and Maintenance of Landscape Bedding Plants*.
- Bannerman, R., and E. Considine. 2003. *Rain Gardens: A how-to manual for homeowners*. University of Wisconsin: University of Wisconsin – Extension Environmental Resources Center.
- Dietz, M. E., and J. C. Clausen. 20012. "Saturation to Improve Pollutant Retention in a Rain Garden." *Environ. Sci. Technol* 40:1335–1340.
- Dougherty, M., C. LeBleu, E. Brantley, and C. Francis. 2006. *Evaluation of Bioretention Nutrient Removal in a Rain Garden with an Internal Water Storage (IWS) Layer*. American Society of Agricultural and Biological Engineers: Meeting Proceedings.
- Dunnett, N., and A. Clayden. 2006. *Rain gardens: managing water sustainability in the garden and designed landscape*. Portland, OR: Timber Press.
- Dussailant, A. R., A. Cuevas, and K. W. Potter. 20012. "Stormwater infiltration and focused groundwater recharge in a rain garden: simulations for different world climates." *Sustainable Water Mgt. Solutions for Large Cities* 293:178–184.
- Dylewski, K. L., A. N. Wright, K. Tilt, and C. LeBleu. 2012. "Effects of Previous Flood Exposure on Flood Tolerance and Growth of Three Landscape Shrub Taxa Subjected to Repeated Short-term Flooding." *Journal of Environmental Horticulture* 30(2):58–64.
- Hunt, W. F., and N. White. 2001. *Designing Rain Gardens* (bio-retention areas). North Carolina Cooperative Extension AG-588-3.
- Isaacs, K., J. Tuell, A. Fieldler, M. Gardiner, and D. Landis. 2009. "Maximizing Arthropod-Mediated Ecosystem Services in Agricultural Landscape: the Role of Native Plants." *Frontiers in Ecology and the Environment* 7:196–200.
- New Jersey Rain Garden Manual*. Native Plant Society of New Jersey. Accessed May 3, 207. http://www.npsnj.org/pages/nativeplants_Rain_Gardens.html.
- Obropta, C., W. J. Sciarappa, and V. Quinn. 20012. *Rain Gardens Fact Sheet*. New Brunswick, NJ: Rutgers Cooperative Research and Extension.
- Virginia Department of Forestry. 2007. *Rain Gardens Technical Guide*. Charlottesville, VA: Virginia Department of Forestry.

TABLE 12.8 MAINTENANCE SCHEDULE

TASK	HOW OFTEN	COMMENTS
Test soil	Prior to planting and every 3 to 5 years thereafter	Incorporate soil-quality amendments such as lime and fertilizer prior to planting.
Irrigate	At planting and twice per week for 6 weeks after planting	Once established, irrigate only during drought.
Inspect	After 0.5" or greater rainfall event	Visually inspect all components of the rain garden for erosion or damage.
Prune	Annually	Prune based on the May Rule.
Replace dead vegetation	After first growing season	Remove diseased or insect-infested vegetation.
Divide plants	Every 2 or 3 years	Plants may become crowded over time, and many perennials recommended for rain gardens will need to be divided. (See Appendix D: Vegetation for more information.)
Remove trash	As needed	Rain gardens in more commercial settings collect trash more frequently.
Remove deposited sediment	As needed or annually	Use a flat shovel to remove.
Check for invasive plants	Twice per year	Hand pull and make sure mulch is in place to prevent weed seeds from germinating.
Replace mulch	Every 2 or 3 years	May need to replace bare areas to maintain at 3" depth.

POLLUTANT REMOVAL

Rain gardens are designed to uptake nutrients, such as nitrogen and phosphorus, found in runoff. To facilitate phosphorus removal, rain garden soil should have a low to very low extractable phosphorus as indicated by a routine soil test. Research shows that rain gardens planted in soils with high phosphorus actually export this nutrient instead of trap it. Many Alabama watersheds and waterways already have excess phosphorus. Select a different site for the rain garden if the soil test indicates high or very high phosphorus levels.

CURB CUTS

Curb cuts convey stormwater into vegetated areas such as roadside swales, parking lot islands, rain gardens, or bioretention areas. They are an easy retrofit to used in residential or commercial land use areas and are effective in moving stormwater to landscaped areas.



Curb cuts are often used to convey stormwater into another low impact development (LID) practice. They do not perform any pretreatment, but they can minimize erosion by creating diffuse flow into other stormwater control measures (SCMs). Curb cuts can also be installed to redirect stormwater into a grassy field. While this is not directly considered an LID practice, it does slow stormwater quantity entering the receiving water body. Roadside curb cuts usually intercept perpendicular stormwater flow. In many cases multiple curb cuts are needed to adequately collect and move stormwater.

SITE SELECTION

Crested streets: Roadside curb cuts are best when used on crested streets that have their highest point in the center of the street and carry stormwater to either side.

Site visit: Prior to design, a site visit during a rainfall event is helpful to note flow patterns that may affect stormwater conveyance into future curb cuts.

Local ordinances: City or county codes and ordinances may require a permit application before any ground can be broken for curb-cut construction.

Driveways and intersections: It is recommended that curb cuts are sited at least 5 feet from driveway aprons and 20 feet from intersections.

Right-of-way: When curb cuts are used to direct flow from roadsides into the right-of-way (ROW), landscaped areas should be a minimum of 6 feet wide when street parking is utilized and 5 feet wide on streets absent of parking.

TABLE 13.1. SITE SELECTION	
Quantity control	No
Drainage area	Small
Space required	Small
<i>Works with:</i>	
Steep slopes	No
Shallow water table	No
Poorly drained soils	No

TABLE 13.2. GENERAL SIGNIFICANCE	
Construction cost	Medium
Maintenance	Low
Community acceptance	High
Habitat	—
Sun/Shade	Either

Slope: Streets with greater than 5 percent slope are not recommended for curb cuts.

Submerged curbs: Curbs that are submerged in water are not recommended for curb cuts.

DESIGN

Components

Outlet protection: A rock apron as wide or wider than the curb cut is laid one to two inches below the curb cut to prevent soil erosion in the landscaped area that collects stormwater.

Curb cut: Curb cuts are generally 18 to 24 inches wide (a minimum of 12 inches wide is recommended to reduce the chance of clogging). The cuts are usually made at 45-degree angles, forming a trapezoidal channel shape. The bottom on the cut should be sloped down toward the area of stormwater collection.




Figure 13.1. Curb cut detail.




Figure 13.2. Curb cut diagram.

TABLE 13.3 MAINTENANCE SCHEDULE		
Task	How Often	Comments
Remove debris from curb cut	Three to four times per year	Remove trash or debris that may inhibit stormwater flow.
Check rock apron	Annually	Repair any erosion to rock apron.
Inspect	After 0.5" or greater rainfall event	Visually inspect all components of the curb cut.

Practice pairing: When curb cuts are used in conjunction with SCMs, a two- to three-inch drop at the intersection of pavement and the SCM is needed to convey stormwater into the SCM.

POLLUTANT REMOVAL

Curb cuts are used to convey stormwater into another SCM or vegetated area. Any associated pollutant removal occurs in the LID practice that receives the redirected stormwater.



Figure 13.3. Curb cut at Hank Aaron Stadium, Mobile, AL.


REFERENCES

- City of Tucson, AZ. 2010. *Green Infrastructure for Public Right-of-Ways: Curb Cuts and Sediment Traps*. Tucson, AZ: Watershed Management Group.
- Pennsylvania Department of Environmental Protection. 2012. *Pennsylvania Stormwater Best Management Practices Manual*. Harrisburg, PA: Bureau of Watershed Management.

DISCONNECTED DOWNSPOUTS

Rooftop runoff can be directed to vegetated areas through the disconnection of rooftop downspouts. By redirecting rooftop runoff, stormwater entering the stormwater conveyance network is reduced and groundwater recharge and runoff infiltration is increased.

Disconnected downspouts are often used in conjunction with other stormwater infiltration practices by directing runoff to practices such as rain gardens, bioretention areas, and grassed swales. In doing so, the need for curbs, gutters, and conventional collection or conveyance of stormwater is reduced.



Conventional stormwater practices focus on the immediate removal and conveyance of stormwater from impervious surfaces into stormwater conveyance networks. Typically, a stormwater conveyance network transports stormwater to a nearby outfall that is eventually discharged into a local waterway. As urban areas in Alabama expand and redevelop, increases in stormwater flows place tremendous pressures on aging sewer infrastructures. Disconnecting downspouts can help reduce the volume of untreated stormwater directed to waterways and decrease pollution in local streams.

Disconnected downspouts are applicable in residential or commercial settings. This handbook provides information regarding downspout disconnection for homeowners.

TABLE 14.1. SITE SELECTION	
Quantity control	No
Drainage area	Small
Space required	Small
<i>Works with:</i>	
Steep slopes	No
Shallow water table	No
Poorly drained soils	No

SITE SELECTION TIPS

- Develop a good plan prior to downspout disconnection.
- Disconnecting the downspout should not result in any structural damage to you or your neighbor's property.
- Do not direct disconnected

TABLE 14.2. GENERAL SIGNIFICANCE	
Construction cost	Low
Maintenance	Low
Community acceptance	High
Habitat	---
Sun/shade	Either

TABLE 14.3. SITE SELECTION: CONSTRAINTS AND LIMITATIONS FOR DISCONNECTED DOWNSPOUTS

House foundation	Water should be discharged 5' from basements and 2' from building foundations. Water should flow away from structure foundations.
Slope	Downspouts should not be disconnected in areas with more than 10% slope.
Septic system drain fields	Do not direct runoff over a septic system.

downspouts to compacted soil that will not infiltrate stormwater. If downspouts are to be directed to poorly drained soils, conduct an infiltration test to ensure that standing water conditions will not persist beyond 48 hours, as this can lead to mosquito breeding. (*For more information on how to conduct an infiltration test, see section on Rain Gardens.*)

- Proper execution of downspout disconnection should still allow stormwater to be quickly removed from any roadways and should not result in standing water on impervious surfaces.
- Areas with slopes greater than 10 percent are not appropriate for disconnected downspouts because steep slopes can result in increased runoff velocities and erosion.

MAINTENANCE

Gutters: Gutters should be free of debris, pitched, and efficiently direct water to attached downspouts. Flashing on the roof should direct water to the gutter system to avoid home maintenance issues.

Downspouts: Downspout elbows are prone to clogging and should be checked periodically so that water flows freely. Check extension pieces for proper connection. If these become loose, use sheet metal screws to firmly attach one piece to another.

TABLE 14.4. MAINTENANCE SCHEDULE

TASK	HOW OFTEN	COMMENTS
Clean gutters	At least twice a year	Gutters with trees overhead may require cleaning out more frequently.
Caulk leaks in gutters	As they occur	Repair leaks or holes as they appear.
Clear elbows or bends	As clogging occurs	Debris may collect in elbows or bends, which can inhibit water flow.
Inspect	After 0.5" or greater rainfall event	Visually inspect the downspout, gutters, and splash block for any damage.

DESIGN EXAMPLE

The following steps have been adapted from the City of Portland, OR, 209.

1. Examine your site.

The first step is to determine where the downspouts drain to or where the runoff from the rooftop goes. Downspouts may drain to a standpipe or other stormwater conveyance network. It helps to draw or print out an aerial view of the building where rooftop square footage can be estimated and downspouts can be located.

2. Make a plan.

Mark downspouts on the site plan and determine any obstructions, such as walkways or impervious surfaces, to avoid when water is redirected. Extension elbows can be used to direct water around areas that need to be avoided or to direct water away from building foundations. Rooftop runoff can be directed to a rain garden or other landscaped area as long as the landscaped area is at least 10 percent of the rooftop footprint area. Rain gardens work well to treat rooftop runoff from downspouts because they are bowl-shaped landscaped areas meant to capture water and encourage infiltration. (See section on Rain Gardens for more information.)

Check your available landscape size:

Roof Area		Sizing Factor		Landscape Area Size Needed
1000 ft ²	x	10%	=	100 ft ² (10' x 10')

Gather your tools:

- measuring tape
- needle-nose pliers or crimpers
- hacksaw
- drill
- screwdriver or nut driver

Materials: Include any downspout elbow or extensions needed plus any materials necessary to seal the standpipe. Be sure to measure the inside diameter of the standpipe so that the correct size of rubber cap and hose clamp are purchased. If the downspout is only attached to the standpipe and gutter, use a strap or bracket to attach it firmly to the building once the downspout is disconnected. Use durable materials for the elbows and extensions. Avoid using corrugated plastic, PVC, dryer hose, or other materials that degrade quickly.

Extensions can be used to direct runoff away from foundations or under other obstructions, such as a deck, so that flow is directed to a landscaped area. A hinged extension is helpful to use since it can be lifted out of the way when mowing the lawn. Concrete splash blocks or decorative rocks can be placed just beneath the downspout to minimize any erosion and to direct flow during a heavy rain. A concrete splash block helps to spread the runoff evenly in a sheet-flow pattern.

continued on next page

3. Disconnect the existing downspout.

Cut the downspout approximately nine inches above where it meets the standpipe. Check the downspout extension length and cut higher if necessary. Seal or plug the standpipe using either an in-pipe test plug or a cap secured by a hose clamp. Do not use concrete or any other substance to seal the standpipe. Attach the elbow over the downspout; attaching the elbow inside the downspout can cause leakage near the building foundation. Needle-nose pliers or crimpers can be used to bend the downspout to ensure that the elbow fits over the cut downspout. Next, measure the extension to either two feet, six feet, or to the length necessary to avoid obstructions. Two feet is the minimum amount of extension away from the building foundations and crawl spaces; six feet is used when there is a basement that could potentially flood. Be sure to attach the extension pieces over the downspout elbow.

Do not direct your runoff into neighboring properties. The extension should end at least five feet before the property line.

Use sheet-metal screws to attach extensions and elbows to one another. Pilot holes can make this an easier process. Add a concrete splash block or rocks below the extension piece to decrease soil erosion.




Figure 9.1. Removal of existing downspout. **Figure 9.2.** Installation of elbow and downspout extension.

Erosion: Landscaped areas where water is directed should be checked during and after a heavy rainfall for any erosion, gullies, scour, or extended standing-water conditions. If erosion occurs, check that concrete splash blocks are in place and that vegetation is actively intercepting runoff.

Vegetation maintenance: Depending on the landscape, plants that were previously unaccustomed to receiving excess runoff may suffer under soggy conditions. In such cases, rain gardens or vegetation that can handle extended periods of wet conditions may need to be used.

POLLUTANT REMOVAL

Impervious surfaces can contribute nonpoint source (NPS) pollutants to stormwater. Through disconnecting downspouts, stormwater is directed to vegetated areas; thus, stormwater pollutants can be treated by plant and soil filtration processes, and runoff quantity is reduced. In slowing and reducing stormwater flows, stream erosion near stormwater outfalls may also be reduced.


REFERENCES

- City of Portland. 209. *How to Manage Stormwater: Downspout Disconnection*. Portland, OR: Environmental Services.
- Department of Environmental Protection, Montgomery County, MD. 2012. *Disconnecting Downspouts*. Accessed on 1/18/12.
- Pennsylvania Department of Environmental Protection. 2012. *Pennsylvania Stormwater Best Management Practices Manual*. Harrisburg, PA: Bureau of Watershed Management.
- Seattle Public Utilities. 209. *Rain Wise: Disconnecting Downspouts from the Sewer System – Safely!* Seattle, WA: Seattle Public Utilities.

APPENDICES

CLOSING THOUGHTS AND APPENDICES

MOVIE 15.1 Closing thoughts.



Appendix A: Stormwater Hydrology

In low impact development (LID), the objective of stormwater control measures (SCMs) is to mimic or replicate the hydrologic function of a natural system. This approach includes the integration of local site conditions, climate, and community with stormwater management to improve resources and quality of life.

By designing SCMs that closely resemble the runoff characteristics of the undeveloped site, the storage, infiltration, and pollutant treatment of a drainage area can be maximized. This is accomplished through the following means, where practical:

- minimizing peak flow runoff and volumes
- removing pollutants
- promoting infiltration in proper soil conditions
 - disconnecting otherwise connected impervious surfaces that drain directly to infrastructure

“Where practical” is very important because, as discussed in the section on Site Selection, the goals and constraints of a site may prevent or be impractical for the construction of some SCMs.

In addition to examining site goals and constraints, stormwater calculations are required in the design of SCMs. These calculations assist a designer in analyzing the effects of proposed stormwater management on hydrology, particularly peak flows and volumes prior to construction.

TABLE A.1. METHODOLOGY FOR STORMWATER CALCULATIONS

CALCULATION	METHOD
Peak flow	Rational method
Runoff volume	Simple method Discrete curve number method
Channel geometry	Manning's equation
Hydraulic performance of standard outlet structures	Weir equation Orifice equation
Storage volume	Stage-storage tables
Pollutant removal	Pollutant removal efficiencies

Traditional stormwater management has always considered water quantity, and the solution has been to pipe stormwater directly to the stream. LID and current stormwater management strategies have evolved to include not only water-quantity treatment and retention to prevent flooding but also pollutant treatment and water-quality improvements.

This appendix focuses on the fundamentals of computing stormwater runoff rates and volumes from rainfall using a variety of mathematical methods and models. This guidance offered includes provisions to control and treat a certain volume of stormwater runoff. Some practices/measures also target the control of peak stormwater discharge rates. Additional calculations are necessary to determine proper treatment capacity. It is up to the designer to determine if the calculations support design requirements. The methodology for stormwater calculations is found in Table A.1.

Designers may adopt different calculation methods; however, the calculation method must meet or exceed the methodology outlined in here. The act of converting rainfall to runoff is complex and variable. Using the equations in this appendix, along with their assumptions and empirical data, you can determine an estimated or predicted runoff. Various methods are used because some of the equations are suitable for large volumes, while others work better for smaller storm events. Furthermore, some methods can be used to determine peak runoff rates, whereas others can determine both volume and peak runoff.

The equations used to calculate these values are presented in the Design sections for each SCM presented in this handbook (see Practice sections); however, in some cases a model or automated program could also be used. Design guidance and examples are provided in this handbook. Due to rounding, your answers may vary.

The equations and methodologies presented are unique because they require limited rainfall and drainage area data. More sophisticated methods and models have broader data requirements that may not be as available for widespread use. A more data-intensive model often will produce a more comprehensive and accurate estimation.

Stormwater hydrology, or the science of stormwater and its interaction with the earth, is often depicted through the image of the hydrologic cycle. Stormwater, or runoff, is the by-product of the interaction of precipitation with the land cover or surface in which it comes into contact. Stormwater runoff is one of many pathways that water may take during the hydrologic cycle. Other pathways include precipitation, evaporation, transpiration from plants, and infiltration into the soil. Due to the relationship between all of these processes, however, when stormwater runoff increases, other processes tend to decrease, causing the cycle to be imbalanced. Rain or precipitation is considered the input of the hydrologic cycle, and runoff or other processes are viewed as outputs. The equations used to calculate runoff are considered in a similar manner. The methods presented here attempt to mathematically simulate processes observed in the hydrologic cycle. These methods treat rainfall as an input and calculate or convert rainfall into runoff volume and/or rate of runoff.

The magnitude, intensity, and frequency of rainfall are all important factors when characterizing the input or design of SCMs. When observing stormwater hydrology or predicting rainfall characteristics for design, the total rainfall that occurs over a particular duration and the likelihood of reoccurrence of the same storm events is very important. The likelihood of its reoccurrence is called the recurrence interval. For instance, a rainfall event that occurs on average once every ten years has an average Recurrence Interval of ten years and is considered a ten-year storm. A storm's recurrence interval can be used to determine the annual probability or the probability of having a given storm event in any given year.

Traditionally, the total amount of rainfall, or runoff volume, for a given storm event has been the primary value of concern. However, a storm event's distribution or intensity variation over a span of time is also of interest, as are the peak rate or

peak runoff. A storm event's duration can vary dramatically. The peak runoff is dependent on both storm intensity and the surface that runoff encounters.

The equations presented compute runoff and address this variability. Methods such as the rational method and the Natural Resources Conservation Service (NRCS) discrete curve number method depend on a hypothetical rain event or the design storm for the rainfall input.

The design storm event is based on a compilation of local, regional, and statewide data recorded over an extended period of time. Using the design storm, a designer assumes existing waterway conditions and average antecedent moisture conditions. Depending on the existing conditions, these average conditions may cause computations to differ from observed current wetter or drier conditions. Hydrologic conditions of the soils in the drainage area as well as the land cover over those soils can also significantly affect both runoff volume and peak runoff. Runoff calculations are impacted by pervious and impervious surfaces, whether those surfaces are connected or disconnected, and the time of concentration or the measure of how quickly or slowly a drainage area responds to rainfall.

The stormwater water-quality design storm for Alabama is the rainfall event used to design structural and nonstructural SCMs. The water-quality design storm has a rainfall depth ranging from 1–1.5 inches depending on geographic location (e.g., coastal locations are 1.5 inches). See Runoff Volume for more information. The design storm can be used to design SCMs based on the rational, simple, and discrete curve number methods. The appropriate SCM selection depends on SCM type and required design data.

MODELING VARIOUS SITE CONDITIONS

Any given drainage area can have a variety of site conditions that affect the analysis and design of SCMs. This guidance, where applicable, is intended for all of the methodologies discussed above for the computation of runoff volumes and peak runoff. For all development sites, a predeveloped land cover must be assumed to be forested and in good hydrologic condition, unless it can be verified that a different land cover has existed for a minimum of five years prior to the analysis.

Sites will typically have a mixture of pervious and impervious surfaces. Impervious surfaces are defined as any surface that does not allow water to penetrate or

infiltrate the surface. Examples of these surfaces include, but are not limited to, roads, roofs, driveways, and parking lots. Impervious surfaces can be considered connected or disconnected. A connected impervious surface is a surface whose runoff drains directly to a pipe, stormwater conveyance network, or other impervious surface. These types of surfaces do not allow for infiltration or treatment of stormwater. Impervious surfaces, particularly directly connected surfaces, should be modeled and runoff calculated using linear methods such as the rational method or the simple method. When using the discrete curve number method to calculate runoff, the impervious and pervious surfaces should be treated separately, calculating runoff from each surface using a weighted average curve number (CN). This is particularly important when calculating runoff for a small rainfall event with rainfall less than two inches, such as the design storm. It is recommended that runoff volumes be computed using a combined weighted average derived by separately calculating runoff from the pervious portions and directly connected impervious portions of the drainage area. For larger storm events and larger rainfall depths, the designer can use his or her discretion as to which technique to use.

PEAK FLOW

When designing practices such as swales, grassed filter strips, and riparian buffers, the calculated flow rate is needed to complete the design. In some states, peak runoff attenuation is required.

The rational method is the primary equation used to calculate peak flow. This method uses an empirical linear equation to compute the peak runoff rate based on a period of uniform rainfall intensity. The rational method uses a composite runoff coefficient, C , which is correlated with runoff potential and is unitless. A value of zero is assigned to a surface with no runoff, and a value of 0.95–1.0 is assigned to completely impervious surfaces. Typically, a range of runoff coefficients is provided for a given land use. The designer must use his or her judgment to select an appropriate runoff coefficient value. Generally, larger areas with flat slopes, permeable soils, and dense vegetation are assigned a runoff

Figure 1. The one-year 24-hour rainfall frequency graph, an example of graphs found in Technical Paper No. 40, “Rainfall Frequency Atlas of the United States for durations from 30 minutes to 24 hours and return periods from 1 to 100 years.”

coefficient from the low end of the range; the opposite is true for small, steep, and impervious areas. Table A.2 shows examples of rational method runoff coefficients.

The precipitation intensity, i , can be determined using the National Oceanic and Atmospheric Administration (NOAA) Technical Memorandum NWS HYDRO-35 “Five- to 60-minute precipitation frequency for the eastern and central United States” published in 1976. The maps found in this document can be used to determine precipitation intensity.


NOAA is in the process of using data stations across the state of Alabama to update precipitation intensity data. NOAA rainfall frequency and intensity data for site-specific locations may currently found at hdsc.nws.noaa.gov/hdsc/pfds/pfds_map_cont.html?bkmrk=al.

EQN A.1

$$Q = CiA$$

C = Composite runoff coefficient (unitless)
 i = Rainfall intensity (in/hr)
 A = Watershed area (ac)
 Q = Estimated design discharge or flow (cfs)

Precipitation intensity can be determined for a given annual return interval or specific storm duration. The technical memorandum has a series of graphs that can be used to determine rainfall intensity and equations for the partial duration



series for selected return periods. Additionally, Technical Paper No. 40, "Rainfall Frequency Atlas of the United States for durations from 30 minutes to 24 hours and return periods from 1 to 100 years," published for the engineering division of the Soil Conservation Service of the U.S. Department of Agriculture and the Department of Commerce, can be used to determine precipitation intensity for smaller-duration storm events (see figure 1).

The rational method is most effective for drainage areas less than 20 acres in size and should be limited to drainage areas that are fairly uniform in land cover/land use and topography.

RUNOFF VOLUME

The majority of SCMs described here are designed as volume control structures. The National Pollutant Discharge Elimination System (NPDES) permit, general permit (ALR100000), for Alabama states that "The permittee is encouraged to design the site, the erosion prevention measures, sediment control measures, and other site management practices with consideration of minimizing stormwater runoff, both during and following construction, including facilitating the use of low-impact development (LID) and green technologies." In order to comply, some volume control is necessary.

In Alabama, the current recommendation is to capture, retain, and infiltrate the "first flush" (first 1–1.5 inches of stormwater) volume within two to four days. The first flush is the initial surface runoff of a rainstorm. This volume of runoff has higher concentrations of pollutants in comparison with runoff later in the storm. By capturing this volume and treating it, we can account for 80 percent of the pollution. There is variation in the volume of water and rainfall depth that represents the first flush. This capture depth ranges from 1–1.5 inches across the state of Alabama, with the coastal plain experiencing a high first-flush runoff depth (1.5 inches).

When designing for the first flush, the SCM is sized to appropriately capture, store, treat, or infiltrate this volume of stormwater. Due to the range of first-flush depths across Alabama, this handbook uses varying first-flush amounts corresponding with site location in the design examples presented. A 1.5" depth is most conservative and sizes SCMs to ensure pollutant capture. Designers should check with the municipality they are working in to confirm an appropriate first-flush depth. To achieve proper design for the capture, retention, and infiltration of this volume,

TABLE A.2. VALUES OF RUNOFF COEFFICIENT (C)* FOR RATIONAL FORMULA

LAND USE	C	LAND USE	C
Business: Downtown areas Neighborhood areas	0.70–0.95 0.50–0.70	Lawns:	
		Sandy soil, flat, 2%	0.05–0.10
		Sandy soil, avg., 2%-7%	0.10–0.15
		Sandy soil, steep, 7%	0.15–0.20
		Heavy soil, flat, 2%	0.13–0.17
		Heavy soil, avg., 2%-7%	0.18–0.22
		Heavy soil, steep, 7%	0.25–0.35
Residential: Single-family areas Multiunits, detached Multiunits, attached Suburban	0.30–0.50 0.40–0.60 0.60–0.75 0.25–0.40	Agricultural land:	
		Bare, packed soil	
		• smooth	0.30–0.60
		• rough	0.20–0.50
		Cultivated rows	
		• heavy soil, no crop	0.30–0.60
		• heavy soil, with crop	0.20–0.50
		• sandy soil, no crop	0.20–0.40
		• sandy soil, with crop	0.10–0.25
		Pasture	
• heavy soil	0.15–0.45		
• sandy soil	0.05–0.25		
• woodlands	0.05–0.25		
Industrial: Light areas Heavy areas	0.50–0.80 0.60–0.90	Streets:	
		Asphaltic	0.70–0.95
		Concrete	0.80–0.95
		Brick	0.70–0.85
Parks, cemeteries	0.10–0.25	Unimproved areas	0.10–0.30
Playgrounds	0.20–0.35	Drives and walks	0.75–0.85
Railroad yard areas	0.20–0.40	Roofs	0.75–0.95

two methods, the simple method and the discrete curve number method, are used to determine the runoff volume for a specific design storm. Runoff volume calculations are intended for site application and the scale of a single site.

The simple method was developed in the late 1980s and, as the name implies, uses minimal site information. Schueler et al. developed the equation by collecting/

TABLE A.3. FOUR HYDROLOGIC SOIL GROUPS

PROPERTIES	
HSG A	Low runoff potential when thoroughly wet; less than 10% clay and more than 90% sand or gravel; have sandy texture.
HSG B	Moderately low runoff potential when thoroughly wet; between 10% and 20% clay and 50% to 90% sand; have loamy sand or sandy loam texture.
HSG C	Moderately high runoff potential when thoroughly wet; between 20% and 40% clay and less than 50% sand; have loam, silt loam, sandy clay loam, clay loam, and silty clay loam textures.
HSG D	High runoff potential when thoroughly wet; greater than 40% clay and less than 50% sand; have clayey textures.

USDA AND NRCS, 2006.

measuring runoff data and plotting the relationship between percent imperviousness and runoff.

The simple method uses two equations to calculate runoff volume:

EQN A.2

$$R_v = 0.05 + 0.9 * I_A$$

R_v = Runoff coefficient, unitless
 I_A = Impervious fraction, unitless

EQN A.3

$$V = 3630 * R_D * R_v * A$$

V = Volume of runoff that must be controlled for the design storm (ft³)
 R_D = Design storm rainfall depth (in) typically 1–1.5"
 A = Area (ac)

Upon determination of the runoff coefficient, the runoff volume can be calculated.

EQN A.4

$$S = \left(\frac{1000}{CN} \right) - 10$$

EQN A.5

$$Q = \frac{[P - (0.2S)]^2}{P + 0.8S}$$

Table A.4. Soil Conservation Service Discrete Curve Numbers

Runoff curve numbers for urban area

* Table A.4 (former 2.2) in Technical Release (TR-55), "Urban Hydrology for Small Watersheds."

Cover description	Average percent impervious area ^{2/}	Curve numbers for hydrologic soil group			
		A	B	C	D
<i>Fully developed urban areas (vegetation established)</i>					
Open space (lawns, parks, golf courses, cemeteries, etc.) ^{3/} :					
Poor condition (grass cover < 50%)		68	79	86	89
Fair condition (grass cover 50% to 75%)		49	69	79	84
Good condition (grass cover > 75%)		39	61	74	80
Impervious areas:					
Paved parking lots, roofs, driveways, etc. (excluding right-of-way)					
		98	98	98	98
Streets and roads:					
Paved; curbs and storm sewers (excluding right-of-way)					
		98	98	98	98
Paved; open ditches (including right-of-way)					
		83	89	92	93
Gravel (including right-of-way)					
		76	85	89	91
Dirt (including right-of-way)					
		72	82	87	89
Western desert urban areas:					
Natural desert landscaping (pervious areas only) ^{4/}					
		63	77	85	88
Artificial desert landscaping (impervious weed barrier, desert shrub with 1- to 2-inch sand or gravel mulch and basin borders)					
		96	96	96	96
Urban districts:					
Commercial and business					
		85	89	92	95
Industrial					
		72	81	88	93
Residential districts by average lot size:					
1/8 acre or less (town houses)					
		65	77	85	92
1/4 acre					
		38	61	75	87
1/3 acre					
		30	57	72	86
1/2 acre					
		25	54	70	85
1 acre					
		20	51	68	84
2 acres					
		12	46	65	82
<i>Developing urban areas</i>					
Newly graded areas (pervious areas only, no vegetation) ^{5/}					
		77	86	91	94
Idle lands (CN's are determined using cover types similar to those in table 2-2c).					

¹ Average runoff condition, and $I_a = 0.2S$.
² The average percent impervious area shown was used to develop the composite CN's. Other assumptions are as follows: impervious areas are directly connected to the drainage system, impervious areas have a CN of 98, and pervious areas are considered equivalent to open space in good hydrologic condition. CN's for other combinations of conditions may be computed using figure 2-3 or 2-4.
³ CN's shown are equivalent to those of pasture. Composite CN's may be computed for other combinations of open space cover type.
⁴ Composite CN's for natural desert landscaping should be computed using figures 2-3 or 2-4 based on the impervious area percentage (CN = 98) and the pervious area CN. The pervious area CN's are assumed equivalent to desert shrub in poor hydrologic condition.
⁵ Composite CN's to use for the design of temporary measures during grading and construction should be computed using figure 2-3 or 2-4 based on the degree of development (impervious area percentage) and the CN's for the newly graded pervious areas.

The discrete curve number method, developed by NRCS, is an excellent fit for designing LID practices. Like the simple method, it uses two equations to calculate runoff. The curve number (CN) is descriptive of the drainage area land use and the characteristics affecting stormwater runoff. The discrete curve number method uses a hypothetical design storm and an empirical nonlinear runoff equation to compute runoff volumes into runoff hydrographs. It is the most widely used method for computing runoff.

Hydrologic soil group (HSG) classifications are crucial in the determination of curve number values. The four hydrologic soil groups are summarized in table A.3. Descriptions of saturated hydraulic conductivity for HSGs can be found in chapter 7 of the USDA and NRCS National Engineering Handbook.

Another characteristic effecting CN is land use or, more specifically, land cover. Impervious surfaces have high runoff potential because, unlike vegetated open space, they have no means of infiltration. Higher runoff potential correlates to a higher CN. A geographic information systems (GIS) can aid in determining land cover as well as site assessments, aerial photography, and land use.

A site usually has more than one land use. The discrete curve number method is applied to each land use separately and summed to determine total stormwater runoff. In some cases, such as the constructed stormwater wetland design example (see section on Constructed Stormwater Wetlands), an area-weighted composite curve number (CCN) can be used. This is called the composite curve number method. Use it only for sites that do not have directly connected impervious surfaces and runoff. Runoff that is not directly connected simply means the runoff is disconnected by passing over a pervious surface, such as a lawn, and allowed to infiltrate.

CHANNEL GEOMETRY

Manning's equation is applicable in determining channel geometry. To justify the use of Manning's steady-state flow, gravitational influences must be assumed. Channel geometry is important to the stability of design with particular regard to erosion and sediment control. Manning's equation is used to calculate channel geometry in the case of a grassed swale or level spreader channel. It is often an iterative process that assumes channel dimensions to calculate the variables of area, wetted perimeter, and hydraulic radius.

Manning's equation:

EQN A.6

$$Q = \frac{1.489}{n} * A * R^{0.667} * S^{0.5}$$

Q - Peak discharge or flow (cfs)
 n = Manning's roughness coefficient (dimensionless)
 A = Cross-sectional area (ft²), typically triangular or trapezoidal
 R = Hydraulic radius (ft)
 S = Longitudinal slope (ft/ft)

The hydraulic radius can be determined using this equation:

EQN A.7

$$R = \frac{A}{P}$$

R = Hydraulic radius (ft)
 A = Cross-sectional area (ft²)
 P = Wetted perimeter (ft)

For detailed equations on the calculation of trapezoidal and triangular channel geometry, refer to *Section 4 on Grassed Swales, Infiltration Swales, and Wet Swales*.

Manning's n is a roughness coefficient assigned to a particular material used to line the design channel, such as grass – n = 0.0312.

HYDRAULIC PERFORMANCE OF STANDARD OUTLET STRUCTURES

The SCM designs presented here are intended to target and treat smaller storm events. These systems require an outlet structure or overflow to bypass larger storm events in order to maintain functionality and to meet safety guidelines. These outlet/overflow components must be considered and properly analyzed to determine how overflow from larger events will exit the system. These devices are usually weirs or orifices. Weirs are used to control exit elevations or to divert flow, whereas orifices are typically used to draw down an SCM detaining stormwater for treatment.

Weir

The broad-crested weir application is most common for practices specified in this handbook. The weir equation:

EQN A.8

$$Q = C_w * L * H^{1.5}$$

Q = Discharge or flow (cfs)
 C_w = Coefficient of discharge (dimensionless),
 3.0 for broad crested weirs
 L = Length of weir (ft)
 H = Driving head (ft)

Orifice

For most applications in this handbook, an orifice is used to control the release of a designed volume of stormwater over an increased time interval. The primary orifice equation:

EQN A.9

$$Q = C_D * A * \sqrt{2 * g * H_o}$$

Q = Discharge of flow (cfs)
C_D = Coefficient of discharge (dimensionless, default value is a
A = Cross-sectional area of flow at the orifice (sq ft)
g = Acceleration of Gravity (32.2 ft/s²)
H_o = Driving head (ft) - measured at the centroid of the orifice to the water surface

STORAGE VOLUME

Many of the SCMs outlined here do not have the capability to provide volume control. SCMs such as bioretention design include a storage volume allowing for some volume control, but the primary function of the SCM is water-quality treatment not water quantity. Each SCM chapter includes the specific calculations for meeting volume control; however, certain SCMs such as constructed stormwater wetlands, involve stormwater detention. These SCMs are designed to provide volume control for the design storm in temporary storage. For SCMs that involve the detention of stormwater, a stage storage discharge model is used to determine this relationship for proper design. Examples of models that may be used include, but are not limited to, HEC-HMS, WinTR-55, SWIMM, and HydroCAD.

POLLUTANT REMOVAL

Within each SCM section there is a discussion of pollutant removal and a table of specified values for each specific SCM according to other jurisdictions. Alabama currently does not assign a specific removal rate of pollutants for each SCM; however, estimated pollutant removal for a designed practice can be assumed using the values found in the pollutant removal table for each practice. In some instances, a municipal entity or a total maximum daily load (TMDL) may require a designer to use a practice that meets a specific pollutant removal standard, such as 85 percent removal of total suspended solids (TSS). To calculate nutrient removal, an approved removal efficiency can be multiplied by the pollutant loading in the influent to determine the pollutant loading in the effluent (typically in lb/ac/yr).

Pollutant removal can be calculated for each SCM. A given site may include multiple drainage areas and multiple SCMs; however, the overall site must meet the regulatory requirements set forth in the NPDES permit for quantity and quality. If multiple SCMs are used for the same drainage area, they may be weighted to meet the removal requirement of the overall site. For SCMs that do not provide direct input into another SCM, the SCMs can be considered in parallel. A flow-weighted removal proportional to the individual removal rate and the fraction of total flow passing through each SCM can be calculated to determine the site's pollutant removal efficiency. Volumes treated for SCMs in parallel are summed for a total volume treated for the site. For SCMs that are placed in a treatment train, or in a series, and capture the same drainage area, volume control as well as removal efficiency can be combined. However, the removal efficiencies are not additive.

The following equation can be used to calculate combined removal efficiency for a given site utilizing a treatment train:

EQN A.10

$$Q = SCM_1 + SCM_2 - \left[\frac{(SCM_1 * SCM_2)}{100} \right]$$

E = Total pollutant removal efficiency (%)
SCM₁ = Efficiency of first SCM
SCM₂ = Efficiency of second SCM

In cases where the treatment train includes more than two SCMs, the equations can be applied iteratively.

REFERENCES

- New Jersey Department of Environmental Protection Division of Watershed Management. 2004. *Best Management Practices Manual*. Trenton, NJ.
- North Carolina Department of the Environment and Natural Resources. 2006. "Stormwater Calculations" (ch. revised 2009). *Stormwater Best Management Practices Manual*. Raleigh, NC: North Carolina Division of Water Quality.
- United States Department of Agriculture and Natural Resources Conservation Service. 2006. "Hydrologic Soil Groups." Part 630 *Hydrology In National Engineering Handbook*. Accessed July 5, 2017. directives.sc.egov.usda.gov/OpenNonWebContent.aspx?content=17756.wba.
- United States Department of Agriculture and Natural Resources Conservation Service 19812. *Urban Hydrology for Small Watersheds*. Technical Release 55 (TR-55).

Appendix B: Community Planning Resources

Excerpted from Auburn, AL, Model Stream Buffer Ordinance.

Section 412. Natural Resource Protection Standards.

- A. All residential and nonresidential development shall be preceded by the identification of any environmental or natural feature described in Sections 413 through 420 and shall meet the specified standards of environmental protection.
- B. Site alterations, regrading, filling and clearing or planting vegetation prior to approval of the subdivision plats and/or site plans for development shall be a violation of this Ordinance. Reference in this section to “open space” is intended to mean the term as it is defined by Article II and described in Section 421.

Section 413. Stream Buffer.

413.01. Purpose. The purpose of this Section is to establish minimal acceptable requirements for the design of buffers to ensure that the stream and adjacent land will fulfill their natural functions; to reduce land development impacts on stream water quality and flows; and to provide for the environmentally sound use of Auburn’s land resources.

413.02. Definitions. For the purpose of this section, the following words or phrases shall be defined as specified below.

- A. *Perennial stream:* See Article II, Definitions—Stream, Perennial
- B. *Intermittent stream:* A stream that flows at least six months out of a year but does not flow during part or all of the summer and may carry water during or after a rainstorm.
- C. *Ephemeral stream:* A stream channel or reach of stream channel that carries surface water runoff for short durations as a result of precipitation events. The channel bottom is always above the groundwater table.
- D. *Best Management Practices (BMPs):* Conservation practices or management measures that control soil loss and reduce water quality degradation caused by nutrients, animal wastes, toxics, sediment, and runoff.

413.03. Streams Determination. Perennial and intermittent streams are identified through site inspection by the City Engineer or his designee and/or US Geological Survey (USGS) maps. Perennial streams are those which are normally depicted on a USGS map with a solid blue line. Intermittent streams are normally depicted on a USGS map with a dotted blue line. Perennial and intermittent streams not identified on the USGS map as described herein may be added to a development site plan by the City Engineer and/or his designee based on the determination by a qualified professional that the stream satisfies the USGS definition for said streams. Ephemeral streams are streams assessed and determined by the City Engineer and/or his designee through stream delineation done on the development site as reported by a qualified professional.

413.04. Buffer description, width, and permitted uses. Stream buffers shall be required on each side of all perennial and intermittent streams as defined in Section 413.02 and further described in Section 413.03. Stream buffers width shall vary based on the size of the upstream drainage basin. Table 4.31 specifies the buffer required based on the drainage area for a particular stream above the most downstream point on the development being considered. The USGS 7.5 minute 1”:2000’ quadrangle maps, in conjunction with the Soil Survey Maps of Lee County and the City of Auburn Geographic Information System (GIS), will serve as tools to delineate the size of drainage basins and specify the corresponding buffer width.

The stream buffer is comprised of three zones: *Streamside Zone, Managed Use Zone, and Upland Zone.* Buffer zones’ function, vegetation and permitted uses vary by zone as described in the Table 4.32.

TABLE 4.31

Stream Buffer Width Based on Drainage Area

Drainage Area (Watershed) Designation	Streamside Zone	Managed Use Zone	Upland Zone	Total Buffer Width on each side of Stream
< 100 acres	25 feet	None	10 feet	35 feet
≥ 100 acres	25 feet	None	20 feet	45 feet
≥ 300 acres	25 feet	20 feet	10 feet	55 feet
≥ 640 acres	25 feet	50 feet	25 feet	100 feet

If an ephemeral stream remains after construction has been completed, and all or a portion of that stream falls within the stream buffer of an intermittent or perennial stream, then that ephemeral stream shall be revegetated on both sides of the stream in accordance with the targeted vegetation of the corresponding buffer zone. Appropriate stream bank stabilization measures shall be designed if warranted by excessive velocities in the ephemeral stream. If the ephemeral stream remains after construction and falls outside of an intermittent/perennial stream buffer, then that ephemeral stream shall be grassed and/or revegetated in accordance with the surrounding vegetation at a width of 25 feet on each side of the ephemeral stream. Ephemeral stream channels and banks shall be stabilized as appropriate for the predicted stream velocities. These measures are performed in order to preserve and protect water quality.

TABLE 4.32

Stream Buffer Description and Permitted Uses

Characteristics	Streamside	Managed Use Zone	Upland Zone
Function	Protects the physical and ecological integrity of the stream ecosystem	Protects key components of the stream and provides distance between upland development and the streamside zone	Prevents encroachment and filter runoff from residential and commercial development
Vegetative Target	Undisturbed natural vegetation	Mature vegetation and native trees; exotic vegetation and underbrush may be removed and maintained	Lawns, gardens, shrubs, and pervious landscaping features
Uses	<u>Very restricted-</u> Permitted uses limited to: flood control structures, utility easements*, natural footpaths, crossings and approaches for paved roadways, and pedestrian paths and bikeways.	<u>Restricted-</u> Permitted uses limited to: all uses allowed in the Streamside Zone as well as storm water best management practices (BMPs), biking and hiking paths (with natural or pervious surfaces), greenway trails, and limited tree clearing approved by the City Engineer.	<u>Restricted-</u> Permitted uses limited to: all uses allowed in the Streamside and Managed Use Zones, as well as, grading for lawns, gardens, and gazebos and accessory structures. No septic systems, principal structures or impervious surfaces are allowed.

**As deemed necessary and approved by the City Engineer*

413.05. Applicability. The buffer requirements shall apply to all perennial and intermittent streams defined in Section 413.02. Buffer widths for streams are measured horizontally on a line perpendicular to the surface water, landward from the top of the bank on each side of the stream. The top of bank is the landward edge of the stream channel during high water or bank full conditions at the point where the water leaves the stream channel and begins to overflow onto the floodplain.

All properties shall be subject to the buffer width requirements except those properties that are an existing lot of record and/or included on an approved preliminary subdivision plat and the lot or lots cannot meet the requirements described in this Section. (*Effective date 5/02/06 pursuant to Ordinance Number 2389*)

413.06. Minimize Intrusion. Any uses allowed in Table 4.32 shall be designed and constructed to minimize the amount of intrusion into the stream buffer and to minimize clearing, grading, erosion, and water quality degradation.

413.07. Land in the Stream Buffer. Land in stream buffers shall not be used for principal structures. All new platted lots shall be designed to provide sufficient land outside of the stream buffer to accommodate primary structures. Stream buffers should be delineated before streets and lots are laid out to minimize buffer intrusion and to assure adequate buildable area on each platted lot.

Land within the stream buffer can serve to meet the minimum lot size requirements.

413.08. Setback Requirements. For all lots within a development requiring a stream buffer, setbacks can be 100% within the stream buffer.

413.09. Buffer Impact. When the application of the buffer zones would result in the loss of buildable area on a lot (See Section 203 for definition of "lot") that was recorded prior to the amendment of this ordinance, modifying the width of the buffer zones may be allowed, through an administrative process, as determined by the City Engineer.

Modification and mitigation of the stream buffer width are also available to landowners or developers of newly platted lots or subdivisions where there are exceptional situations or physical conditions on the parcel that pose practical difficulty to its development and restrict the application of the regulations of this ordinance. There must be proof of such circumstances by the landowner.

The landowner or his designated representative proposing any of the impacts shall prepare and submit for approval a written request and a site plan showing the extent of the proposed impact and must specify a proposed mitigation technique. Mitigation techniques are included in Section 413.10.

The City Engineer and other appropriate city staff members shall review and render a decision on any buffer encroachment and mitigation technique with regard to the stream buffer requirements. Amendment to the stream buffer width may be allowed in accordance with the following criteria:

- A. The proposed encroachment and mitigation is in accordance with the purpose and intent of this section of the ordinance.
- B. The proposed lot and structure conforms to all other zoning and development regulations.
- C. Encroachments into the buffer areas shall be the minimum necessary to achieve a reasonable buildable area for a principal structure and necessary utility.
- D. The landowner or his designated representative submitted an acceptable written statement justifying the need for the buffer impact.
- E. The landowner or his designated representative submitted an acceptable mitigation plan in accordance with cited mitigation techniques.

- F. Attention has been given to maintaining natural vegetation and eliminating run-off.

In no case shall the reduced portion of the buffer area be less than the width of the Streamside Zone (25 feet).

413.10. Stream Buffer Mitigation Techniques. The following techniques are available to landowners for mitigation of buffer impact.

- A. *Installation of Structural BMPs.* The installation of an on-site structural BMP (i.e. bioretention, extended detention/retention, rain gardens, stormwater wetlands, etc.) will allow for stream buffer impacts on the specific site. The structural BMP shall be designed to achieve pollutant (nutrients, herbicides, pesticides, sediment and other illicit discharges) removal to the maximum extent practicable. The BMP shall remain outside the Streamside Zone. A detailed BMP design plan must be submitted to the City Engineer for approval along with a long-term maintenance plan.
- B. *Controlled Impervious Surface.* The landowner may commit to and provide a specific site development plan that limits the overall site impervious surface ratio equal to or less than 25%.
- C. *Open Space Development.* The landowner may submit a specific site development plan which preserves an undisturbed, vegetative area on-site or near the development site as open space equal to 200% of the buffer encroachment area. The open space preserved must promote water quality protection.
- D. *Stream Restoration:* The landowner may restore and preserve the buffer area on any stream of equivalent or greater drainage area the condition of which is determined to be qualified for restoration by the City Engineer on a 1:1 basis in linear feet of stream. This restoration shall include stream bank improvements and Streamside and Managed Use Zone re-vegetation.
- E. *Stream Preservation:* The landowner may purchase, fee simple, other stream segments within the city limits at equivalent or greater drainage area on a 1:1 linear foot basis and convey fee simple and absolute title of the land to the City.
- F. *Wetland Restoration:* On a 2:1 acreage basis for disturbed stream and buffer area (2 acres of wetland for each acre of disturbed area), the landowner may provide a combination of the preservation and/or restoration of wetlands with protective easements, and the implementation of structural or non-structural BMPs to achieve pollutant removal to the maximum extent practicable.
- G. *Greenways:* The landowner may allocate and donate open space within the city limits through fee simple to the City of Auburn for preservation and use as common open space.
- H. *Wider Buffer Widths:* A developer may add additional widths to buffer areas where encroachment occurs in other areas on a development site and may obtain an acre for acre credit based on the stream buffer zone impacted. A 2:1 credit could be obtained by determination of the City Engineer in the event additional streamside buffer is set aside for encroachment of the managed use and upland stream buffer zones.
- I. *Other Mitigation Techniques:* Other creative mitigation techniques and plans may be considered by the City Engineer.

413.11. Vegetation Preservation. The buffer shall provide for the preservation and enhancement of natural vegetation or planting. No live vegetation may be removed from the Streamside and Managed Use Zones for preparation of land for uses permitted in Table 4.32 unless approved by the City Engineer.

Additional information on the Auburn, AL ordinances may be found at the following link: www.auburnalabama.org.

The City Engineer may grant approval of the removal of exotic vegetation (i.e. privet, kudzu, etc.) provided that a vegetation restoration plan is submitted and approved prior to the disturbance of the vegetation. The purpose of such plan is to ensure that native vegetation is restored to the Streamside Zone.

Where a developer or lot owner removes live vegetation from the buffer strip, in violation of this section, the City Engineer shall require native vegetation of reasonable diameter in size to be planted so as to create a buffer area which is in compliance with this section. A vegetation restoration plan must be submitted and approved by the City Engineer prior to restoration.

413.12. Vegetation Restoration Plan. A vegetation restoration plan shall include the following information:

- A. Scaled map of lot showing buffer delineation (copy of the survey is acceptable).
- B. Square footage of the actual area disturbed or proposed disturbed area.
- C. Proposed vegetation to be removed from the buffer.
- D. Proposed location, number, and species of plants to be planted in the disturbed area (See list of plant species).
- E. Type of ground cover to be placed in the disturbed area (i.e. mulch, pine straw, etc.).
- F. Proposed planting schedule and deadline for completion of restoration activities.

413.13. Buffer Delineation. The following buffer delineations are required:

- A. Stream boundaries including each buffer zone must be clearly delineated on all grading plans, subdivision plats, site plans and any other development plans.
- B. The outside boundaries of the *Managed Use Zone* of the stream buffer must be clearly marked on-site by flagging or fencing prior to land disturbing activities.
- C. The outside boundary of the *Managed Use Zone* must be permanently marked at highway stream crossings.
- D. Stream and buffer boundaries including the delineation of each buffer zone must be specified on all surveys and recorded plats and noted on individual deeds.
- E. Stream buffer requirements must be referenced in homeowners association documents.

413.14. Approved Permits. Where a landowner or his representative obtain permits from Alabama Department of Environmental Management (ADEM) or the U. S. Army Corp of Engineers for proposed impact to the stream or stream buffers then these approved mitigation impacts and plans would supersede the applicable requirements of these sections of the ordinance. The regulations that these permits do not affect shall be applicable to the proposed development site.

Auburn, AL Model Conservation Subdivision Ordinance

G. Design Standards for Conservation Subdivisions

1. Dimensional Standards:

Each lot shall have frontage on a public street.

Minimum Lot Area: The minimum lot size is as follows:

Within the Watershed:

Option 1: *Conservation Subdivision*

Minimum lot size for lots without sewer-- 1.5 acres

Minimum lot size for lots with sewer --- 10,890 square feet

Option 2: *Conventional Subdivision*

Minimum lot size for lots without sewer-- 3 acres

Minimum lot size for lots with sewer --- Same as the minimum lot size for specified for the underlying zoning district.

Outside the Watershed:

There is no minimum lot size requirement outside the watershed area. However, the density allowed by the underlying zoning district or specified in these regulations limits the maximum site density.

Minimum Lot Width: 50 feet

Minimum Yards:

Front /Side Street: 20 feet (*porch is included*)

Side: 10 feet

Rear: 20 feet

2. Maximum impervious surface: The overall impervious surface ratio (ISR) of a conservation subdivision in the Lake Ogletree Subwatershed should not exceed 10 percent of the gross area. If the ISR must exceed 10 percent, then appropriate stormwater Best Management Practices (BMPs) shall be incorporated on the development site outside the required Open Space (See Item 8 under this section).

Outside the watershed areas, the overall ISR shall be determined by the underlying zoning district. If the development site is located outside the watershed but within the planning jurisdiction, there shall be no ISR requirement.

3. Street Design

Street Width: Minimum right-of-way (ROW) widths, measured from lot line to lot line; and minimum street width, measured from back-of-curb to back-of-curb, shall be as follows:

Design Factor*	Alley (one way)	Local	Cul-de-Sac	Residential Loop One Way/Two Way
B/C to B/C Width	Not Required	26 feet	26 feet	15 feet/27 feet
Pavement Width	11 feet	22 feet	22 feet	11 feet/22 feet
ROW	25 feet	50 feet	50 feet	varies
Minimum centerline radius	100 feet	200 feet	200 feet	100 feet
Maximum Grade	15%	5%/15%	5%/15%	5%/15%
Design Speed	15 mph	25 mph	25 mph	15 mph
Sidewalk Location	Not Required	Optional/Pervious	Optional/Pervious	Optional/Pervious
Public/Private	Public/Private	Public	Public	Public

*Curb and gutter required where profile grades exceed 5%

All other street classifications shall conform to design requirements found in Article IV, Section C.

Street Layout: The use of interconnected streets and alleys shall be used throughout the development site. Street design such as loop streets is preferred to the use of cul-de-sacs.

4. **Cul-de-sac Streets:** Cul-de-sacs shall be permitted where topographic features or configuration of property boundaries prevent street connections. In such cases, a planter island shall be incorporated in the center of the terminus. The planter island shall have a minimum radius of 20 feet and shall be reinforced with a mountable rolled curb, at a minimum. Other alternatives to the cul-de-sac shall include an eyebrow or crescent with an island and a one-way loop (See Figure 1).

5. **Shared Driveway:** Common/shared driveways are encouraged to reduce impervious surface. All shared driveways must be constructed in accordance with standards approved by the City Engineer.

6. **Sidewalk/Trail System:** Sidewalks shall be installed along one side of the street within a conservation subdivision. Pedestrian trails shall also be permitted in a conservation subdivision. Sidewalks or trails must provide pedestrian access to all existing and planned bicycle and/or greenway networks that run through and adjacent to the development site.

Trails shall be planned, designed and constructed to avoid or minimize degradation of natural resources. Trails shall be soft-surface except where necessary to prevent erosion and/or resource damage. To the extent possible, trails shall provide for pedestrian, bicycle, and/or other non-motorized uses.

All trails and sidewalks shall be designed in accordance with current American Association of State Highway & Transportation Officials (AASHTO) standards. Sidewalks and trails may be constructed of pervious concrete and other porous materials provided the runoff through the material will not be directed towards the subgrade of the traveled lane portion of a roadway. Sidewalks shall be no less than four feet in width.

The City may consider the installation of an alternating sidewalk/trail system in lieu of sidewalks. Such system must incorporate well-connected sidewalks and trails that link each residential lot with on-site open space, recreational facilities, and other amenities within the development site. A sidewalk/trail plan for the entire development site must be submitted to the City Engineer for approval. The plan shall include a map depicting the proposed location of all sidewalks and trails throughout the development site. The plan shall be submitted with initial set of construction plans for the proposed development site.

7. Other Design Standards

See Article IV, Design Standards, for other street, sidewalk, block and lot standards.

8. Stormwater Treatment Design Standards.

Within the Lake Ogletree Subwatershed, each development site overall impervious surface ratio (ISR) should not exceed 10 percent of the gross area. Stormwater Best Management Practices (BMPs) shall be required for water quality control if the total ISR is projected to exceed 10 percent for the development site. For development sites with an ISR above 10 percent, stormwater treatment BMPs shall be designed and installed in a manner to achieve the targeted pollutant removal efficiencies found in the City of Auburn Engineering Design Manual.

Outside the watershed areas, the overall ISR shall be determined by the underlying zoning district. If the development site is located outside the watershed but within the planning jurisdiction, there shall be no ISR requirement.

The applicant shall submit a Stormwater Management Plan if the total ISR for the development site is projected to exceed 10 percent. The focus of this plan is to describe how the site will be developed in order to achieve the pollutant target removal efficiencies found in manual. The project engineer shall prepare the stormwater plan that includes a water quality/water quantity report, a water quality site development analysis, the location of all structural and nonstructural stormwater treatment BMPs, procedures for implementing non-structural stormwater treatment practices along with a proper maintenance plan. All stormwater management measures shall be incorporated into the design of the conservation subdivision. Stormwater BMP measures shall be designed in accordance with standards outlined in the City of Auburn Engineering Design Manual. The manual includes design standards and target pollutant removal efficiencies for a variety of stormwater BMPs. See of the manual for further details on BMP design guidelines.

The maintenance plan shall contain specific preventative maintenance tasks and an inspection schedule of all stormwater management techniques installed on the development site. The name of a person or persons responsible for preventative and corrective maintenance (including replacement) of the stormwater BMP techniques shall be stated in the maintenance plan. If the maintenance plan identifies a person other than the developer as having the responsibility for maintenance, the plan shall include documentation of such person's agreement to assume this responsibility. Responsibility for maintenance shall not be assigned or transferred to an owner of individual property within a conservation subdivision development, unless such owner owns the entire development.

The Stormwater Management Plan shall be reviewed as a part of the subdivision plat review process and must be submitted with the construction plans.

ARTICLE VI- ARTICLE VII. ADMINISTRATION

APPENDIX

How to Design a Conservation Subdivision

A conservation subdivision should be designed in accordance with the following suggested process:

1. Identify all Potential Conservation Areas. Determine which areas will be designated as primary and secondary conservation areas and note these areas as permanent open space. This delineation will help identify where the areas for development are located on the development site.
2. Location of House Sites. Draw the house footprint outside the conservation areas based on the permitted density calculations. House sites should generally be located to enjoy views of the conservation areas but should not be in close proximity to pose negative impacts on these areas. As a general rule, house sites should be at least 100 feet from any Primary Conservation Areas.
3. Alignment of Streets and Trails. Streets should be designed to provide vehicular access to each house and bear a logical relationship to topographical conditions. Streets should be designed outside the conservation areas; however, trails can be located within these areas (See Section E (3)(c)).
4. Drawing the Lot Lines. The final step of the process is to draw the lot lines.

Figure 1 is an illustration of the four-step conservation subdivision design process.

All persons who desire shall have an opportunity of being heard in opposition to or in favor of such ordinance.

Publication Date: Sunday, January 21, 2007

Additional information on the Daphne, AL Ordinances may be found at the following link.
<http://www.daphneal.com/residents/community-development/documents-information/>

Daphne, AL Model Land Use & Subdivision Ordinance

**ARTICLE I
PURPOSE, REPEALS, ENACTMENT AND SHORT TITLE**

1-1 PURPOSE

The City of Daphne, Alabama, pursuant to the authority granted by Title 11, Subtitle 2, Chapter 52, Articles 1 through 4, Code of Alabama, 1975 and 1986 Cumulative Supplement, in order to promote the health, safety, convenience, order, prosperity, and general welfare of the residents; to lessen congestion in the street; to secure safety from fire, panic, and other dangers; to provide adequate light and air; to prevent the overcrowding of land, to avoid undue concentration of population; to facilitate the adequate provision of transportation, water, sewerage, and parks; to facilitate initiation of the Comprehensive Plan, and other public requirements, hereby ordains and enacts into law an official Land Use and Development Ordinance in accordance with the laws of Alabama. In their interpretation and application, the provisions of this Ordinance shall be:

- (a) Considered as minimum requirements.
- (b) Liberally construed in favor of the governing body.
- (c) Deemed to neither limit nor repeal any other powers granted under state statutes.

1-2 REPEALS AND ENACTMENT

An Ordinance of the City of Daphne establishing rules and regulations for zoning, platting, and subdividing land which rules and regulations define the legal authority; classify land; establish zoning districts requirements; prescribe procedures for plat review; set standards and specifications for streets, utilities, and other public improvements in subdivisions; and, prescribe methods for enforcement, exceptions, and amendments.

1-3 SHORT TITLE

This Ordinance shall be known and may be cited as the "Land Use and Development Ordinance" for the City of Daphne.

**ARTICLE II
LEGAL STATUS**

2-1 AUTHORITY

The rules and regulations set forth herein are hereby adopted in accordance with Title 11, Subtitle 2, Chapter 52, Articles 1 through 4 of the Code of Alabama, 1975, (as amended), and 1986 Cumulative Supplement are as follows:

- (a) Zoning:
Zoning authority is specifically contained in Title 11, Subtitle 2, Chapter 52, Articles 1 and 4 of the Code of Alabama, 1975, (as amended), and 1986 Cumulative Supplement.
- (b) Subdivisions:
Subdivision authority is specifically contained in Title 11, Subtitle 2, Chapter 52, Articles 1, 2, and 3 of the Code of Alabama, 1975, (as amended), and 1986 Cumulative Supplement.

2-2 JURISDICTION

- (a) Zoning:
This Ordinance shall be in force and effect for zoning purposes within the corporate limits of the City of Daphne as presently or hereinafter established.
- (b) Subdivisions:
This Ordinance shall be in force and effect for the subdivision of all land which is situated inside the corporate limits of the City of Daphne, as well as, all land which lies in the extraterritorial planning jurisdiction of the City of Daphne, as presently or hereinafter established.

**ARTICLE III
OFFICIAL PLANS AND MAPS**

3-1 IMPLEMENTATION

This Ordinance shall be implemented in accordance with the Comprehensive Plan. A copy of the plan is filed in the office of the City Clerk and Zoning Administrator and/or Director of Community Development.

3-2 FUTURE LAND USE MAP

The Future Land Use Map as contained in the Comprehensive Plan shall serve as a guide for the future development of Daphne. To the extent practical, it shall be followed in the administration of this Ordinance.

3-3 OFFICIAL ZONING DISTRICT MAP

The Future Land Use Map as contained in the Comprehensive Plan, as well as all official maps, are to be utilized and construed only as visual aids for the City and/or any of its Departments, agencies, or Commissions in the furtherance of City duties and goals and are not solely to be relied upon by any party.

The Zoning District Map, Exhibit A, the latest edition, is hereby adopted and made a part of this Ordinance. It shall be filed in the office of the Zoning Administrator and/or Director of Community Development and the City Clerk to show thereon the date of adoption of said Ordinance. All Official maps shall be used as a tool in determining the permissible use of land. Zoning should always be verified by Zoning Administrator or Director of Community Development.

3-4 AMENDMENTS TO THE OFFICIAL ZONING DISTRICT MAP

If, in accordance with the provisions herein, revisions are made in the zoning district boundaries or any other information portrayed on the Zoning District Map, changes shall be made on the Map immediately following the amendment and upon approval of the City Council. Unauthorized alterations to Zoning District Map shall be considered a violation of this Ordinance and subject to penalties as prescribed herein.

3-5 FILE OF PROPERTIES REZONED, VARIANCES GRANTED, SUBDIVISIONS APPROVED

The Zoning Administrator and/or Director of Community Development shall maintain a file or registry of properties rezoned, variances granted, and subdivisions approved under the authority of this Ordinance in conjunction with all pertinent requirements and/or conditions thereto.

3-6 OFFICIAL OLDE TOWNE DISTRICT MAP

The Olde Towne District Map, Exhibit B, the latest edition, is hereby adopted and made a part of this Ordinance. This map shall be signed by the Mayor and attested by the City Clerk. It shall be filed in the office of the Zoning Administrator and/or Director of Community Development and the City Clerk to show thereon the date of adoption of said Ordinance.

3-7 AMENDMENTS TO THE OFFICIAL OLDE TOWNE DISTRICT MAP

If, in accordance with the provisions herein, revisions are made in the district boundaries or any other information portrayed on the Olde Towne District Map, changes shall be made on the Map immediately following the amendment and upon approval of the City Council. Unauthorized alterations to the Olde Towne District Map shall be considered a violation of this Ordinance and subject to penalties as prescribed herein.

3-8 OTHER OFFICIAL MAPS

The Official Street Map, Exhibit A-2, the latest edition, is hereby adopted and made a part of this Ordinance. The Village Overlay District Map, Exhibit C, the latest edition, is hereby adopted and made a part of this Ordinance. The Official Eastern Shore District Overlay Map, Exhibit D, the latest edition, is hereby adopted and made a part of this Ordinance. The Residential High Rise District Boundary Map, Exhibit E, latest edition, is hereby adopted and made a part of this Ordinance. The Jubilee Retail Overlay District Map, Exhibit F, latest edition, is hereby adopted and made a part of this Ordinance.

3-9 AMENDMENTS TO THE OFFICIAL MAPS

If, in accordance with the provisions herein, revisions are made in the zoning district boundaries or any other information portrayed on the Village Overlay District Map, the Official Eastern Shore District Overlay Map, or the Official Street Map, the Residential High Rise District Boundary Map or the Jubilee Retail Overlay District Map, changes shall be made on the individual map immediately following the amendment and upon Official Maps shall be considered a violation of this Ordinance and subject to penalties as prescribed herein.

1 GENERAL PROVISIONS

1.1 Authority

These regulations are enacted in accordance with the authority granted to the Semmes Planning Commission by the Legislature of the State of Alabama in Title 11, Chapter 52, Code of Alabama, 1975, as amended.

1.2 Jurisdiction

From and after the date of legal adoption and certification to the Probate Judge of Mobile County, Alabama as required by Law, these regulations shall govern each and every subdivision of land within the Semmes corporate limits and expanding 5 miles outside the corporate limits. The 5 mile extra-territorial jurisdiction is subject to change as a result of the following actions:

- 1. Annexations
- 2. Jurisdictional agreements entered into with neighboring authorities.

1.3 Purpose

The purpose of these regulations is to establish procedures and guidelines for the development of subdivisions or proposed additions to existing subdivisions within the planning jurisdiction of Semmes, Alabama, in order to regulate the size of lots, the planning and provide for appropriate design and construction of infrastructure and other public facilities. It is the intent of these regulations to harmoniously relate the development of the various tracks of land to the existing community and to obtain the best design possible for each tract of land being subdivided while promoting the public health, safety, economy, good order, appearance, convenience and general welfare within the planning jurisdiction of Semmes.

The Subdivision Regulations are also designed to be used by the Planning Commission to attempt to keep the area compatible with current overall ambience of the area. The purpose of these subdivision regulations is to promote the health, safety, morals, and general welfare of present and future residents alike. It is also the purpose of these regulations to promote coordinated, ecologically sensitive, and aesthetic development in the City of Semmes and its jurisdiction in accordance with the Comprehensive Plan and all other plans and programs adopted by the City. The regulations shall achieve:

- 1. Govern the subdivision of land within its jurisdiction.

City of Semmes

2. Provide for the proper arrangement of streets in relation to other existing or planned streets in accordance with the Comprehensive Plan.
3. Provide adequate open space and provisions for traffic.
4. Provide adequate open space and provisions for utilities.
5. Provide adequate open space and access for fire-fighting apparatus.
6. Provide adequate open space and provisions for recreation.
7. Provide adequate open space and provisions for light and air.
8. Provide minimum standards to avoid congestion of population.
9. Provide appropriate standards for the grading and improvement of streets, water and sewer, other utilities, and other facilities.
10. Establishment of minimum requirements and procedures to control the adverse effects of increased storm water runoff associated with both future land development and existing developed land. Proper management of storm water will minimize damage to public and private property, ensure a functional drainage system, reduce the effects of development on land and stream channel erosion, assist in the attainment and maintenance of water quality standards, enhance the local environment associated with the drainage system, reduce local flooding, maintain as nearly as possible the pre-developed runoff characteristics of the area, and facilitate economic development while mitigating associated flooding and drainage impacts.
11. Promote good civic design and arrangement in accordance with the Comprehensive Plan.

1.4 Policy

It is hereby declared to be the policy of the **City of Semmes** to consider the subdivisions of land and the subsequent development of the subdivided land as subject to the control of the **Semmes Planning Commission** pursuant to the authority granted to the City by Alabama Law.

Any owner of land which lies within the area of jurisdiction of the City of Semmes who wishes to subdivide or re-subdivide such land into two (2) or more lots, parcels, plats, or other divisions of land for the purpose of sale (whether immediate or future), transfer, or lease of lots for building development, shall submit to the City of Semmes Planning Commission a plat of the subdivision which shall conform to the established requirements set forth in these regulations.

City of Semmes

No subdivider shall proceed with any improvements or with the installation of utilities in a proposed subdivision until such subdivision plat shall have been reviewed and approved by the City of Semmes Planning Commission.

These regulations shall hereafter be known, cited and referred to as the Subdivision Regulations of the City of Semmes, Alabama.

1.5 Application of Regulations

No subdivider shall proceed with the sale, transfer, or lease of lots, or the erection of buildings, excluding required public improvements and utility structures, within a proposed subdivision until such subdivision has been granted Final Plat approval entered in writing on the plat and signed by the City Engineer, the Chair of the City of Semmes Planning Commission and the Mobile County Engineer (if subdivision is located within the extraterritorial jurisdiction of the City of Semmes) and recorded in the Office of the Probate Judge of Mobile County in accordance with the procedures prescribed in these regulations. Any changes that are required by Mobile County Engineering prior to their Final Plat approval must also be re-routed through the Semmes City Engineer and the Chair of the Semmes Planning Commission for signatures before recording with the Office of the Probate Judge of Mobile County.

1.6 Interpretation

In their interpretation and application, the provisions of these regulations shall be held to be the established requirements for the protection of our rural character and promotion of the public health, safety, and general welfare of our citizens. Where any provision of these regulations impose restrictions different from those imposed by any other provision of these regulations, or any other ordinance, rule or regulation, or other provisions of law, whichever provisions are more restrictive or impose higher standards shall control.

The City of Semmes Definitions of Words as Phrases as amended from time to time and approved by the City shall provide the meanings of all words and phrases in this document. It is hereby adopted by reference.

1.7 Minimum Standards:

The provisions and requirements of these regulations shall be considered minimum standards. There may be cases in the course of subdivision consideration and approval that due to the site characteristics meeting minimum standards may not adequately protect local and public property, residents, public infrastructure, public investment, and the life and safety of the City. Therefore, it is the designer's responsibility to exceed minimum requirements as necessary. Additionally, the City and its staff reserve the right to require that minimum standards are exceeded based on professional judgment and professional engineering standards.

City of Semmes

1.8 Responsibilities:

Responsibility of Subdivider:

The subdivider shall be responsible for providing all engineering services, including plans and specifications in conformity with these regulations and construction observation inspection and supervision as is necessary to assure that improvements are installed in conformity with plans, city standards and the requirements of these regulations. The subdivider shall provide the City with all engineering plans required in conjunction with any applicable state, federal or local laws or regulations. Where the Planning Commission deems additional or supplemental engineering data to be necessary for the purpose of assuring the City's interests are protected, all costs shall be borne by the subdivider. The subdivider is responsible for payment of all fees and charges in full.

Responsibility of the City of Semmes:

The City shall, after final plat approval, plat recording and upon receipt of all test reports, maintenance surety, as-built plans and certification and other requirements of these regulations, by resolution of the City Council accept the streets and drainage within the public right-of-way for maintenance. The City Council shall only accept for public maintenance the right-of-ways that are located within the corporate limits of the City of Semmes, Alabama, as may be amended from time to time. The City may cause the inspection of any or all parts of the improvements during and after construction and require the correction of any improvements for maintenance.

Table B.1

Extract from Low Impact Development Manual for Southern California

LEED for New Construction and Major Renovations Credit Options

Category	Credit Number	Credit Name	Points Possible	Possible LID BMP
Sustainable Sites	5.1	Site Development, Protect or Restore Habitat	1	Appropriate native plant selection, protect sensitive areas
	5.2	Site Development, Maximize Open Space	1	Minimize construction footprint
	6.1	Stormwater Design, Quantity Control	1	Multiple LID BMPs
	6.2	Stormwater Design, Quality Control	1	Multiple LID BMPs
	7.1	Heat Island Effect, Non-roof	1	Shade from trees, light colored pervious paving
	7.2	Heat Island Effect, Roof	1	Vegetated roof
Water Efficiency	1.1	Water Efficient Landscaping, Reduce by 50%	2	Rain barrels, cisterns, select appropriate plant species
	1.2	Water Efficient Landscaping, No Potable Use or No Irrigation	4	Soil amendments, capture/reuse
	2.1	Innovative Wastewater Technologies, Reduce potable by 50%	2	Capture/reuse
	3.1	Water Use Reduction, 30% Reduction	2	Capture/reuse
	3.2	Water Use Reduction, 35% Reduction	3	Capture/reuse
	3.3	Water Use Reduction, 40% Reduction	4	Capture/reuse
	3.1	Material Reuse, 5%	1	Multiple LID BMPs
Materials & Resources	3.2	Material Reuse, 10%	1	Multiple LID BMPs
	4.1	Recycled Content, 10%	1	Multiple LID BMPs
	4.2	Recycled Content, 20%	1	Multiple LID BMPs
	5.1	Regional Materials, 10%	1	Multiple LID BMPs
	5.2	Regional Materials, 20%	1	Multiple LID BMPs
Total Possible Points:			22	

Source: Low Impact Development Center, Inc. Low Impact Development Manual for Southern California: Technical Guidance and Site Planning Strategies. 2010. World Wide Web. Last accessed: Feb. 13, 2013. <http://www.casqa.org/LID/SoCalLID/tabid/218/Default.aspx>

Table B.2

Extract from Low Impact Development Manual for Southern California

LEED for Neighborhood Development Credit Options

Category	Credit Number	Credit Name	Points Possible	Possible LID BMP/Strategy
Smart Location & Linkage	8.1	Steep Slope Protection	1	Vegetated swales, native plants
	9.1	Site Design for Habitat or Wetland Conservation	1	Native plants, infiltration basins, dry ponds, constructed wetlands
	10.1	Restoration of Habitat or Wetlands	1	Restore vegetation
	11.1	Conservation Management of Habitat or Wetlands	1	Preserve existing vegetation and sensitive areas
Neighborhood Pattern & Design	1.1	Compact Development	1-7	Minimize impervious areas
	6.1	Reduced Parking Footprint	2	Decrease size of parking spaces, pervious pavement
	7.1	Walkable Streets	4-8	Planting trees, curb bump-outs
	12.1	Access to Open Spaces	1	Minimize impervious areas
	13.1	Access to Active Spaces	1	Minimize impervious areas
	15.1	Community Outreach and Involvement	1	Informative signs on public LID structures, meetings

Source: Low Impact Development Center, Inc. Low Impact Development Manual for Southern California: Technical Guidance and Site Planning Strategies. 2010. World Wide Web. Last accessed: Feb. 13, 2013. <http://www.casqa.org/LID/SoCalLID/tabid/218/Default.aspx>

Table B.3

Extract from Low Impact Development Manual for Southern California

Sustainable Sites Initiative Prerequisite and Credit Options.

Category	Credit Number	Credit Name	Points Possible	Possible LID BMP/Strategy
Site Selection	Prerequisite 1.2	Protect floodplain functions		Protect sensitive areas
	Prerequisite 1.3	Preserve wetlands		Protect sensitive areas
	Prerequisite 1.4	Preserve threatened or endangered species and their habitats		Protect sensitive areas
	Credit 1.5	Select brownfields or greyfields for redevelopment	5-10	LID can be used on these sites
	Credit 1.6	Select sites within existing communities	6	LID can be used for redevelopment
	Credit 1.7	Select sites that encourage non-motorized transportation and use of public transit	5	LID can be used for redevelopment
Pre-Design Assessment and Planning	Prerequisite 2.1	Conduct a pre-design site assessment and explore opportunities for site sustainability		LID site assessment process
	Prerequisite 2.2	Use an integrated site development process		LID site planning strategies
Site Design – Water	Prerequisite 3.1	Reduce potable water use for landscape irrigation by 50 percent from established baseline		Plant adapted vegetation Capture/reuse
	Credit 3.2	Reduce potable water use for landscape irrigation by 75 percent or more from established baseline	2-5	Plant adapted vegetation Capture/reuse
	Credit 3.3	Protect and restore riparian, wetland, and shoreline buffers	3-8	Protect sensitive areas
	Credit 3.5	Manage stormwater on site	5-10	Multiple LID BMPs
	Credit 3.6	Protect and enhance on-site water resources and receiving water quality	3-9	Multiple LID BMPs
	Credit 3.7	Design rainwater/stormwater features to provide a landscape amenity	1-3	Multiple LID BMPs
	Credit 3.8	Maintain water features to conserve water and other resources	1-4	Multiple LID BMPs

Low Impact Development Center, Inc. Low Impact Development Manual for Southern California: Technical Guidance and Site Planning Strategies. 2010. World Wide Web. Last accessed: Feb. 13, 2013. <http://www.casqa.org/LID/SoCalLID/tabid/218/Default.aspx>

Sustainable Sites Initiative Prerequisite and Credit Options--Continued

Category	Credit Number	Credit Name	Points Possible	Possible LID BMP/Strategy
Site Design – Soil and Vegetation	Prerequisite 4.2	Use appropriate, non-invasive plants		Revegetate disturbed areas
	Prerequisite 4.3	Create a soil management plan		Amend soils
	Credit 4.4	Minimize soil disturbance in design and construction	6	Minimize impervious areas Minimize construction footprint
	Credit 4.5	Preserve all vegetation designated as special status	5	Protect existing vegetation
	Credit 4.6	Preserve or restore appropriate plant biomass on site	3-8	Protect existing vegetation Revegetate disturbed areas
	Credit 4.7	Use native plants	1-4	Revegetate disturbed areas
Site Design – Soil and Vegetation	Credit 4.8	Preserve plant communities native to the ecoregion	2-6	Protect existing vegetation
	Credit 4.9	Restore plant communities native to the ecoregion	1-5	Revegetate disturbed areas
	Credit 4.10	Use vegetation to minimize building heating requirements	2-4	Vegetated roofs
	Credit 4.11	Use vegetation to minimize building cooling requirements	2-5	Vegetated roofs
	Credit 4.12	Reduce urban heat island effects	3-5	Minimize impervious areas Vegetated roofs Light-colored pervious pavement
Site Design – Materials Selection	Credit 5.2	Maintain on-site structures, hardscape, and landscape amenities	1-4	Minimize impervious areas
Site Design – Human Health and Well-Being	Credit 6.7	Provide views of vegetation and quiet outdoor spaces for mental restoration	3-4	Multiple LID BMPs
	Credit 6.8	Provide outdoor spaces for social interaction	3	Vegetated roofs
Monitoring and Innovation	Credit 9.2	Innovation in site design	8	LID Site Design Process
Total Possible Points:			127	

Appendix: C

Maintenance

Plan for maintenance: Maintenance practices, equipment needed, and manpower should be well thought out prior to designing any stormwater control measure (SCM). Planning for regular inspection and maintenance of an SCM is crucial to the long-term effectiveness and aesthetics of each practice. Maintenance tasks often take a back seat until it is too late and the practice is failing.

The right message: Maintenance of SCMs is especially important. When a practice performs poorly or looks bad, it sends the wrong message to municipal officials and employees, developers, and the general public. Practices left unmaintained can discourage communities from adopting these practices and can pose a safety concern. Instead, these practices should encourage and inspire watershed and environmental stewardship.

Maintenance access: Obtain maintenance easements prior to design of the practice. Include the SCM footprint and at least 10 feet surrounding the SCM. The maintenance access area may need to be larger for tasks such as sediment removal from a forebay. These activities require use of heavy equipment and a maintenance roadway.

SCM footprint: The SCM footprint includes the SCM, side slopes, forebay or other pretreatment device, outlet, riser structure, dam embankment, and emergency spillway.

Maintenance easement ownership: Maintenance easements are typically owned by the entity that owns the SCM. Privately owned maintenance easements should allow for public inspection and maintenance, if necessary. Private entities may include an individual, homeowners association (HOA), or a corporation.

Maintenance agreements: Maintenance agreements are completed to guarantee appropriate and timely maintenance of these practices.

Maintenance agreements should include the following:

- maintenance schedule including tasks, frequency, and equipment recommendations
- responsible parties for any professional or nonprofessional maintenance tasks to be performed on-site
- any special maintenance concerns, constraints, or site-specific information that will aid the maintenance professional
- SCM components that require inspection
- problems specific to the SCM that may be encountered
- recommendations for problems that may occur

Nonprofessional maintenance: Basic maintenance tasks such as mowing, trash removal, or mulch replenishment can be performed by nonprofessionals and can be included in grounds maintenance for the overall property.

Professional maintenance: Professional maintenance refers to tasks that require professional judgment such as inspections of riser structures, dam embankments, outlets, or plant health. Professional engineers, Certified Professionals in Erosion and Sediment Control (CPESC), professional landscape architects, horticulturalists, and other specialists should be consulted for recommendations. Repairing eroded areas, grading, and any soil-disturbing activities are best left to maintenance professionals since these tasks can significantly affect SCM function.

Record keeping: Keeping maintenance records is extremely important to identify effective maintenance strategies and to define site-specific maintenance task frequency. Keep records or data sheets in the same location. Maintenance task lists or checklists are most effective to ensure consistency in record keeping and inspection. Note any maintenance performed or recommended as a result of the inspection. Also add maintenance repairs to the inspection task list so they may be regularly evaluated for performance.

Maintenance professional education: Workshops or training sessions with the party responsible for maintenance are strongly recommended. Some maintenance divisions experience frequent turnover, and annual trainings are helpful to introduce new maintenance procedures and to educate new employees.

Maintenance expenses: Maintenance expenses are driven by the condition of the drainage area upstream or upslope of the SCM. High sediment loads entering the SCM increase maintenance frequency and expense. As such, stabilization and any erosion repair upslope reduces the maintenance cost of the SCM.

Funding options: Funding mechanisms, such as an escrow account, can be set up to collect fees for regularly performed maintenance. For example, in a conservation subdivision with multiple SCMs, a developer may start the escrow and then transfer it to the HOA so that regular contributions fund routine maintenance or any SCM reconstruction.

Sample Access and Maintenance Easement Agreement

DEVELOPMENT REVIEW
Town of Cary
PO Box 8005, Cary, NC 27512

NORTH CAROLINA

WAKE COUNTY

STORMWATER CONTROL STRUCTURE AND ACCESS EASEMENT AND AGREEMENT (Corporate)

THIS STORMWATER CONTROL STRUCTURE AND ACCESS EASEMENT AND AGREEMENT, made this day 1 of 1, 191, (**DATE OF AGREEMENT**) by 2 (**NAME OF OWNER**), a North Carolina corporation whose principal address is 2a, (hereafter "Grantor"), with, to, and for the benefit of the Town of Cary, a municipal corporation of the State of North Carolina, whose address is P.O. Box 8005, Cary North Carolina 27512-8005 (hereinafter "Grantee" or "Town").

WITNESSETH:

WHEREAS, Grantor is the owner in fee simple of certain real property, situated in the Town of Cary, County of Wake, North Carolina and more particularly described as follows:

3 (LEGAL DESCRIPTION OF PROPERTY)

It being the same land conveyed to the Grantor by deed recorded in Book 3a at page 3a in the Office of the Register of Deeds for Wake County (hereafter referred to as "Property"); and

WHEREAS, the property is located within the planning jurisdiction of the Town of Cary, and is subject to certain requirements set forth in the Land Development Ordinance of the Town, (hereafter "Cary LDO"), as such may be amended from time to time; and

WHEREAS, one of the conditions for development of Property is the granting or dedication of a Stormwater Control Structure easement, which includes the implementation of certain stormwater practices such as, but not limited to, the construction, operation and maintenance of engineered stormwater control structure(s) as provided in Cary LDO; the dedication of an access easement for inspection and

maintenance of the Stormwater Control Structure easement area and engineered structures; and the assumption by Grantor of certain specified maintenance and repair responsibilities; and

WHEREAS, this Easement and Agreement has been procured in accordance with the requirements of N.C. G.S. Sec 143-211 *et. seq.* and Chapter 4, Part 4.6 of the Cary LDO.

NOW, THEREFORE, for a valuable consideration, including the benefits Grantor may derive therefrom, the receipt of which is hereby acknowledged, Grantor has dedicated, bargained and conveyed and by these presents does hereby dedicate bargain, sell, grant and convey unto the Grantee, its successors and assigns, a perpetual, and irrevocable right and easement in, on, over, under, through and across Property (1) for a STORMWATER CONTROL STRUCTURE easement ("hereafter SCS Easement") of the nature and character and to the extent hereinafter set forth, more particularly shown and described on Attachment 4 (**NAME OF AS BUILT DRAWING**) which is attached hereto and incorporated herein by reference; upon which Grantor shall construct, maintain, repair and reconstruct stormwater control structure(s), including detention pond(s), pipes and water control structures, berms and dikes, and shall establish and maintain vegetative filters and groundcovers; and (2) an access easement more particularly shown and described on Attachment 4a (**ATTACHMENT NUMBER 1 OR 2**), , for the purpose of permitting Town inspection and, if necessary, maintenance and repair of the SCS Easement and engineered structure(s) as more fully set forth herein and in Cary LDO.

The terms, conditions, and restrictions of the Stormwater Control Structure Easement and Access Easement are:

1. The requirements pertaining to the SCS Easement are more fully set forth in Chapter Chapter 4, Part 4.6 of Cary LDO and the "Operation and Maintenance Manual for 5 (hereafter "Operations and Maintenance Manual"), Cary, NC, prepared by 5a, and dated 5b a copy of which is on file in the Town of Cary Engineering Department. Grantor further agrees Grantor shall perform the following, all at its sole cost and expense:

- I. Monthly or after every runoff producing rainfall, whichever comes first:
 - a. Remove debris from trash rack.
 - b. Check and clear orifice of any obstructions.
 - c. Check pond side slopes; remove trash, repair eroded areas before next rainfall.

replacements to the engineered stormwater control structure(s) and appurtenances and conditions as may be necessary or convenient thereto in the event Grantor defaults in its obligations and to recover from Grantor the cost thereof, and in addition to other rights and remedies available to it, to enforce by proceedings at law or in equity the rights, covenants, duties, and other obligations herein imposed.

The Grantor shall in all other respects remain the fee owner of Property and area subject to these easements, and may make all lawful uses of Property not inconsistent with these easements.

The Grantee does not waive or forfeit the right to take action to ensure compliance with the terms, conditions and purposes of this Easement and Agreement by a prior failure to act.

The Grantor agrees that the terms, conditions and restrictions of this easement will be inserted by Grantor in any subsequent deed or other legal instrument by which he divests himself of either the fee simple title to or possessory interests in the subject property. The designation Grantor and Grantee shall include the parties, their heirs, successors and assigns.

TO HAVE AND TO HOLD the aforesaid rights, privileges, and easements herein granted to the Grantee, its successors and assigns forever and the same Grantor does covenant and that Grantor is seized of said premises in fee and has the right to convey the same, that except as set forth below the same are free from encumbrances and that Grantor will warrant and defend the said title to the same against claims of all persons whosoever.

The covenants agreed hereto and the conditions imposed herein shall be binding upon the Grantor and its agents, personal representatives, heirs and assigns and all other successors to Grantor in interest and shall continue as a servitude running in perpetuity with the above described land.

IN WITNESS WHEREOF, the Grantor has caused this instrument to be signed in its corporate name by its duly authorized officers and its seal to be hereunto affixed by authority of its Board of Directors, the day and year first above written.

7
(Grantor)

7a
7b President

Attest:

7c

Secretary (Corporate Seal)

NORTH CAROLINA
WAKE COUNTY

I, the undersigned Notary Public, do hereby certify and State aforesaid, do hereby certify that _____ personally appeared before me this day and acknowledged the execution of the foregoing instrument.

Witness my hand and official seal this __ day of _____, 19__.

My commission expires: _____

Notary Public

[Official Seal]

ckc
Easement&Deed/Corporate.doc

REFERENCES

North Carolina Department of the Environment and Natural Resources. 2006. Chapter 7:
“BMP Inspection and Maintenance.”

Appendix D: Vegetation and Alabama Native Plant List

Native plant lists for low impact development (LID) practices are located in each chapter along with planting density suggestions and design ideas where appropriate. This appendix explores common characteristics and helpful hints in getting to know why and what species are included in this handbook.

Native plants are recommended for use in LID practices for both practical and ecological reasons. Alabama native plants are indigenous to the Southeast and occur in the wild without human interaction. This handbook makes use of the United States Department of Agriculture (USDA) plant database (www.plants.usda.gov) to categorize plant species as native or nonnative. Plant selection is often specific to goals of the site and practice. For example, aesthetics and plant availability combined with sunlight and water requirements may limit the use of native plant species for a specific site. In general, native plants are recommended for LID practices, but nonnative plants are acceptable as long as they are not considered to be invasive.



Figure D.1. Muhly grass in rain garden at Donald E. Davis Arboretum, Auburn, AL.

NUTRIENT REMOVAL

Plants used in LID practices absorb nutrients in stormwater runoff to reduce pollutant loads. Nutrient removal through plant uptake is generally a secondary form of pollutant removal for LID practices. The primary form of pollutant removal occurs through microbial (biological) activity or chemical processes in the soil or growing substrate. As such, the rhizosphere should provide adequate habitat for microorganisms to reduce nutrient loads. A mixture of evergreen and deciduous vegetation is recommended for year-round nutrient uptake.

Nutrient release: Concerns have been expressed over nutrients released from plants or discharged back into systems at the end of the growing season when plants undergo dormancy, especially in constructed stormwater wetlands. If this is a concern, consider using herbaceous perennials, since these plants can effectively be harvested to remove nutrient-laden plant tissues at the end of the growing season. New tissue will be produced and arise from the root ball the following spring.

DESIGN CONSIDERATIONS

Planning: Client preferences for each project site can determine plant sizes and types, which can limit plant choices for particular sites. For example, if visibility is a concern, plant selection may be limited to low-growing vegetation. Sunlight and hydrologic conditions present on-site may also create constraints. Making a list of constraints for the project site and the LID practice you are considering is useful to outline characteristics of plants required. In some cases, native plant species are unavailable or do not fit the site goals, and using ornamental nonnative plants is acceptable as long as they are not invasive.

Plant spacing: Always base plant spacing on mature plant size. Some plants work well in mass plantings and should be planted on a tighter spacing pattern. Over time, these plants create a dense grouping. Resist the urge to crowd plants; it is more expensive and also leads to competition among plants for water, nutrients, and sunlight. This causes stress and weakens plants, making them more susceptible to insect and disease infestations.

Plant preferences: Specify plants in the LID practice according to their sunlight preference, water inputs, soil type, and drainage. Always group plants based on similar preferences to reduce maintenance costs associated with any type of irrigation needed during establishment and plant replacement. (*For more*

information on planting the right plant in the right place, see the *Alabama Smart Yards Manual* at www.aces.edu/pubs/docs/A/ANR-1359/ANR-1359.pdf).

Vegetation plan: Make a vegetation design for LID to scale to ensure that mature plant sizes are taken into account. (For more information, see section on Bioretention.) Calculating plant quantity is another acceptable form of determining plant placement, although it may not be as precise as a sketch drawn to scale. (See section on Rain Gardens for information on plant quantity calculations.)

PLANT HABIT

For the purpose of this manual, plant habits, or vegetation types, include herbaceous perennials and grasses, succulents, turfgrass, shrubs, and trees.

Herbaceous plants: Herbaceous perennials, grasses, and turfgrass do not form woody tissue; instead they typically have soft, fleshy tissue. Herbaceous plants are dormant during winter months when they die back to ground level. These plants may be short- or long-lived, ranging from several years to decades based on the species.

Woody plants: Trees and shrubs are woody plants that form bark and hold woody plant parts above ground. Trees have a central axis and are at least six feet tall (usually much taller), but shrubs are multistemmed (i.e., branched from the



Figure D.2. Students install plants in bioretention area, Phenix City, AL.

Sun: at least six hours of full sun per day

Part Shade: three to five hours without direct sun per day

Shade: less than two hours of direct sun per day

ground level) and typically smaller than trees. Small trees are less than 20 feet tall. Evergreen is a term that refers to a woody plant that remains green and retains leaves throughout the entire year, which is the opposite of deciduous plants that are leafless during winter months.

INSTALLATION AND ESTABLISHMENT

Installation: Install plants at the top or just above finished soil grade. Plants installed too deeply are at risk for disease such as fungal root rot. Remediating compacted soils by breaking them up and amending with organic matter helps plant roots establish more quickly into the surrounding soil. Mulching is also important to improve water retention in the soil and reduce soil temperatures.

Time of year: Summer plant installations use more irrigation for establishment due to hot weather and low rainfall conditions experienced in Alabama. Fall plantings, on the other hand, allow for root growth over the winter prior to spring shoot flush. Spring planting dates are also acceptable but may require more irrigation until establishment as compared to fall planting.

Irrigation: Water plants immediately after planting to reduce transplant shock, ensure soil contact with root ball, and aid in root growth and establishment.

Establishment: Plant establishment generally occurs in one growing season (or longer, up to three years, under extreme drought) depending on the time of year of installation, environmental conditions, and rate of plant growth. Post-transplant root growth is critical for plant survival. Note: Drought-tolerant plants are not immediately tolerant of dry conditions when planted but will tolerate these conditions once established.

Calibrating irrigation: Calibrating irrigation systems to minimize excess irrigation applications. (See *Alabama Smart Yards manual*, chapter 3).

Turfgrass

Install turfgrass sod as soon as it is delivered, preferably in the early morning before temperatures rise. (Refer to the *Alabama Handbook for Erosion Control*,

Sediment Control and Stormwater Management on Construction Sites and Urban Areas for more information on sod installation.)

Irrigation: For June to September installation, irrigate newly planted turf at planting so that the surface does not dry out. Water sod daily for the first one to two weeks to keep it evenly moist (unless rainfall occurs). As the sod begins to grow new roots, irrigation frequency can be decreased, but a larger volume of water should be applied at each watering. Supplement rainfall so that turfgrass receives about 1–1.5 inches per week from all irrigation sources. Turfgrass sod planted during dormancy requires less irrigation for establishment. In some cases, a dormant planting does not need any supplemental irrigation, because rainfall during these months is sufficient for turf to establish. Dormant plantings, however, may benefit from irrigation during spring months when sod begins to produce new growth (i.e., spring green up).

Type	Time of Year for Install	Advantages	Disadvantages
Plug	Any but summer	<ul style="list-style-type: none"> inexpensive easy to install 	<ul style="list-style-type: none"> limited species availability limited plant nurseries carry them
Bare root	Winter	<ul style="list-style-type: none"> inexpensive reduced irrigation needed because they are installed in the dormant season with typically wet weather conditions less root injury easy to install roots can be inspected at planting 	<ul style="list-style-type: none"> limited plant nurseries carry them limited to winter installation must store in ground or in cooler until planting roots lost or severed in harvest
Container	Any	<ul style="list-style-type: none"> inexpensive reduced irrigation needed because they are installed in the wet season less root injury easy to install roots can be inspected at planting 	<ul style="list-style-type: none"> more expensive require more irrigation especially when installed in warmer months roots may be matted or encircle pots more difficult to install mass plantings
B & B	Any but summer	<ul style="list-style-type: none"> larger trees available can match soil types if bought locally to ease transplant shock 	<ul style="list-style-type: none"> reduced root systems need lots of water

PLANT SIZES

Plant sizes or maturity of plants used in LID practices are usually driven by economics and time of year.

Containers: Container plants are available in a wide variety of sizes; plugs and one- or three-gallon containers are most commonly used. Larger container plants have the advantage of establishing at any time of the year. Because container substrates can dry more quickly in the landscape, irrigation should be concentrated on the root ball after planting.

Plugs: Plugs are usually two- or three-inch pots containing a four-inch-8tall plant. They are most common for herbaceous plants. This size is ideal when large quantities are planted (e.g., constructed stormwater wetland) due to ease of installation. Plugs can be installed at any time of year, but spring is best since these are very young, small plants.

Bare roots: Bare-root seedlings are an inexpensive option for planting woody plants but can only be installed during winter months when plants are dormant. Under the right environmental conditions, establishment and cover of bare-root seedlings is comparable to container plants after several growing seasons. Upon arriving, bare-root seedlings should be inspected for mold and mildew; if roots smell rotten or sour or are powdery, or dry, then the seedlings are likely diseased and should not be planted.

Storing bare roots: Bare-root seedlings can be stored in a cooler or “heeled in” by digging a V-shaped trench in a moist, shady area. A ten-foot-long trench can hold approximately 1,000 seedlings if they are cut out of the bundles and not overcrowded. The ideal temperature range for storing bareroot seedlings is 35–38 degrees Fahrenheit. Completely cover seedling roots by backfilling the trench with soil and then watering. For better plant survival, plant bare-root seedlings before new leaves appear. Planting bars or dibble bars can be used to install bare-root seedlings with nonspreading root systems; plants with spreading root systems should be planted using a round shovel.

Cost: Bare-root seedlings range from \$0.20 to \$0.50 each compared to one-gallon containers, which may range from \$2.50 to \$12.00-plus. Plugs can range from \$0.50 to \$1.00.

SEEDING

Seeding can be utilized for temporary or permanent cover of bare soil. Seed type and species are dependent on time of year and location within the state of Alabama.

Temporary seeding: Temporary seeding for erosion control is mandatory on bare soil during construction. Follow the guidelines set forth in the Alabama Handbook for Erosion Control, Sediment Control and Stormwater Management on Construction Sites and Urban Areas.

Permanent seeding: Permanent seeding can be utilized when immediate stabilization is not required. Permanent seeding may be appropriate for riparian buffers (i.e., in areas where seeds will not be washed away), but seeding is not usually recommended for LID practices that are expected to function immediately after they are installed.

Erosion control blankets: Erosion control blankets, such as coconut or straw blend, are placed over seed and straw to stabilize soil while seeds become established.

Pure live seed: If seeding is chosen as a method of planting, uses pure live seed (PLS) to adjust seeding rates to achieve a desired plant density. Seeding at too high of a density results in competition for water, nutrients, and sunlight, while seeding at low density can result in invasive plant invasion or decreased cover. Pure live seed expresses seed quality and is the percentage of seed per pound of seed applied that has the potential to germinate (excluding inert material and defunct seeds). Most seeding rates are expressed in pounds of PLS per acre; thus the following calculation is necessary.

To calculate pure live seed (PLS):

Pounds PLS = number of pounds / percent live seed

Percent live seed = germination percent – inert material percent

For example, to plant 10 lbs PLS of a species with 80% germination and 10% inert material, 9.3 lbs of seed would be needed to adjust the seeding rate:

$$10\text{lbs PLS} = \frac{10\text{lbs}}{(80\% - 10\%)} = \frac{10\text{lbs}}{0.70} = 14.3\text{lbs}$$

For more information on seeding and erosion control blankets, see the *Alabama Handbook for Erosion Control, Sediment Control and Stormwater management on Construction Sites and Urban Areas* at: <http://conservealabama.gov/uploads/general/2014-ESC-Handbook-Vol-1.pdf>

NATIVE PLANT BENEFITS

There are a number of advantages to choosing native plants:

- They encourage diversity of insects, wildlife, and other plants.
- They are adapted to local environmental conditions and are considered to be low maintenance.
- They require less pruning.
- They can persist under drought conditions once established.
- They tend to withstand lower water inputs because they are adapted to the local climate and precipitation patterns of a given area.
- Local or already acclimated native plant seedlings perform better.




Figure D.3. Purple coneflower attracts native insects, Waverly, AL.

Wildlife habitat: Plants are sources of food and shelter for wildlife. Birds, small mammals, and other wildlife consume plant fruits and seeds; thus, animal populations are directly related to diversity of plant communities. Shelter is provided both in and under tree and shrub canopies, with taller native grasses providing ground-roaming small mammals with overhead cover to travel protected from predators and weather. Native plants are the preferred host for bees, butterflies, and moths. They are easy to establish, low maintenance once established, and serve as hosts to native insect communities.

Invasive plants: Invasive plants should never be intentionally planted or introduced into landscapes. Unfortunately, most invasive plant species have been introduced through the ornamental plant trade and may go unnoticed as problematic for decades or until the negative ecological impacts can no longer be ignored. For example, Chinese privet (*Ligustrum sinense*) was introduced in the 1850s to the United States as an ornamental hedge from China; today, Chinese privet has become naturalized throughout the Southeast and threatens riparian ecosystems.

Homeowners are often surprised when plants become invasive in their own landscapes or when they find these plants have escaped to their neighbor's yard. Invasive plants are able to thrive in a variety of conditions, such as land disturbance, low nutrient availability, herbivory, grazing, available water, and sunlight exposure, making them prone to outcompete native plants.

Many nonnative plants become invasive in the United States because their native insects and natural enemies are no longer present to keep them in check. Invasive plants alter plant communities and successional patterns through competition and displacement of native plant species. Other negative consequences include habitat loss, breeding-site loss, and alterations to food webs. Invasive plants spread easily through suckering roots, abiotic (wind or water) and biotic (by animals) seed dispersal, and through other methods of self-propagation, which make these species difficult to control. (*For more information on controlling invasive plants see Invasive Plant Removal.*)

PLANTS FOR LOW IMPACT DEVELOPMENT

Once established, plants in LID practices should require little maintenance. Turfgrass in pretreatment areas or as part of the LID practice require some mowing during the growing season. This frequency is site-specific and depends on preferred aesthetics. Native plants are recommended in LID practices because they are low maintenance, sustainable, and already adapted to environmental conditions experienced in these practices. All plants need irrigation until established or if there is a severe drought; but once established, LID plants should rely solely on stormwater received.

Sustainability: Native herbaceous perennial plants are sustainable because they usually reseed themselves or spread by vegetative offsets to maintain landscape cover over time. Although native seed plantings may be slow to establish and more expensive compared to nonnative plants, their persistence makes them a cost-effective choice.

Wildlife value: Some LID practices have high wildlife value, provide habitat, and have the added benefit of serving as wildlife corridors that allow for microcosms of plant and animal diversity. These areas provide links between undeveloped land and developed land to balance ecosystems in the face of urbanization and expansion to connect otherwise fragmented native forested areas and landscapes.

Cultivars: Many nurseries may grow native plant cultivars instead of the original plant species because that is what the market currently demands. One criticism is that cultivars of native plants have been mass-produced and lack any genetic diversity. Consider goals of the site or project to determine whether a straight species or a cultivar is appropriate. In a constructed stormwater wetland, genetic diversity and species richness can be prioritized to enhance habitat, insect, and animal diversity. In commercial or residential settings, however, native plant cultivars may be preferred due to specific ornamental qualities they possess. Practices such as bioretention areas, rain gardens, or swales may also utilize a cultivar due to sight or sizing constraints of the site.

Screening plants: Plant trials or screenings of vegetation in Alabama LID practices are advised to provide sound plant recommendations. Specific soil types and textures, as well as local microclimates on-site, may affect performance of vegetation.

DROUGHT TOLERANCE

In addition to experiencing repeated flood events in LID practices, plants may be exposed to extended periods of drying in practices such as bioretention, swales, and rain gardens, to name a few. LID vegetation should provide evaporative cooling effects as well as maintain plant growth and vigor.

Visual quality: Many LID practices are in high-visibility areas, especially in municipal, commercial, or residential community settings; therefore, plants in these practices need to maintain visual quality. Drought-tolerant plants have the ability to maintain photosynthesis and transpiration during a drought. This allows them to continue to efficiently produce carbohydrates necessary for growth, which correlates to plant survival and recovery following a drought.

Evapotranspiration: Evapotranspiration is the combination of water lost from the soil through atmospheric evaporation and water lost from the plant leaves through transpiration. LID emphasizes the importance of evapotranspiration for cooling. It is estimated that about 10 percent of water in the atmosphere is a result of plant transpiration. In an undeveloped watershed, approximately 50 percent of



Figure D.4. American Beautyberry, Smiths Station, AL

precipitation is evapotranspired. In an urbanized watershed only 30 percent is evapotranspired. Thus, the use of LID aims to increase evapotranspiration in urban settings to bridge the gap in evapotranspiration rates.

Transpiration rates: Transpiration rates vary depending on plant species, season, and plant size. During the dormant season, plants do not require as much water; thus, evapotranspiration is decreased. Larger plants use more water than smaller ones. For example, a large oak tree may transpire up to 40,000 gallons of water per year.

Additional information: To ensure that the plants selected are appropriately drought tolerant, consult plant lists in this handbook, review information on plants labels, consider plant books, or look online. Be advised that you may find conflicting information. It is best to seek an information source that is Alabama specific, such as the Alabama Plant Atlas (www.floraofalabama.org/) or the Alabama Cooperative Extension System (www.aces.edu). More information on drought-tolerant plants for Alabama can be found at <http://www.aces.edu/pubs/docs/A/ANR-1336/ANR-13312.pdf>. If you cannot find the information you need from a credible Alabama source, seek information from other southeastern states with reputable plant science or horticulture departments.

FLOOD TOLERANCE

Constructed stormwater wetlands and wet swales require plants that are tolerant of flooded conditions.

Flood stress: Under flooded conditions, oxygen is decreased because soil pores fill with water. Oxygen is slow to diffuse in water; this causes an oxygen deficiency resulting in anaerobic (without oxygen) soil conditions. The length of time necessary for anaerobic conditions to occur varies from several hours to a few days and is dependent on temperature, amount of organic materials in the substrate to be consumed by microbes, and the chemical demand of ions in the soil.

Anaerobic conditions: Anaerobic conditions are particularly harmful because oxygen is required for root respiration to maintain healthy root tissue and produce new root growth. When oxygen is absent, ions present in the soil are reduced and can be toxic to plants. Wetland plants and flood-tolerant plant species adapt to these conditions to transfer oxygen to roots. In doing so, these plants produce oxidized linings around their roots to protect them from reduced ions that may be toxic.



Figure D.12. Aquatic plants in a wet swale, Auburn, AL.

WETLAND PLANTS

Wetland plants are adapted to low oxygen (hypoxic) or no oxygen (anaerobic) conditions where nonwetland-adapted vegetation would not survive.

Adaptations: Plants acclimated to flooding usually develop some type of physical adaptations such as lenticels, adventitious roots, surface rooting, shallow root systems, pneumatophores (cypress knees), or aerenchyma tissue. Plants may develop shallow root systems or adventitious roots in the top few millimeters of soil to avoid anaerobic conditions in deeper soil layers. The thickness of the aerated surface soil depends on oxygen transfer from the atmosphere to the soil water surface. Adventitious roots grow on lower stems to avoid low-oxygen soil layers and to anchor plants. Most flood-tolerant plants exhibit at least some of these adaptations when planted in a constructed stormwater wetland. It is important to understand that all plants cannot tolerate inundated conditions. (For more information on specific flood-tolerant plants for Alabama, see the vegetation list in the section on Constructed Stormwater Wetlands.)

Aquatic plants: Aquatic plants are used in deep pools of constructed stormwater wetlands. These plants are found growing in areas where standing water is present. Aquatic plants are adapted to living under continuous inundated conditions and grow either partially or totally in water. Similarly to terrestrial plants, aquatic plants require sunlight, water, carbon dioxide, and oxygen. These plants are a valuable source of oxygen and carbohydrates to animals such as fish and other organisms in and around water. Many aquatic plants grow in shallow water and can be separated into three groups: emergent, floating leaf plants, and completely submersed.

Emergent plants: Emergent plants grow in the shallowest water and are rooted in substrate or sediment. Their leaves are held above the water surface. Some examples include pickerelweed, lotus, lizard tail, and arrow arum. Emergent plants are very productive and play a vital role in nutrient cycling and pollutant removal.

Floating leaf plants: Floating leaf plants grow at intermediate water depths and may or may not be rooted in sediment. The entire plant may float. Leaves are held at the water surface. An example is water lily.

Submersed plants: Submersed plants grow completely in the water column and do not have any part exposed to the atmosphere. These plants are rooted in the sediment. An example is pondweed. Submersed plants need clear water to flourish, since suspended sediments in the water column will inhibit light penetration.

Wetland Indicator Status

Wetland indicator status (WIS) can be an excellent guide for moisture conditions preferred by plants in their native habitats. WIS is a helpful designation for plants to define their designation as a hydrophyte, nonhydrophyte, or both. A hydrophyte is defined as a plant that is water loving and flood tolerant. Conversely, a nonhydrophyte does not tolerate waterlogged conditions and is not considered flood tolerant.

The National Wetland Plant List has recently been revised by the U.S. Army Corps of Engineers (USACE) based on these designations:

- **obligate (OBL):** almost always a hydrophyte, rarely in uplands
- **facultative wet (FACW):** usually a hydrophyte, but occasionally found in uplands

- **facultative (FAC):** commonly occurs as either a hydrophyte or nonhydrophyte
- **facultative upland (FACU):** occasionally a hydrophyte but usually occurs in uplands
- **upland (UPL):** rarely a hydrophyte, almost always in uplands

Wetland indicator status lists: These lists are available by ecological region.

There are two lists for Alabama, which are the Eastern Mountains and Piedmont and the Atlantic Gulf Coastal Plains. The Alabama lists can be found at: <http://rsgisias.crrel.usace.army.mil/NWPL/>. These wetland plant designations are included in the Alabama Native Plant List for this handbook found in Appendix D.

For more information, please see the National Wetland Plant List <http://rsgisias.crrel.usace.army.mil/NWPL/>.

Use where appropriate: Constructed stormwater wetlands use plants from each of the wetland indicator status categories due to the different zones of hydrology. Bioretention cells, rain gardens, and bioswales require plants that are both flood and drought tolerant. They may use facultative plants that tolerate alternating hydroperiods in both wetland and nonwetland situations.



Figure D.12. Winterberry holly in Donald E. Davis Arboretum, Auburn, AL.

BOTANICAL NAMES

Each plant is assigned a Latin binomial botanical name consisting of both a genus and specific epithet (collectively known as the species). When ordering plants from a nursery or distributor, refer to plants by their botanical name to reduce the chance of confusion between you and the nursery grower. Referring to plants by their common name is risky since many plants share the same common name; but no two plants share the same botanical name.

Correct citation: The entire botanical name is underlined or italicized. The genus is capitalized; the species is not. An example is *Coreopsis tinctoria*. *Coreopsis* is the genus and has many species within it (e.g., *Coreopsis nana*, *Coreopsis lanceolata*, etc.), but *tinctoria* is the species, and there is only one *Coreopsis tinctoria*. The cultivar name, or common name, follows the species name and is not italicized.

MALE AND FEMALE PLANTS

When a plant species does not produce perfect flowers (both male and female flower parts in the same flower), that plant species is classified as either monoecious or dioecious. Knowing whether a plant is monoecious or dioecious is important when using plants for ornamental fruit characteristics.

Monoecious: Defined as “one house,” monoecious means that male and female flowers occur on the same plant.

Dioecious: Defined as “two houses,” dioecious means that one plant has male flowers (a male plant) and one plant has female flowers (female plant). For dioecious plants, you must have both a male and female plant for pollination, fertilization, and fruit production to occur on female plants.



Figure D.6. Foliar application of herbicide, Auburn, AL.

TABLE D.2. SUMMARY OF CHEMICAL CONTROL MEASURES			
Control Type	Size/Vegetation Type	Equipment	Time
Foliar	< 8' tall nonevergreen woody or herbaceous	Backpack sprayer with metal tip	Midsummer through fall best, but anytime after leaf out is okay
Foliar	< 8' tall woody evergreen or semievergreen	Backpack sprayer with metal tip	Winter
Cut stump or cut stem	> 0.5" diameter stem	Chainsaw, handsaw, or pruning shears and backpack sprayer or pressurized hand sprayer	Anytime, but later summer to fall is best
Basal bark	Any woody vegetation less than 6" to 8" in diameter	Backpack sprayer or handheld pressurized sprayer	Anytime, but late summer to fall is best

(MILLER ET AL., 2010; ENLOE ET AL., 2010)

Ornamental fruit production: When ornamental fruit production is desired for dioecious plants, one or two male plants often are placed out of sight, with female plants placed in front for fruit bearing. For example, *Ilex verticillata* (winterberry holly) needs a male pollinator plant no more than 50 feet away. One male plant is sufficient for ten to 20 female plants. The nursery or grower should be able to provide you with the information necessary to ensure fruit production on dioecious plants.

VEGETATION MAINTENANCE

Pruning

Most plants can be pruned once a year to maintain shape. In some cases, plants may need pruning only every couple of years. Prune shrubs and other flowering plants based on the May Rule.

May Rule: If a plant flowers before May, this means that the plant flowers on old wood; it should be pruned after it flowers. If pruned during the winter, the flower buds are removed; thus, the plant does not flower that year. If a plant flowers after May, it should be pruned during the winter months because flowers are produced on new wood.

Herbaceous plants: Stems and leaves of herbaceous perennials die back to ground level during winter months. Leaving the seed heads or spent flower

heads may enhance visual winter interest and help to encourage seed dispersal, since many herbaceous perennials spread by seed. Birds may also eat plant seeds during the winter months, so letting the seed heads persist can provide a valuable food source.

Mowing

Do not mow immediately following a rain event or when the ground is wet. Mowing under saturated conditions can result in ruts caused by mower wheels or blades. This may inhibit flow patterns, especially in pretreatment areas for SCMs where turfgrass is usually specified. Mowing in wet weather conditions may also cause areas of compaction that decrease functionality and result in reconcentration of diffuse flow.

Native grasses: Native grasses are generally mowed at greater heights once or twice per year to remove dead tissue before new growth occurs in early spring. Native grasses do not perform to their potential if mowed or disturbed too often. Mowing creates favorable conditions for exotic species (turfgrass) to outcompete native warm-season grasses.

Turfgrass: Turfgrass requires mowing at least once a month (every other week is better) during the growing season. A general rule of thumb is never to remove more than one third of the leaf during mowing. Turfgrasses such as bermudagrass are stimulated to grow through mowing and respond well to frequent mowing.

Thatch: The thatch layer in turfgrass is organic matter made up of stems and leaves that have not decomposed. Thatch develops between turfgrass foliage and the underlying soil layer. Thatch accumulation is increased with excess nitrogen application and infrequent mowing. Thatch buildup inhibits water from soaking into soil layers below and can cause turfgrass to mimic an impervious surface, causing runoff. Even when thatch is moistened, it usually remains too wet for healthy grass growth.

Dethatching: The thatch layer can be checked in September or October by using a knife or shovel to remove a piece or plug of grass and soil. Look beneath the turfgrass plants; thatch will be a dark brown to black color and easily distinguished from soil layers. When this layer builds to 0.75 inch or greater, brown patches or spots may be noticeable, and dethatching is necessary. Perform dethatching after spring green up in early summer from May to August using a vertical mower, power rake, or other spring attachment.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	WIS AGCP	WIS EMP	Fall Color	Comments
<i>Acer</i>	<i>barbatum</i>	southern sugar maple	P	D	20'–25'	spring	yellow/green	NL	NL	Y	Yellow fall color; resistant to wind and ice.
<i>Acer</i>	<i>negundo</i>	boxelder	S	W	30'–50'	spring	yellow, green, brown	FAC	FAC	N	Attracts birds and cecropia silkmot; planted widely as a shade tree; fast growing; weak limbs.
<i>Acer</i>	<i>rubrum</i>	red maple	F	W-D	50'–75'	spring	red	FAC	FAC	Y	Buds and young twigs are red/green; fall color.
<i>Acer</i>	<i>saccharinum</i>	silver maple	F-S	W	50'–70'	spring	white, red, yellow	FAC	FACW	Y	Fast growth rate; brittle branch; yellow, brown, to red fall color; attracts cecropia silkmot.
<i>Acer</i>	<i>saccharum</i>	sugar maple	F-P	M	50'–75'	spring	yellow, green, brown	FACU	FACU	Y	Excellent fall color; beautiful, large shade tree.
<i>Achillea</i>	<i>millefolium</i>	common yarrow	F-P	W	24"–36"	spring to summer	white, pink	FACU	FACU	N	Flower heads are compact clusters; fragrant foliage.
<i>Acorus</i>	<i>calamus</i>	sweetflag	F-P	W-M	3'–5'	summer	yellow	OBL	OBL	N	Perennial, rhizomatous, iris-like herb; grass-like.
<i>Actaea</i>	<i>pachypoda</i>	doll's-eyes	P-S	M-W	1'–2'	spring	white	FACU	UPL	N	Small white flowers Apr–May; poisonous white berries Aug–Sep.
<i>Actaea</i>	<i>rubra</i>	red baneberry	P-S	M	1'–3'	spring	white	UPL	UPL	N	A bushy plant with large, highly divided leaves and a short, thick, rounded cluster of small white flowers.
<i>Adiantum</i>	<i>pedatum</i>	maidenhair fern	P-S	M	18"–36"	N/A	N/A	FACU	FAC	N	Tiny fan-shaped, deep blue-green fronds held on black stems.
<i>Aesculus</i>	<i>pavia</i>	red buckeye	S-P	D	10'–20'	spring	red	FACU	FAC	N	Normal for this plant to drop its leaves at the end of summer.
<i>Aesculus</i>	<i>parviflora</i>	bottlebrush buckeye	F-P-S	M	6'–12'	summer	white	NL	NL	N	A mound-shaped thicket-forming shrub with picturesque candelabra-like branching.
<i>Aesculus</i>	<i>sylvatica</i>	painted buckeye	S-P	M	6'–12'	spring	yellow/green	FAC	FAC	N	Large understory shrub in deciduous forests; unique pear shaped fruits.
<i>Aletris</i>	<i>farinosa</i>	colicroot	F	M-D	2.5'–3'	summer	white	FAC	FAC	N	Small, white urn-shaped flowers.
<i>Allium</i>	<i>canadense</i>	wild onion	PS	D	8'–12"	summer	white, pink	FACU	FACU	N	High deer resistance.
<i>Alnus</i>	<i>serrulata</i>	hazel or tag alder	F-P	W	40'	spring	red, green, brown	FACW	OBL	Y	Can fix nitrogen; yellow to red fall color.
<i>Amelanchier</i>	<i>arborea</i>	serviceberry	F-P	M-D	15'–25'	spring	white	FACU	FAC	Y	Yellow/orange/red fall color; white flowers in April.
<i>Amorpha</i>	<i>fruticosa</i>	indigo bush	F-P	M-W	6'–10'	spring to summer	purple and yellow	FACW	FACW	N	Attracts lots of moths and butterflies.
<i>Amsonia</i>	<i>tabernaemontana</i>	bluestar	F-P	M	2'–3'	spring	blue	FACW	FACW	N	Blue showy flowers in May
<i>Anemone</i>	<i>virginiana</i>	thimbleweed	S	M	1'–3'	summer	white	FACU	FACU	N	Lovely large, white flowers followed by fluffy seed heads.
<i>Antennaria</i>	<i>plantaginifolia</i>	pussytoes	F	M	.5-1'	spring to summer	white	NL	NL	N	Forms a low mat of little rosettes of white, woolly leaves.
<i>Apios</i>	<i>americana</i>	groundnut	S	W	vine	summer	red, pink, and purple	FACW	FACW	N	Climbing vine, may take over.
<i>Aquilegia</i>	<i>canadensis</i>	wild columbine	P-S	M-D	1'–2'	spring to summer	red and yellow	FACU	FAC	N	Unique red and yellow flowers attract hummingbirds.
<i>Aralia</i>	<i>spinosa</i>	devil's walkingstick	F-P	M-D	10'–20'	summer	white	FAC	FAC	N	Thorny; 3"–4" clusters of white flowers in summer; birds like berries.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Argemone</i>	<i>albiflora</i>	bluestem pricklypoppy	P	D	1'-3'	spring to summer	white	N	NL	NL	Plant parts toxic to humans.
<i>Arisaema</i>	<i>dracontium</i>	green dragon	P-S	M-D	28"	spring	yellow, green	N	FACW	FACW	Similar to jack in the pulpit; goes dormant midsummer.
<i>Arisaema</i>	<i>triphillum</i>	Jack in the pulpit	P-S	M	12"	spring	green, purple, brown	N	FACW	FACW	Spathe appears Mar-May; red berries late summer, fall.
<i>Aruncus</i>	<i>dioicus</i>	goat's beard	F-P	M	4'-7'	spring	cream	N	FACU	FACU	Feathery plumes of cream-colored flowers rise above foliage.
<i>Aronia</i>	<i>arbutifolia</i>	red chokeberry	F	W-M	5'	spring	white	Y	NL	NL	
<i>Arundinaria</i>	<i>gigantea</i>	giant cane	P-S	M-W	6'-25'	green	spring	N	FACW	FACW	Rarely flowers; wood stems; spreads by rhizomes.
<i>Asarum</i>	<i>canadense</i>	wildginger	P-S	M	6"	spring	red brown to purple	N	UPL	FACU	Evergreen ground cover with heart-shaped glossy leaves.
<i>Asclepias</i>	<i>incarnata</i>	swamp milkweed	F-P	M-W	2'-4'	summer to fall	pink	N	OBL	OBL	Attracts butterflies and hummingbirds.
<i>Asclepias</i>	<i>longifolia</i>	longleaf milkweed	F-P	M-W	1'-2'	summer	white	N	FACW	OBL	Grows from a taproot.
<i>Asclepias</i>	<i>tuberosa</i>	butterfly weed	F	D	1'-2'	summer	orange	N	NL	NL	Clusters of brilliant orange flowers Jun-Aug.
<i>Asimina</i>	<i>parviflora</i>	dwarf paw paw	P	D	6'-8'	spring	maroon	N	FACU	UPL	Maroon axillary flowers in mid-March; high dry sites.
<i>Asimina</i>	<i>triloba</i>	pawpaw	P-S	M	40'	spring	maroon	Y	FAC	FAC	Unique fruit resembles and tastes like banana; light green to yellow fall color; attracts butterflies and moths.
<i>Asplenium</i>	<i>platyneuron</i>	ebony spleenwort	F-P	M	6"-12"	N/A	N/A	N	FACU	FACU	Stalk turns shiny black with age.
<i>Athyrium</i>	<i>filix-femina</i>	ladyfern	S	M-W	18"-24"	N/A	N/A	N	FAC	FAC	Delicate and lacy arching fronds have dark red stems at maturity.
<i>Baccharis</i>	<i>halimifolia</i>	sea myrtle	P	W	6'-12'	summer to fall	white	Y	FAC	FACW	White to green flowers occur in small dense terminal clusters.
<i>Bacopa</i>	<i>monnieri</i>	water hyssop	F-P	M-W	1'	spring	white	N	OBL	OBL	Attracts butterflies.
<i>Baptisia</i>	<i>alba</i>	white wild indigo	F-P	D	2'-4'	spring	white	N	FACU	FACU	Leaves turn black in the fall.
<i>Baptisia</i>	<i>australis</i>	blue indigo	F	M-D	2'-4'	spring/summer	blue-violet	N	NL	FACU	If started from seed, plants will not flower for three years.
<i>Betula</i>	<i>lenta</i>	sweet birch	F-P	M	40'-55'	spring	yellow, green, brown	Y	FACU	FACU	Golden-yellow fall color.
<i>Betula</i>	<i>nigra</i>	river birch	F	M-W	40'-70'	spring	green and brown	Y	FACW	FACW	Modest yellow fall color; seed attracts birds.
<i>Bignonia</i>	<i>capreolata</i>	crossvine	F-P	M	vine	spring	red, yellow	Y	FAC	FAC	Reddish purple fall color.
<i>Boltonia</i>	<i>asteroides</i>	white doll's daisy	P	W	3'-6'	summer/fall	white	N	FACW	FACW	Broad, flat clusters of generally small flower heads.
<i>Botrychium</i>	<i>virginianum</i>	rattlesnake fern	P-S	M	3'	spring/summer	n/a	N	FACU	FACU	Requires more care than other ferns.
<i>Callicarpa</i>	<i>americana</i>	American beautyberry	P	M	3' to 8'	summer	white, pink	N	FACU	FACU	Axillary berries in fall attract more than 40 birds specie.
<i>Calycanthus</i>	<i>floridus</i>	sweetshrub	P-S	M	6'-10'	summer	brown, maroon	N	FACU	FACU	Interesting brown blooms Apr-July.
<i>Camassia</i>	<i>scilloides</i>	wild hyacinth	F-PS	M-D	1'-2'	spring	blue/lavender	N	FACW	FAC	A leafless stem with lavender to blue flowers in an elongated, loose-flowered cluster.
<i>Campanulastrum</i>	<i>americanum</i>	American bellflower	P	M	3'-4'	summer	blue/purple	N	FAC	FACU	Attracts hummingbirds.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Campsis</i>	<i>radicans</i>	trumpet creeper	F	M-D	vine	summer	red, orange, yellow	N	FAC	FAC	A high-climbing, aggressively colonizing woody vine to 35' with showy flowers.
<i>Carex</i>	<i>comosa</i>	bottlebrush sedge	F-P	W	3.5'	summer	green	N	OBL	OBL	Prefers mucky soils; a more cultivated sedge variety that can be used in wet rain gardens.
<i>Carex</i>	<i>crinita</i>	fringed sedge	P	M-W	2'	summer	green	N	FACW	OBL	Grass-like evergreen; seeds eaten by waterfowl; transplants easily.
<i>Carex</i>	<i>lupulina</i>	hop sedge	P	W	3'	summer	green	N	OBL	OBL	Spreads by rhizomes; will grow on the edge of streams or ponds.
<i>Carex</i>	<i>lurida</i>	shallow sedge	F-P	W	2.5'	summer	green/yellow	N	OBL	OBL	Attracts birds.
<i>Carex</i>	<i>stricta</i>	tussock sedge	F	M-W	3'	summer	yellow	N	OBL	OBL	Attracts birds, butterflies, and moths; nesting habitat for rails and snipes.
<i>Carex</i>	<i>tribuloides</i>	blunt broom sedge	F-P	M-W	3'	summer	green and brown	N	FACW	FACW	Tolerates gravelly and mucky substrates.
<i>Carya</i>	<i>cordiformis</i>	bitternut hickory	F-P	M	50'–70'	spring	yellow, green, brown	Y	FAC	FACU	Striking yellow buds; pinnately compound leaves; yellow fall color.
<i>Carya</i>	<i>glabra</i>	pignut hickory	F-S	D	50'–60'	spring	yellow, green, brown	Y	FACU	FACU	Golden yellow fall color; rapid growth rate.
<i>Carya</i>	<i>illinoensis</i>	pecan	F	M	70'–100'	spring	yellow	N	FACU	FACU	The largest of the hickories and one of the most valuable cultivated plants originating in North America.
<i>Carya</i>	<i>ovata</i>	shagbark hickory	F-S	M-D	60'–80'	spring	green, brown	Y	FACU	FACU	Golden yellow fall color.
<i>Carya</i>	<i>tomentosa</i>	mockernut hickory	F-S	M-D	50'–60'	spring	yellow, green, brown	Y	NL	NL	Golden yellow fall color.
<i>Castanea</i>	<i>pumila</i>	chinquapin	F-S	M	20'–25'	spring	white	Y	NL	NL	Slender spikes of strongly scented staminate flowers; yellowish purple fall color.
<i>Catalpa</i>	<i>bignonioides</i>	southern catalpa	P	M	25'–40'	spring	white	N	UPL	FACU	Short, crooked branches with heart-shaped leaves and clustered flowers.
<i>Caulophyllum</i>	<i>thalictroides</i>	blue cohosh	P-S	M-W	1'–3'	spring	green	N	NL	NL	Green flowers Apr–May; blue poisonous berries.
<i>Ceanothus</i>	<i>americanus</i>	New Jersey tea	F-P	D	3'	summer	white	N	NL	NL	Short spikes of tiny white flowers in June.
<i>Celtis</i>	<i>laevigata</i>	sugar hackberry	F-P	M-D	60'–80'	spring	green	N	FACW	FACW	Attracts butterflies and moths.
<i>Celtis</i>	<i>occidentalis</i>	common hackberry	F	M-D	40'–60'	spring	green, brown	N	FACU	FACU	Attracts butterflies and moths.
<i>Cephalanthus</i>	<i>occidentalis</i>	buttonbush	P-S	M-W	6'–12'	summer	white	N	OBL	OBL	Used for live stakes; attracts birds and butterflies.
<i>Cercis</i>	<i>canadensis</i>	eastern redbud	F-S	M-D	20'–30'	spring	pink	N	UPL	FACU	Clusters of rosy/pink flowers (Apr); flowers line branches/trunk.
<i>Chamaecrista</i>	<i>fasciculata</i>	partridge pea	F-P	M-D		summer	yellow	N	FACU	FACU	Seeds are eaten by song and game birds; flowers attract bees and butterflies; an annual that is great used in a mix for stream enhancement projects.
<i>Chasmanthium</i>	<i>latifolium</i>	river oats	P-S	M	2'	summer	green, brown	Y	FAC	FACU	Yellow fall color; perennial grass; clump forming with oat-like flowers.
<i>Chelone</i>	<i>glabra</i>	white turtlehead	F-S	M-W	1'–4'	summer	white	N	OBL	OBL	Terminal clusters of white-and lavender-tinged, two-lipped flowers; attracts butterflies and hummingbirds.
<i>Chelone</i>	<i>lyonii</i>	pink turtlehead	F-P	M-W	24"–30"	summer	pink	N	FACW	FACW	Showy pink flowers July–Sept.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Chionanthus</i>	<i>virginicus</i>	fringetree	F-P	M	12'-20'	spring	white	N	FACU	FAC	Wispy, creamy white fragrant flowers in May.
<i>Chrysogonum</i>	<i>virginianum</i>	green and gold	P-S	M	8"	spring/fall	yellow	N	NL	NL	Yellow flowers contrast green foliage in spring and fall.
<i>Cimicifuga</i>	<i>racemosa</i>	black cohosh	P-S	M	1'-3'	summer/fall	white	N	NL	NL	Slender candle-like clusters of white flowers in summer and fall.
<i>Cirsium</i>	<i>discolor</i>	field thistle	F	D	3'-6'	summer	pink/purple	N	UPL	UPL	Attracts butterflies; seeds attract birds.
<i>Cirsium</i>	<i>muticum</i>	swamp thistle	F	W	2'-7'	summer	pink/purple	N	OBL	OBL	Attracts butterflies.
<i>Cladrastis</i>	<i>kentuckea</i>	yellowwood	F-P	M	30'-50'	spring	white	Y	NL	NL	Clusters of fragrant, white pea-type flowers spring; yellow fall color.
<i>Claytonia</i>	<i>virginica</i>	springbeauty	P	M	4'-12"	spring	white to pink	N	FACU	FAC	Tuber; good in patches.
<i>Clematis</i>	<i>crispa</i>	blue jasmine	F-P	M-W	vine	spring/fall	white, pink, blue, purple	N	FACW	FACW	Usually blooms midspring and again in fall; attracts birds and butterflies.
<i>Clethra</i>	<i>acuminata</i>	cinnamonbark	F-P	M	8'-15'	summer	white	Y	NL	NL	Twisted racines of white lily of the valley-like fragrant flowers; yellow orange fall color.
<i>Clethra</i>	<i>alnifolia</i>	summersweet clethra	F-P	M-W	6'-12'	summer	white to pink	Y	FACW	FAC	Yellow orange fall color.
<i>Cliftonia</i>	<i>monophylla</i>	buckwheat brush	F	W	12'-18'	spring	white to pink	N	OBL	OBL	A thicket-forming shrub with white to pink flower clusters; fragrant flowers; evergreen.
<i>Clinopodium</i>	<i>coccineum</i>	scarlet calamint	F-P	D	1'-3'	spring/summer/fall	red	N	NL	NL	A shrub with wiry stems and showy red flowers.
<i>Commelina</i>	<i>erecta</i>	whitemouth dayflower	P	D	1'-3'	summer/fall	blue	N	FACU	FAC	Attracts bird; will usually lay down if not supported by other plants.
<i>Conoclinium</i>	<i>coelestinum</i>	mistflower	F-P	M	3'	summer to fall	blue-violet	N	FAC	FAC	Very vigorous; can be leggy; attracts birds, bees, and butterflies.
<i>Coreopsis</i>	<i>auriculata</i>	mouse-ear coreopsis	F	M	18"	spring	yellow	N	NL	NL	Rich yellow flower head spring to frost if dead-headed.
<i>Coreopsis</i>	<i>basalis</i>	goldenmane tickseed	F	D	15"	summer	yellow	N	NL	NL	Annual; self sows.
<i>Coreopsis</i>	<i>lanceolata</i>	tickseed	F	M-D	1'-2.5'	spring	yellow	N	UPL	FACU	Best in full sun; will take part shade; attracts butterflies.
<i>Coreopsis</i>	<i>nudata</i>	Georgia tickseed	P	W-M	3'-5'	spring	pink	N	OBL	NL	Notched ray flowers surround a center of small, yellow disk flowers.
<i>Coreopsis</i>	<i>pubescens</i>	star tickseed	F	M	3'-4'	summer	yellow	N	FAC	FACU	Bright golden yellow flowers all summer; perennial.
<i>Coreopsis</i>	<i>tinctoria</i>	golden tickseed	F-P	M	1'-2'	spring	yellow/maroon	N	FAC	FAC	Nectar source for bees and butterflies; birds eat seeds; considered an annual but may perform as a short-lived perennial in some states.
<i>Coreopsis</i>	<i>verticillata</i>	threadleaf coreopsis	S	D	1'-2'	summer	yellow	N	NL	NL	Perennial; spreads by rhizomes; seeds attract birds.
<i>Cornus</i>	<i>alternifolia</i>	pagoda dogwood	P-S	W-D	15'-25'	summer	white	Y	FAC	FAC	Clusters of white flowers (late summer); black berries; dull maroon fall foliage.
<i>Cornus</i>	<i>amomum</i>	silky dogwood	F-S	M-W	6'-10'	summer	white	N	FACW	FACW	Creamy white flowers May-Jun; no fall color.
<i>Cornus</i>	<i>florida</i>	flowering dogwood	F-S	D-M	25'-30'	spring	white	Y	FACU	FACU	White flowers in spring turn into bird-attracting berries; red fall color.
<i>Cornus</i>	<i>foemina</i>	stiff dogwood	P	M-W	20'	spring	white	N	FACW	FACW	Reddish twigs becoming gray with age.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Cotinus</i>	<i>obovatus</i>	American smoke tree	F	D	15'-30'	spring	red, purple	Y	NL	NL	A short trunk; open crown with flower panicles that develop long, red or purple hairlike petioles.
<i>Corylus</i>	<i>americana</i>	American hazelnut	F-S	M	12'-15'	spring	white, green	Y	FACU	FACU	Edible nuts; suckering; fall color varies from deep red to bright yellow.
<i>Crataegus</i>	<i>aestivalis</i>	may hawthorn	P	W	30'-40'	spring	white	N	OBL	NL	Clusters of white flowers followed by edible red fruit.
<i>Crataegus</i>	<i>marshallii</i>	parsley hawthorn	P	D	12'-25'	spring	white	Y	FAC	FAC	Dainty, white, five-petaled blossoms are followed by bright-red, persistent fruits.
<i>Crataegus</i>	<i>phaenopyrum</i>	Washington hawthorn	F-P	M	25'-30'	spring	white	Y	FAC	FAC	White spring flowers; red fall berries; orange/scarlet fall color.
<i>Crataegus</i>	<i>spatulata</i>	littlehip hawthorn	P	M	12'-36'	spring	white	N	FAC	FAC	Slender, thorny branches with clusters of white flowers.
<i>Crinum</i>	<i>americanum</i>	swamp lily	P	W	2'-3'	summer/fall	white	N	OBL	NL	The fragrant flowers are white, sometimes marked with pink on an erect plant that grows in small clumps.
<i>Croton</i>	<i>alabamensis</i>	Alabama croton	P	M	6'-8'	spring	white, yellow	Y	NL	NL	Orange fall color; crushed leaves smell like banana-apple; likes soil rich in organic matter.
<i>Cypripedium</i>	<i>acuale</i>	pink lady's slipper	P-S	M-D	12"	spring to summer	pink	N	FACU	FACU	One of the largest native orchids; found both in low, sandy woods and in higher, rocky woods of mountains.
<i>Cypripedium</i>	<i>calceolus</i>	yellow lady's slipper	F-P	M	6'-12"	spring	yellow	N			Found in boggy areas, not available in the trade.
<i>Cyrilla</i>	<i>racemiflora</i>	swamp titi	S	W	10'-15'	spring to summer	white	Y	FACW	FACW	Starts out as a shrub but eventually grows into a tree; can grow to be up to 30' tall; red fall color; can be evergreen in mild climates.
<i>Decumaria</i>	<i>barbara</i>	wild hydrangea vine	P-S	W	vine	spring to fall	white	N	FACW	OBL	Blooms on new wood and will only bloom when climbing.
<i>Delphinium</i>	<i>carolinianum</i>	blue larkspur	P	D	1'-2'	spring to summer	violet	N	NL	NL	White to pale blue, spurred flowers in a narrow cluster on a finely downy stalk.
<i>Delphinium</i>	<i>tricornis</i>	dwarf larkspur	P	M	12'-30"	spring	deep blue	N	NL	NL	Attracts large numbers of native bees.
<i>Dennstaedtia</i>	<i>punctilobula</i>	hayscented fern	P-S	M	36"	N/A	N/A	N	UPL	FACU	Fronks smell like hay when crushed.
<i>Dicentra</i>	<i>cucullaria</i>	dutchman's breeches	F-S	M	10"	spring	white, yellow	N	NL	NL	Can spread to cover larger areas; perennial; attracts bees.
<i>Diervilla</i>	<i>sessilifolia</i>	bush honeysuckle	F-S	M	4'-6'	summer	yellow	N	NL	NL	Small yellow flowers on tips of new growth all summer.
<i>Diodia</i>	<i>virginiana</i>	Virginia buttonweed	P	D	6'-18"	summer	white	N	FACW	FACW	
<i>Diospyros</i>	<i>virginiana</i>	persimmon	F-P	D-M	30'-50'	spring	yellow/green	N	FAC	FAC	Yellow/orange/mauve color; butterfly larval plant; attracts the luna moth.
<i>Dodecatheon</i>	<i>meadia</i>	shootingstar	F-P	M	1'-2'	spring	pink & white	N	FACU	FACU	Delicate white to pink petals, red and yellow center; important pollen and nectar source for honeybees.
<i>Dracopis</i>	<i>amplexicaulis</i>	clasping coneflower	P	M	2'-3'	spring to summer	yellow	N	FAC	FAC	Smooth-stemmed annual coneflower.
<i>Drosera</i>	<i>rotundifolia</i>	roundleaf sundew	F	W	<12"	summer	white	N	OBL	OBL	Native to swamps and bogs.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Dryopteris</i>	<i>marginalis</i>	marginal fern	P-S	W-M	1'-3'	N/A	N/A	N	FACU	FACU	Evergreen clumping fern; sensitive to heat; likes an oak leaf winter covering.
<i>Echinacea</i>	<i>purpurea</i>	purple coneflower	F-P	M-D	3'	summer	pink	N	NL	NL	Self-sows and spreads by offsets; clumping perennial; attracts butterflies, hummingbirds, and native bees.
<i>Elymus</i>	<i>hystrix</i>	eastern bottlebrush grass	F-P	M-D	2.5'-5'	summer	green	N	UPL	UPL	
<i>Eragrostis</i>	<i>spectabilis</i>	purple lovegrass	F	M	1'-1.5'	summer/fall	purple, red	N	FACU	UPL	Widely available as containers or seed; will spread through seed to reseed an area.
<i>Erythronium</i>	<i>americanum</i>	trout lily	P-S	M	8"	spring	yellow	N	NL	NL	Large few-petaled yellow flowers; mottled leaves.
<i>Euonymus</i>	<i>americanus</i>	Hearts-a-burstin	P-S	M	4'-6'	spring	yellow/green to purplish	Y	FAC	FAC	Purplish flowers in May; interesting red seed pods in Sept; attracts birds; some red fall color.
<i>Euonymus</i>	<i>atropurpureus</i>	burningbush	P	M	20'-25'	spring	purple	Y	FAC	FACU	Can be a shrub or small tree; red fall color; showy crimson fruit pods in fall and into winter.
<i>Eupatoriadelphus</i>	<i>fistulosus</i>	joe pye weed	F-P	M	5'-8'	summer	purple	N	FACW	FACW	Purplish-pink flowers explode in Aug/Sept, attracting butterflies.
<i>Eutrochium</i>	<i>fistulosum</i>	trumpetweed	F-P	M-W	4'-7'	summer	pink/purple	N	FACW	FACW	
<i>Fagus</i>	<i>grandifolia</i>	American beech	F-P	M	85+'	spring	yellow, green, brown	N	FACU	FACU	Nuts in fall attract birds/mammals/humans; leaves turn copper colored in fall and remain on the tree throughout the winter.
<i>Fothergilla</i>	<i>gardenii</i>	fothergilla	F-P	W-M	3'	spring	white	Y	FACW	FACW	Orange to yellow fall color.
<i>Fothergilla</i>	<i>major</i>	large fothergilla	F-P	M	6'-10'	spring	white	Y	NL	NL	Showy, fragrant flowers in spring; spectacular fall leaves.
<i>Fragaria</i>	<i>virginiana</i>	wild strawberry	F-P	M-D	6"	spring	white	N	FACU	FACU	Forms ground cover; tasty fruit in early summer; fruit attracts wildlife; flowers attract butterflies.
<i>Frangula</i>	<i>caroliniana</i>	Carolina buckthorn	P	M	12'-15'	spring	yellow	Y	FACU	FAC	Songbirds and other wildlife consume the berries, which apparently have medicinal properties but can be toxic.
<i>Fraxinus</i>	<i>americana</i>	white ash	F	M-D	80'	spring	green to purple	Y	FACU	FACU	Can grow larger than 80'; early yellow fall color then change to burgundy; easily transplanted; attracts many butterflies and moths.
<i>Fraxinus</i>	<i>caroliniana</i>	pop ash	F	M-D	30'	spring	green	N	OBL	OBL	Small tree; not available in the trade; transplants well.
<i>Fraxinus</i>	<i>pennsylvanica</i>	green Ash	F	M-D	60'-80'	spring	green to purple	Y	FACW	FACW	Yellow fall color; transplants well; planted in spoil soils after strip mining.
<i>Gaillardia</i>	<i>pulchella</i>	firewheel	F-P	D	1'-2'	summer	red and yellow	N	UPL	UPL	Annual, but is a short-lived perennial in coastal settings; reseeds; needs well-drained soils.
<i>Gaultheria</i>	<i>procumbens</i>	wintergreen	P-S	M	4"-8"	summer	pink	N	FACU	FACU	Pink flowers in summer followed by edible fruit that persists; evergreen; deer browse in winter.
<i>Gaura</i>	<i>angustifolia</i>	southern beeblossom	F-P	M	4'	spring to summer	pink & white	N	NL	NL	Annual; not available in the trade.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Gaylussacia</i>	<i>dumosa</i>	dwarf huckleberry	P	W-D	3"-15"	spring to summer	white	N	FAC	FAC	Spreads by rhizomes; semievergreen to deciduous.
<i>Gelsemium</i>	<i>rankinii</i>	swamp jessamine	F-P	M-D	vine	spring	yellow	N	FACW		High-climbing vine very common in parts of the South.
<i>Gelsemium</i>	<i>sempervirens</i>	Carolina jessamine	F-P	M	vine	early spring	yellow	N	FAC	FAC	Evergreen vine; can have problems with leaf miner; seen growing natively in tops of trees all over; fragrant yellow trumpet-shaped flowers.
<i>Geranium</i>	<i>maculatum</i>	wild geranium	F-S	M	1'-2'	spring and summer	purple	N	FACU	FACU	One-inch lavender-purple flowers in spring and summer; colonizes by rhizomes but is not aggressive.
<i>Gleditsia</i>	<i>triacanthos</i>	honeylocust	F	M-D	30'-75'	late spring	yellow	N	FAC	FAC	A thornless variety is available (<i>Gleditsia triacanthos inermis</i>); attracts butterflies and moths.
<i>Gordonia</i>	<i>lasianthus</i>	loblolly bay	F	M	30'-80'	summer	white	N	FACW	FACW	Evergreen; fragrant white flowers.
<i>Gymnocladus</i>	<i>dioicus</i>	Kentucky coffeetree	F-P-S	M-D	60'-75'	summer	white, green, brown	Y	NL	NL	Leaves give the foliage a tropical look.
<i>Halesia</i>	<i>carolina</i>	Carolina silverbell	F-S	M	30'	spring	white	N	FACU	FAC	Drooping, large white bell-shaped flowers in early spring; yellow to brown fall color is considered poor.
<i>Halesia</i>	<i>diptera</i>	silverbell	F-P	M	20'-30'	spring	white	Y	FAC	FAC	The white, tubular flowers hang on long, pendulous pedicels.
<i>Hamamelis</i>	<i>vernalis</i>	vernal witchhazel	F-P	M-D	12'-36'	winter	yellow	Y	FACU	FACU	A small tree or large shrub to 15' tall with multiple crooked stems forming an irregular, open crown.
<i>Hamamelis</i>	<i>virginiana</i>	common witchhazel	F-S	M	15'-30'	fall	yellow	Y	FACU	FACU	One-inch fragrant, creamy to bright yellow flowers in fall; yellow fall color.
<i>Helianthus</i>	<i>angustifolius</i>	swamp sunflower	P	M-W	3'	fall	yellow	N	FACW	FACW	Browsed by white tail deer; seeds used by birds; reseeds readily.
<i>Hepatica</i>	<i>acutiloba</i>	sharplobe hepatica	S	M-D	4'-9"	spring	white, pink, purple, blue	N	NL	NL	White, pink, blue, or purple solitary flowers in spring.
<i>Heuchera</i>	<i>americana</i>	alumroot	S	D	1'-3'	spring to summer	greenish purple	Y	FACU	FACU	Greenish-purple bell-shaped flowers bloom on leafless stalks; foliage turns purple, red, and yellow in fall.
<i>Hexastylis</i>	<i>arifolia</i>	littlebrownjug	P-S	M	6"	spring	purple to brown	N	FAC	FAC	Spotty groundcover, heart-shaped leaves, jug-shaped flowers held at ground level beneath the leaves.
<i>Hibiscus</i>	<i>coccineus</i>	scarlet rosemallow	S	W	4'-7'	summer	red	N	OBL	OBL	Deep scarlet flowers over 10" in width.
<i>Hibiscus</i>	<i>moscheutos</i>	crimson-eyed rosemallow	F-P	M-W	3'-8'	summer	white/red	N	OBL	OBL	Widely available; likes slightly acidic soils.
<i>Hydrangea</i>	<i>arborescens</i>	snowhill hydrangea	P-S	M	4'-6'	summer	white	N	UPL	FACU	Large clusters of flat, creamy white flowers Jun-Jul; suckers freely.
<i>Hydrangea</i>	<i>quercifolia</i>	oakleaf hydrangea	S	M	3'-12'	summer	white, green, purple	Y	NL	NL	The foliage, shaped something like that of red oak, becomes colorful in fall.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Hymenocallis</i>	<i>caroliniana</i>	Carolina spiderlily	P-S	M	1'-3'	spring, summer	white	N	OBL	OBL	A smooth, fleshy, fragrant perennial.
<i>Hypericum</i>	<i>densiflorum</i>	bushy St. Johnswort	F-P	W-D	4'-6'	spring	yellow	N	FACW	FACW	Golden yellow 1" flowers in late spring; semi-evergreen; spreads by stolons.
<i>Hypericum</i>	<i>prolificum</i>	shrubby St. Johnswort	F-P	M	1'-5'	summer	yellow	Y	FAC	FACU	Showy 1" yellow flowers bloom Jun-Sept; yellow green fall color.
<i>Ilex</i>	<i>cassine</i>	dahoon holly	F-P	W-M	20'-30'	spring	white	N	FACW	FACW	Inconspicuous greenish white axillary flowers.
<i>Ilex</i>	<i>decidua</i>	possumhaw	F-P	M	15'-30'	spring	white	N	FACW	FACW	Female trees produce red berries in fall.
<i>Ilex</i>	<i>glabra</i>	inkberry	P	M-W	6'-12'	spring	white	N	FACW	FAC	Black berries in the fall that persist into winter.
<i>Ilex</i>	<i>montana</i>	mountain winterberry	F-P	M	15'-40'	spring	white	N	NL	FACU	Red berries on female plants.
<i>Ilex</i>	<i>opaca</i>	American holly	F-S	M-D	20'-40'	spring	white	N	FAC	FACU	To ensure fruit, one male is needed per two to three females.
<i>Ilex</i>	<i>verticillata</i>	common winterberry	F-S	M-W	6'-15'	spring	white	N	FACW	FACW	Red berries on female plants persist into winter and attract birds.
<i>Ilex</i>	<i>vomitorea</i>	yaupon	F-P	W-D	12'-25'	spring	white	N	FAC	FAC	Evergreen; berries produced on female plants.
<i>Illicium</i>	<i>floridanum</i>	Florida anisetree	P-S	W-M	6'-12'	spring	red, purple	N	FACW	FACW	Maroon-purple flowers occur singly and are composed of 20-30 strap-like petals.
<i>Impatiens</i>	<i>capensis</i>	jewelweed	F-P	M	3'	summer	orange	N	FACW	FACW	Beautiful orange flowers attract butterflies and hummingbirds; annual; important for honeybees.
<i>Ipomopsis</i>	<i>rubra</i>	standing-cypress	F-P	D	2'-6'	summer	red	N	NL	NL	Showy red tubular flowers on spikes; attracts hummingbirds.
<i>Iris</i>	<i>cristata</i>	dwarf crested iris	P-S	M-D	4"-8"	spring	lavender-blue	N	NL	NL	Pale lavender-blue, crested flowers Apr-May.
<i>Iris</i>	<i>fulva</i>	copper iris	F-P	M	1'-3'	spring	red, orange, yellow	N	OBL	OBL	Showy copper, red, or orange; drooping petals and spreading sepals make up the terminal flower.
<i>Iris</i>	<i>virginica</i>	southern blue flag iris	P-S	W	3'-6'	early summer	blue/purple	N	OBL	OBL	Spreads by rhizomes; be sure to get this iris and not the nonnative invasive yellow flag iris.
<i>Itea</i>	<i>virginica</i>	Virginia sweetspire	F-S	W	3'-6'	summer	white	Y	FACW	OBL	Spectacular long -asting yellow, orange, crimson fall color.
<i>Juglans</i>	<i>nigra</i>	black walnut	F-P	M	50'-75'	spring	yellow, green, brown	Y	UPL	FACU	Yellow fall color; deep taproot makes transplant difficult; certain plants will not grow beneath black walnut due to the juglones it releases into the soil; attracts birds and small mammals; host plant for luna moth.
<i>Juncus</i>	<i>effusus</i>	common rush	F-P	M-W	3'	spring	yellow	N	OBL	FACW	Attracts birds; very easily transplanted; can be divided.
<i>Juniperus</i>	<i>virginiana</i>	eastern redcedar	F-P	M-D	40'-50'	spring	green, purple, brown	N	FACU	FACU	Offers nesting and cover to birds; fruits used extensively by birds and small mammals; evergreen.
<i>Justica</i>	<i>americana</i>	water-willow	F-P	W-M	1'-3'	spring/summer	pink, purple, violet	N	OBL	OBL	An aquatic with bicolored flowers in dense, head-like or spike-like clusters.
<i>Kalmia</i>	<i>latifolia</i>	mountain laurel	P	M	8'-10'	spring	pink, red, white	N	FACU	FACU	Pink, red, or white flowers in late spring; evergreen; difficult to propagate.
<i>Leucothoe</i>	<i>axillaris</i>	doghobble	P-S	M	2'-4'	spring	white to pink	N	FACW	FACW	Evergreen; attracts bees; browsed by deer.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Leucothoe</i>	<i>fontanesiana</i>	drooping leucothoe	P-S	M	3'-5'	summer	white	N	FACW	FACW	Lance-shaped leaves on slender stems; few branches; evergreen.
<i>Liatris</i>	<i>spicata</i>	blazing star	F	M	3'	summer	purple	N	FAC	FAC	Tall purple spikes bloom after two to three years; attracts butterflies and hummingbirds.
<i>Lilium</i>	<i>canadense</i>	Canada lily	F	W-M	3'-8'	summer	red, orange, yellow	N	FAC	FAC	A large, showy lily with recurved petals.
<i>Lilium</i>	<i>superbum</i>	turk's-cap lily	F-P	M	4'-6'	summer	orange	N	FACW	FACW	Gorgeous orange flowers; morning sun and afternoon shade.
<i>Lindera</i>	<i>benzoin</i>	spicebush	P-S	M	6'-12'	winter	yellow	N	FACW	FAC	Yellow spicily fragrant flowers in late winter; red fruit in fall on female plants.
<i>Liquidambar</i>	<i>styraciflua</i>	sweetgum	P	M	70'-120'	spring	white, green	Y	FAC	FAC	Red to purple fall color; fruit attracts several bird species; used as a nesting site.
<i>Liriodendron</i>	<i>tulipifera</i>	tuliptree	F	M	70'-90'	spring	yellow, green, orange	Y	FACU	FACU	Large tulip-like flowers are yellow/green/orange in May-June; yellow fall color.
<i>Lobelia</i>	<i>cardinalis</i>	cardinal flower	F-P	W	3'-5'	fall	red	N	FACW	FACW	Terminal clusters of bright red flowers each 1 1/2" long in fall.
<i>Lobelia</i>	<i>puberula</i>	lobelia	F-S	M	2'-4'	summer/fall	blue-violet	N	FACW	FACW	Spikes of flowers range from pale blue to violet.
<i>Lobelia</i>	<i>siphilitica</i>	great blue lobelia	P-S	W	1'-3'	summer	blue	N	OBL	FACW	Elongated clusters of pale to dark blue flowers in late summer.
<i>Lonicera</i>	<i>sempervirens</i>	trumpet honeysuckle	F-P	M	vine	spring	red to orange	N	FACU	FACU	Evergreen vine; flowers followed by red berries that attract birds and other wildlife; flowers attract hummingbirds, butterflies, and bees.
<i>Lyonia</i>	<i>ligustrina</i>	maleberry	P	W	6'-12'	summer	white	Y	FACW	FACW	Orange to red fall color; low wildlife value; attracts birds.
<i>Lyonia</i>	<i>lucida</i>	lyonia	P-S	M-D	3'-5'	spring	pink	N	FACW	FACW	Evergreen; suckers easily; flowers attract bees.
<i>Lysimachia</i>	<i>ciliata</i>	fringed loosestrife	F-P	M-W	2'-3'	summer	yellow	N	FACW	FACW	Yellow flowers grow upside down; good groundcover; tolerates seasonal flooding.
<i>Magnolia</i>	<i>acuminata</i>	cucumber tree	P-S	M	50'-75'	spring	yellow/green	N	NL	FACU	Yellow/green magnolia-type flowers (spring); pink/red fruit in fall; fruits eaten by groundforaging birds and small mammals.
<i>Magnolia</i>	<i>grandiflora</i>	southern magnolia	F-P	M-D	72'-100'	spring	white	N	FAC	FACU	Beautiful, fragrant large white flowers.
<i>Magnolia</i>	<i>macrophylla</i>	bigleaf magnolia	P	W	30'-40'	summer	white	N	NL	NL	Largest flowers and largest leaves of all native North American species.
<i>Magnolia</i>	<i>tripetala</i>	umbrellatree	F-P	M	15'-40'	spring	white	N	FACU	FACU	Six- to eight-inch white flowers spring w/unpleasant odor; red fruit in fall.
<i>Magnolia</i>	<i>virginiana</i>	sweetbay magnolia	PS	M-D	40'-60'	summer	white	N	FACW	FACW	Semievergreen to evergreen; lemon-scented flowers; attracts sweetbay silk moth; medium growth rate.
<i>Maianthemum</i>	<i>canadense</i>	wild lily of the valley	P-S	M	3"-6"	late spring to early summer	white	N	FAC	FAC	Spreads by rhizomes to form a colony.
<i>Malus</i>	<i>angustifolia</i>	southern crab apple	P	M	25'-30'	spring	pink	N	NL	NL	Fruit consumed by birds and small mammals.
<i>Matteuccia</i>	<i>struthiopteris</i>	osterich fern	P	M	3'-6'	N/A	N/A	N	FACW	FACW	Tall fronds, 2'-8'.
<i>Mertensia</i>	<i>virginica</i>	Virginia bluebells	F-P	M	1'-3'	spring	purple	N	FAC	FACW	Nodding clusters of pink buds that open into light-blue trumpet-shaped flowers.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Mitchella</i>	<i>repens</i>	partridgeberry	P-S	M	3"	spring to summer	pink	N	FACU	FACU	Elegant pink flowers; red edible fruit; dense/creeping evergreen ground cover.
<i>Mitella</i>	<i>diphylla</i>	bishop's cap	P-S	M-D	1'-2'	spring	white	N	FACU	FACU	Produces distinctive clusters of tiny white flowers.
<i>Monarda</i>	<i>didyma</i>	bee balm	F-P	M	3'-4'	summer	red	N	FAC	FAC	Edible leaves; red flowers attract bees/hummingbirds.
<i>Morella</i>	<i>cerifera</i>	southern wax myrtle	F-P	M-D	6'-12'	spring	green	N	FAC	FAC	Fixes nitrogen; should not be used in nitrogen sensitive watersheds; evergreen, attracts birds and butterflies.
<i>Morus</i>	<i>rubra</i>	red mulberry	F-P-S	M-D	12'-36'	spring	white, green, brown	Y	FACU	FACU	Habitat, flower, and fruit similar to white mulberry; yellow fall color.
<i>Muhlenbergia</i>	<i>capillaris</i>	muhly grass	F-P	M-D	3'	fall	pink	N	FAC	FACU	Used extensively; a good phosphorous uptake plant.
<i>Nelumbo</i>	<i>lutea</i>	American lotus	F	W	6'	summer	yellow	N	OBL	OBL	Aquatic plant; good for deep pools.
<i>Nuphar</i>	<i>lutea</i>	cow lily	P	W	3'	spring to fall	yellow	N	OBL	OBL	Aquatic plant; can grow in water up to 16" deep.
<i>Nymphaea</i>	<i>odorata</i>	American waterlily	F-P-S	W	1'	spring to fall	white/yellow	N	OBL	OBL	Aquatic plant; shallow water.
<i>Nyssa</i>	<i>aquatica</i>	water tupelo	F	W	50'-100'	spring	green	N	OBL	OBL	Buttressed base, flood tolerant, deciduous, can grow in standing water.
<i>Nyssa</i>	<i>sylvatica</i>	black tupelo	F	M-D	30'-60'	spring	white, green, brown	Y	FAC	FAC	Scarlet-red fall color.
<i>Oenothera</i>	<i>speciosa</i>	pink evening primrose	FS	M	1-3'	spring	pink, white	N	NL	NL	Opens flowers in the evening, closing them by early morning; seeds attract birds and mammals.
<i>Onoclea</i>	<i>sensibilis</i>	sensitive fern	F-P	W	12"-4"	N/A	N/A	N	FACW	FACW	Shelters salamanders and frogs; poisonous to livestock; roots shallow.
<i>Osmanthus</i>	<i>americanus</i>	devilwood	P	M	30'	spring	white	N	NL	NL	Small, fragrant white flowers; evergreen.
<i>Osmunda</i>	<i>cinnamomea</i>	cinnamon fern	P-S	M-W	24"-48"	N/A	N/A	N	FACW	FACW	Clusters of arching fronds; cinnamon-colored fertile fronds.
<i>Osmunda</i>	<i>regalis</i>	royal fern	P	M-W	2'-5'	N/A	N/A	N	OBL	OBL	Tolerates year-round shallow water; pinnae resemble locust tree leaves.
<i>Ostrya</i>	<i>virginiana</i>	hophornbeam	P-S	M	30'-50'	spring	white, yellow, green, brown	Y	FACU	FACU	Scarlet red autumn color; some food value to birds and small mammals.
<i>Oxydendrum</i>	<i>arboreum</i>	sourwood	F-S	M-D	20'-30'	summer	white	Y	FACU	UPL	Fragrant flowers in spring; yellow/pink/red in fall.
<i>Pachysandra</i>	<i>procumbens</i>	Allegheny-spurge	P-S	M	9"	spring	white, pink	N	NL	NL	Mottled purple leaves; flowers are white with pink tinge; semievergreen ground cover; spreads by slender rhizomes.
<i>Panicum</i>	<i>virgatum</i>	switchgrass	F-P	M-D	3'-6'	summer/fall	green and brown	N	FAC	FAC	Grows in clumps; a loose sod former; spreads by rhizomes; attracts birds and butterflies.
<i>Parthenocissus</i>	<i>quinquefolia</i>	Virginia creeper	F-P-S	W-M-D	vine	spring	white/green	N	FACU	FACU	A woody, deciduous vine, Virginia creeper can be high climbing or trailing.
<i>Passiflora</i>	<i>incarnata</i>	passion flower	S-P	M-D	12'-36'	spring to fall	purple, pink, white	N	NL	NL	Unusual purple, showy flowers; vine with tendrils.
<i>Peltandra</i>	<i>virginica</i>	arrow arum	P	W	2'-3'	spring	yellow	N	OBL	OBL	Flowers are spathe and spadix.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Penstemon</i>	<i>digitalis</i>	foxglove beardtongue	F-P-S	D	3'-6'	summer	white	N	FAC	FAC	
<i>Persea</i>	<i>borbonia</i>	redbay	P	W-M	36'-72'	spring	pale yellow	N	FACW	FACW	Evergreen with pale yellow flowers; aromatic; fruit eaten by birds
<i>Phacelia</i>	<i>bipinnatifida</i>	fernleaf phacelia	P-S	M	1'-2'	spring	purple, violet, blue	N	NL	NL	Reseeds readily; contact can cause allergic reaction; biennial, blooms midspring of second year.
<i>Philadelphus</i>	<i>inodorus</i>	mock orange	F-P	W	10'-12'	spring	white	N	NL	NL	Attracts large numbers of native bees; white flowers are nearly odorless; <i>Philadelphus coronarius</i> (nonnative) has fragrant flowers.
<i>Phlox</i>	<i>amoena</i>	chalice phlox	F-P	M	2'-3'	spring	pink	N	NL	NL	Clusters of fragrant rose and white flowers; attracts hummingbirds.
<i>Phlox</i>	<i>carolina</i>	Carolina phlox	F-P	M	3'-4'	summer to fall	white, pink, purple	N	FACU	FACU	Thick leaves and showy flower clusters; attracts butterflies and hummingbirds.
<i>Phlox</i>	<i>divaricata</i>	wild blue phlox	P-S	M	12'-18"	spring	lavender	N	FACU	FACU	Fragrant lavender-blue flowers Apr-May.
<i>Phlox</i>	<i>glaberrima</i>	smooth phlox	P	W-M	2'-4'	spring	pink/purple	N	FACW	FAC	Attracts hummingbirds.
<i>Phlox</i>	<i>paniculata</i>	garden phlox	F-P	M	2'-4'	summer	pink, magenta, white	N	FACU	FACU	Clusters of magenta, pink lavender, or white flowers Jul-Sep; powdery mildew can be a problem.
<i>Phlox</i>	<i>stolonifera</i>	creeping phlox	P-S	M	6'-10"	spring	white, pink, purple, violet	N	NL	NL	White, pink, purple to violet trumpet-shaped flowers in spring; semi-evergreen ground cover; does not like full sun; slugs can be a problem in wet soils.
<i>Photinia</i>	<i>melanocarpa</i>	black chokeberry	F-P	D-W	3'-5'	spring	white	Y	FAC	FAC	Dependable showy orange, burgundy and purple fall color.
<i>Physocarpus</i>	<i>opulifolius</i>	ninebark	F-P-S	D-M-W	6-12'	summer	white/pink	Y	FAC	FACW	Has been used as a live stake, yellow fall color
<i>Physostegia</i>	<i>virginiana</i>	obedient plant	F-P	W-D	4'	summer to fall	pink, purple	N	FACW	FAC	Long-lasting purple flowers with triangular lobes; can be aggressive; colonizes.
<i>Pinus</i>	<i>echinata</i>	shortleaf pine	P	D	50'-100'	spring	yellow	N	NL	NL	Evergreen; used for cover and nesting site; seeds attract birds; attracts butterflies.
<i>Pinus</i>	<i>elliottii</i>	slash pine	P	M	75'-100'	winter	red	N	FACW	FACW	Evergreen; loses its lower branches with age, forming an open, rounded crown.
<i>Pinus</i>	<i>glabra</i>	spruce pine	P	M	100'-120'	spring	green	N	FACW	FACW	Evergreen; spruce pine has bark that resembles a spruce tree.
<i>Pinus</i>	<i>palustris</i>	longleaf pine	F	D	80'-100'	winter	brown	N	FAC	FAC	Evergreen; an 80'-100' tree with short, stout, spare branches forming an open, irregular crown.
<i>Pinus</i>	<i>strobus</i>	eastern white pine	F-P-S	M-D	75'-100'	spring	green	N	FACU	FACU	Evergreen; largest northeastern conifer and useful for pulpwood, construction, and countless other items.
<i>Pinus</i>	<i>taeda</i>	loblolly pine	P	D	60'-110'	spring	yellow	N	FAC	FAC	Evergreen; used for cover and nesting site; seeds attract birds; attracts butterflies.
<i>Pinus</i>	<i>virginiana</i>	Virginia pine	F-P	M-D	15'-40'	spring	yellow	N	NL	NL	Evergreen; seeds attract birds; attracts butterflies.
<i>Platanus</i>	<i>occidentalis</i>	sycamore	F-P	M-W	70'-90'	spring	yellow, green, brown	N	FACW	FACW	Leaves drop all summer; white molted bark; attracts birds; shade tree.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Podophyllum</i>	<i>peltatum</i>	mayapple	P-S	M	1.5'	spring	white, pink	N	FACU	FACU	Only has two leaves and one flower; leaves, roots, and stems toxic if ingested; colonizes by rhizomes.
<i>Polemonium</i>	<i>reptans</i>	Jacob's-ladder	S	M	1'-3'	spring	purple	N	FAC	FACU	Smooth, weak-stemmed plant with light blue to purple bell-shaped flowers.
<i>Polygonatum</i>	<i>biflorum</i>	Solomon's seal	P-S	M	2'-3'	spring	greenish white	N	FACU	FACU	Half-inch bell-shaped greenish-white flowers hang from leaf axils; attracts birds and butterflies.
<i>Polystichum</i>	<i>acrostichoides</i>	Christmas fern	P-S	M	12"-36"	N/A	N/A	N	FACU	FACU	Stiff, deep-green fronds are once pinnate.
<i>Pontederia</i>	<i>cordata</i>	pickerelweed	W	M-W	3'	summer	blue/purple	N	OBL	OBL	Easy to grow so long as it does not dry out; attracts bees and butterflies; also attracts dragonflies that eat mosquito larvae.
<i>Prunus</i>	<i>americana</i>	American plum	F-P	W-D	12'-20'	spring	white	Y	UPL	FACU	White-fragrant flowers in spring; 1" red/yellow fruit in summer; red to yellow fall color.
<i>Prunus</i>	<i>angustifolia</i>	chickasaw plum	P	D	15'-30'	spring	white	Y	NL	NL	Pale yellow fall color; edible fruit; attracts birds and butterflies.
<i>Prunus</i>	<i>caroliniana</i>	Carolina laurelcherry	F-P	M	15'-36'	spring	white	N	FACU	FACU	Evergreen; attracts native bees; berries attract birds.
<i>Prunus</i>	<i>serotina</i>	black cherry	F-S	D	50'-80'	spring	white	Y	FACU	FACU	Messy tree; small edible berries in summer attract birds; yellow fall color.
<i>Ptelea</i>	<i>trifoliata</i>	hoptree	F-S	M	15'-20'	spring	white	Y	FACU	FAC	Small, white, fragrant flowers; yellow/green fall color; larval host for swallowtails.
<i>Quercus</i>	<i>alba</i>	white oak	F-P	D	60'-90'	spring	red, yellow, green, brown	Y	FACU	FACU	Brown/red/ bright red fall color; grows rapidly; attracts birds and butterflies.
<i>Quercus</i>	<i>bicolor</i>	swamp white oak	P	W-M	80'	spring	red, yellow, green	Y	FACW	FACW	Attracts birds and small mammals; yellow fall color.
<i>Quercus</i>	<i>coccinea</i>	scarlet oak	F	M	60'-75'	spring	yellow	Y	NL	NL	A beautiful oak best known for its brilliant autumn color.
<i>Quercus</i>	<i>falcata</i>	southern red oak	P	D	100'	spring	yellow	Y	FACU	FACU	Reddish brown fall color; used for cover and as a nesting site; attracts birds and moths.
<i>Quercus</i>	<i>georgiana</i>	Georgia oak	S	D	12'-36'	spring	green	Y	NL	NL	This species is a conservation concern and is officially listed as threatened.
<i>Quercus</i>	<i>hemisphaerica</i>	Darlington oak	F	D	90'-120'	spring	green	N	FACU	FACU	A short-lived pyramidal-rounded evergreen.
<i>Quercus</i>	<i>laevis</i>	turkey oak	F	M-D	30'-40'	spring	yellow	Y	NL	NL	Leaves resemble a turkey foot; brightly colored fall foliage.
<i>Quercus</i>	<i>laurifolia</i>	laurel oak	P	M	36'-80'	spring	yellow	N	FACW	FACW	Semievergreen; can be short-lived.
<i>Quercus</i>	<i>lyrata</i>	overcup oak	F-P	W-M-D	30'-45'	spring	yellow	N	OBL	OBL	Attracts waterfowl.
<i>Quercus</i>	<i>michauxii</i>	swamp chestnut oak	P	M	50'-100'	spring	yellow	Y	FACW	FACW	Yellow to red fall color; attracts birds and butterflies.
<i>Quercus</i>	<i>nigra</i>	water oak	P	W-M	50'-100'	spring	yellow	Y	FAC	FAC	Yellow fall color; attracts moths, birds, and small mammals.
<i>Quercus</i>	<i>phellos</i>	willow oak	P	W-M	100'	spring	yellow	Y	FACW	FAC	Attracts moths and birds; yellow or russet fall color.
<i>Quercus</i>	<i>prinus</i>	chestnut oak	P	D	65'-145'	spring	yellow	Y	UPL	UPL	A medium to large tree with chestnut-like foliage.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Quercus</i>	<i>rubra</i>	red oak	F-P	M-D	60'–75'	spring	yellow, green, brown	Y	FACU	FACU	Russett red to bright red fall color; grows rapidly; attracts birds and small mammals.
<i>Quercus</i>	<i>shumardii</i>	Shumard's oak	F-P	M-D	50'–90'	spring	white/green	Y	FAC	FAC	Scarlet red fall color; used for cover and as a nesting site; fruits attract birds.
<i>Quercus</i>	<i>stellata</i>	post oak	F-P	D	40'–50'	spring	yellow, brown	Y	UPL	UPL	Variable fall color; nonshowy to golden brown.
<i>Quercus</i>	<i>virginiana</i>	live oak	F-P	M-D	40'–80'	spring	yellow	N	FACU	FACU	Evergreen; frequently seen growing with Spanish moss in the South; birds and squirrels use this tree for cover.
<i>Rhapidophyllum</i>	<i>hystrix</i>	needle palm	F-P	W-M	3'–6'	spring/summer	white	N	FACW	FACW	Needle palm is an armed shrub, rarely more than 6' tall, with erect or spreading stems from a short trunk.
<i>Rhododendron</i>	<i>alabamense</i>	Alabama azalea	S	M	5'–6'	spring	white/yellow	N	NL	NL	Deciduous; flowers before leaves emerge; flowers lemon scented.
<i>Rhododendron</i>	<i>arborescens</i>	smooth azalea	P	M	8'–12'	summer	white	Y	FACW	FAC	Large, white flowers; it is the last of the azaleas to bloom in the spring.
<i>Rhododendron</i>	<i>austrinum</i>	Florida flame azalea	P	D	6'–12'	spring	orange/yellow/red	N	FAC	FAC	Beautiful orange, yellow, and red flowers.
<i>Rhododendron</i>	<i>calendulaceum</i>	flame azalea	P-S	M	4'–8'	spring	yellow, orange, scarlet	N	NL	NL	Yellow, orange, scarlet flowers in late spring.
<i>Rhododendron</i>	<i>canescens</i>	pedmont azalea	P	D	6'–12'	spring	white/pink	N	FACW	FACW	A showy shrub growing up to 8' tall.
<i>Rhododendron</i>	<i>catawbiense</i>	mountain rosebay	F-S	M	6'–10'	spring	lilac purple	N	FACU	FACU	Five- to six-inch umbel of lilac purple to pale-pink flowers midspring; special value to honeybees; evergreen
<i>Rhododendron</i>	<i>periclymenoides</i>	pinxterbloom azalea	P-S	M	6'–10'	spring	pink	N	FAC	FAC	Variable flower color; often pink flowers before leaves emerge; special value to honeybees.
<i>Rhododendron</i>	<i>maximum</i>	rosebay rhododendron	P-S	M-W	15'–40'	summer	white to deep pink	N	FAC	FAC	Huge clusters of white to deep-pink flowers with yellow spots; evergreen; should not be ingested by humans or animals.
<i>Rhododendron</i>	<i>viscosum</i>	swamp azalea	P	D	12'	summer	white to pink	N	OBL	FACW	Special value to honeybees.
<i>Rhus</i>	<i>copallinum</i>	winged sumac	F	D	20'–35'	summer	yellow, green	Y	UPL	FACU	Yellowish-green flowers are succeeded by drooping, pubescent, pyramidal fruit clusters.
<i>Rhus</i>	<i>glabra</i>	smooth sumac	F-P	M-D	9'–15'	summer	white, green, yellow, brown	Y	NL	NL	Velvety red fruit on female plants that persist into winter; special value to native bees; also attracts parasitic insects that prey on insect pests.
<i>Robinia</i>	<i>pseudoacacia</i>	blacklocust	F	M-D	30'–50'	spring	white	N	UPL	FACU	Attracts large numbers of native bees and honeybees; attracts butterflies, birds, and hummingbirds.
<i>Rosa</i>	<i>carolina</i>	Carolina rose	F-P	W-D	3'–4'	summer	pink	Y	FACU	FACU	Yellow, orange, red fall color; pink flowers May-July; does not have thorns.
<i>Rosa</i>	<i>palustris</i>	swamp rose	F-P	M-W	4'–6'	summer	pink	N	OBL	OBL	Fragrant flowers in summer; red hips in fall; attracts birds.
<i>Rudbeckia</i>	<i>fulgida</i>	orange coneflower	F-P	M	3'	summer to fall	yellow	N	FAC	FAC	Attracts birds; will colonize by offsets and reseeding.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Rudbeckia</i>	<i>hirta</i>	blackeyed Susan	F-P	M-D	2'-3'	summer/fall	yellow	Y	FACU	FACU	Two- to four-inch flower heads with 10-20 bright yellow petals summer/fall; annual or short-lived perennial; attracts nectar bees and butterflies; attracts birds.
<i>Ruellia</i>	<i>caroliniensis</i>	Carolina wild petunia	P	M	2'-3'	summer	purple	N	FACU	FACU	Usually only one or two of the light purple flowers are open per day.
<i>Ruellia</i>	<i>humilis</i>	fringeleaf wild petunia	F-P	D	1'-2'	summer	purple	N	FACU	FACU	Its showy flowers are petunia shaped and vary in color from lavender to purple.
<i>Sabal</i>	<i>minor</i>	dwarf palmetto	F-P-S	M-D	5'-10'	summer	white	N	FACW	FACW	Fruit attracts birds and mammals; used for cover.
<i>Sagittaria</i>	<i>lancifolia</i>	lance leaf arrowhead	F	W	3'	summer	white	N	OBL	OBL	A tuber that produces rhizomes.
<i>Sagittaria</i>	<i>latifolia</i>	duck-potato	F-P	W	1'-3'	summer	white	N	OBL	OBL	Colonizing; starchy tubers used by ducks and muskrats.
<i>Salvia</i>	<i>coccinea</i>	Texas sage	F-P	M-D	1'-3'	spring/ summer/fall	red	N	NL	NL	Several whorls of red flowers form an interrupted spike on a square stem.
<i>Salix</i>	<i>sericea</i>	silky willow	F-S	W-M	12'	spring	green, yellow	N	OBL	OBL	Provides good wildlife habitat; used for live stakes.
<i>Sambucus</i>	<i>canadensis</i>	elderberry	F-S	M-W	5'-12'	summer	white	N	FACW	FACW	Showy white flowers in July, edible fruit in Sept; commonly used for live stakes.
<i>Sambucus</i>	<i>nigra</i>	elderberry	P	W	10'-20'	spring to summer	white	N	FACW	FACU	Produces berries that are used in preserves and pies but should never be eaten when fresh and raw.
<i>Sanguinaria</i>	<i>canadensis</i>	bloodroot	S	M	6'-10"	spring	white	N	UPL	UPL	Two-inch white flowers with yellow centers; roots have red sap; rhizomes toxic and may be fatal if ingested.
<i>Sassafras</i>	<i>albidum</i>	common sassafras	F-P	D-M	30'-60'	spring	yellow	Y	FACU	FACU	Yellow flowers (Apr); clear yellow/orange/pink/scarlet fall color; fruit attracts birds.
<i>Saururus</i>	<i>cernuus</i>	lizard's tail	P-S	M-W	4'	spring/summer	white	N	OBL	OBL	Prefers up to 4" flooding; colonizing.
<i>Schizachrium</i>	<i>scoparium</i>	little bluestem	F-P	D	3'	summer to fall	white	Y	FACU	FACU	clump-forming perennial grass with great, striking red fall color that remains almost all winter.
<i>Schoenoplectus</i>	<i>americanus</i>	Olney's three-square bulrush	F-P	M	3'-6'	spring to summer	yellow, brown	N	OBL	OBL	Native to coastal AL but will perform throughout the state; the rhizomes are a food source of muskrat, nutria, and other animals.
<i>Schoenoplectus</i>	<i>tabernaemontani</i>	sofstem bulrush	F	W	3'-6'	spring	red	N	OBL	OBL	Native to central AL.
<i>Scirpus</i>	<i>cyperinus</i>	woolgrass	F	W	3'-6'	summer	green and brown	N	OBL	FACW	Seeds eaten by waterfowl. Roots eaten by muskrats and geese. Provides cover for nesting birds; colonizing.
<i>Sedum</i>	<i>pulchellum</i>	rock stonecrop	F	W	0'-1'	spring	white/pink	N	UPL	FACU	
<i>Sedum</i>	<i>ternatum</i>	wild stonecrop	P	M	4"-8"	spring	white	N	NL	FACU	Rock-loving perennial.
<i>Serenoa</i>	<i>repens</i>	saw palmetto	P	M	10'-12'	summer	white	N	FACU	FACU	Small, white, fragrant flowers occur on plume-like branched stalks from leaf axils.
<i>Sideroxylon</i>	<i>lycioides</i>	buckthorn bumelia	P	W-M	20'	summer	white	N	FAC	FACW	Spiny shrub or small tree with open crown.
<i>Silene</i>	<i>virginica</i>	fire pink	F-P	M	10"-20"	spring/summer	pink	N	NL	NL	Deep red-pink flowers attract hummingbirds and butterflies; short-lived perennial.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Sisyrinchium</i>	<i>mucronatum</i>	needletip blue-eyed grass	F-P	M-D	1'	summer	blue/purple	N	FACW	FAC	Rich blue/purple flowers with yellow centers May-Jul; a member of the iris family.
<i>Smilax</i>	<i>smallii</i>	Jackson vine	F-P	M	8'	spring	yellow/green	N	FACU	FACU	Thornless; attracts birds.
<i>Solidago</i>	<i>altissima</i>	goldenrod	F-S	M	2'-4'	fall	yellow	N	FACU	FACU	Attracts butterflies and birds.
<i>Solidago</i>	<i>rugosa</i>	winkleleaf goldenrod	F	M-D	2'-5'	fall	yellow	N	FAC	FAC	Tiny flowers look like strings of yellow beads Aug-Oct.
<i>Sorghastrum</i>	<i>nutans</i>	Indiangrass	F-P-S	M-D	3'-8'	summer	yellow	Y	FACU	FACU	Deep orange to purple fall color; tolerates seasonal inundation.
<i>Sparganium</i>	<i>americanum</i>	bur-reed	S-P	W	2.5'	summer	yellow/green	N	OBL	OBL	Seeds used by waterfowl; tolerates flowing water; colonizes by slender underground rhizomes
<i>Spigelia</i>	<i>marilandica</i>	Indian pink	P	D	1'-2'	spring	red/yellow	N	NL	NL	Blooms from the bottom upward and the flowering season can be prolonged by removing the flowers as they wither.
<i>Staphylea</i>	<i>trifolia</i>	American bladdernut	S	M	8'-15'	spring	white	N	FAC	FAC	Drooping clusters of cream, bell-shaped flowers and attractive, dark-green, trifoliate leaves.
<i>Stewartia</i>	<i>malacodendron</i>	silky camellia	S	M	10'	spring	white	N	NL	NL	Open branched deciduous shrub
<i>Stewartia</i>	<i>ovata</i>	mountain camelia	S	M	12'-20'	summer	white	Y	NL	NL	Large, showy, solitary, white flower with crimped and scalloped edges.
<i>Stokesia</i>	<i>laevis</i>	Stokes' aster	F	M	12"-30"	summer	purple	N	FAC	FAC	Showy purple flowers
<i>Stylophorum</i>	<i>diphyllum</i>	celadine poppy	S	M	12"-14"	spring	yellow	N	NL	NL	Known for its large, poppy-like, yellow flowers.
<i>Styrax</i>	<i>americanus</i>	snowbell	F-P	W-M	8'-15'	spring/summer	white	N	FACW	OBL	Attracts nectar bees and butterflies; fruit attracts birds
<i>Styrax</i>	<i>grandifolius</i>	bigleaf snowbell	P	M	20'	spring	white	N	FACU	FACU	Fragrant white flowers are bell-shaped and hang from the tree in late spring. It needs shade and acid, moist soil.
<i>Symphoricarpos</i>	<i>orbiculatus</i>	coralberry	F-S	M	2'-5'	spring/summer	white/green	N	FACU	FACU	Bell shaped flowers become clusters of large pink berries
<i>Symphyotrichum</i>	<i>patens</i>	late purple aster	F-P	M-D	1'-3'	summer	violet-blue	N	NL	NL	1 1/2" bright violet-blue flowers with yellow centers, used to be <i>Aster patens</i>
<i>Symplocos</i>	<i>tinctoria</i>	horsesugar	P	W	36'-72'	spring	cream/white	N	FAC	FAC	Small, fragrant cream colored flowers.
<i>Taxodium</i>	<i>distichum</i>	bald cypress	F-P	W	50'-75'	spring	purple	Y	OBL	OBL	Leaves turn yellow to copper in fall; attracts birds and small mammals; used for cover and nesting site
<i>Thelypteris</i>	<i>kunthii</i>	Kunth's maiden fern	P-S	M	3'	N/A	N/A	Y	FACW	FACW	Arching fronds of this fern are lime to medium-green in color; bronze fall color
<i>Thelypteris</i>	<i>noveboracensis</i>	New York fern	P-S	M-D	1'-2'	N/A	N/A	N	NL	NL	Provides shelter for toads
<i>Thermopsis</i>	<i>villosa</i>	Bush pea	S	M	3'-5'	spring/summer	yellow	N	NL	NL	1" yellow flowers crowd long narrow erect clusters spring/sum; needs water during droughty summers
<i>Tiarella</i>	<i>cordifolia</i>	foamflower	P-S	M	6'-12"	spring	white	N	FAC	FAC	Evergreen groundcover; feathery white flowers Apr-Jun; spreads by underground stems

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Tilia</i>	<i>americana</i>	American linden	F-S	M	60'–80'	spring/summer	yellow	N	FACU	FACU	Clusters of creamy yellow fragrant flowers; flowers attract native bees and honey bees; this tree attracts predatory insects that prey on insect pests and supports biological control efforts
<i>Tradescantia</i>	<i>virginiana</i>	Virginia spiderwort	F-P-S	D-M	3'	spring/summer	blue, purple	N	FAC	FACU	Adaptable to various soil conditions; Juglones tolerant
<i>Trillium</i>	<i>grandiflorum</i>	white trillium	P-S	M	8'–16"	spring/summer	white	N	NL	NL	A single large, white, long-lasting flower arises above the leaf whorl
<i>Tsuga</i>	<i>canadensis</i>	Canadian hemlock	F-S	M	40'–60'	spring	yellow	N	FACU	FACU	When grown in sun this evergreen requires consistent watering; attracts showy insects such as butterflies and moths
<i>Ulmus</i>	<i>alata</i>	winged elm	PS	D	30'–40'	spring	yellow/green	Y	FACU	FACU	Dull-yellow fall color; fast-growing shade tree used for cover and as a nesting site; attracts birds, butterflies, and small mammals.
<i>Ulmus</i>	<i>americana</i>	American elm	F-P	M	80'	spring	red, green	N	FAC	FACW	Was once a common tree but has been largely eradicated due to Dutch elm disease.
<i>Vaccinium</i>	<i>arboreum</i>	farkleberry	PS	D	12'–15'	spring/summer	white	Y	FACU	FACU	Red fall color; fruit attracts birds and mammals.
<i>Vaccinium</i>	<i>corymbosum</i>	highbush blueberry	F-P	W-D	6'–12'	spring/summer	white to pink	Y	FACW	FACW	Excellent fall color that is red, orange, yellow, and sometimes purple; fruit readily eaten by humans and wildlife.
<i>Vaccinium</i>	<i>darrowii</i>	evergreen blueberry	P	M	1'–3'	spring	pink to white	N	FACU	NL	Small, blue-green leaves with a whitish bloom and pink to white, urn-shaped flowers.
<i>Vaccinium</i>	<i>elliottii</i>	Elliot's blueberry	F-P	W-M	12'	spring	pink	N	FACW	FACW	Flowers appear before the leaves and are bell-shaped; blue-black fruit; best in full sun.
<i>Vaccinium</i>	<i>pallidum</i>	lowbush blueberry	F-P	M-D	12'–16"	spring	white/pink	N	NL	NL	Sets some fruit even in shade; has white/pink flowers; fruit attracts birds.
<i>Vaccinium</i>	<i>stamineum</i>	deerberry	F-P	M	10'–15'	spring/summer	white	N	FACU	FACU	Twisted trunks; bell-shaped flowers; sweet, spicy-tasting fruit; birds and mammals eat berries.
<i>Vallisneria</i>	<i>americana</i>	eelgrass	F-P	W	6'–12"	spring to summer	green	N	OBL	OBL	grow from stoloniferous clumps submerged underwater. In shallow water, leaves may reach and float on the surface; important food source for turtles.
<i>Verbena</i>	<i>hastata</i>	swamp verbena	F-P	M	3'–5'	summer	purple	N	FAC	FACW	Used by native bees; reseeds.
<i>Vernonia</i>	<i>gigantea</i>	giant ironweed	F-S	M	5'–8'	fall	purple	N	FAC	FAC	Attracts bees.
<i>Vernonia</i>	<i>noveboracensis</i>	New York ironweed	F	M-W	4'–7'	summer	red, purple	N	FACW	FACW	Intense reddish-purple, thistle-like heads; flowers attract butterflies and seeds attract birds.
<i>Viburnum</i>	<i>acerifolium</i>	mapleleaf viburnum	F-P	M-D	4'–6'	spring/summer	white	Y	FACU	UPL	Pie-shaped clusters of creamy-white flowers; beautiful fall color; attracts birds and butterflies.
<i>Viburnum</i>	<i>dentatum</i>	arrowwood	F-P	W-M	6'–12'	spring	white	Y	FAC	FAC	Creamy-white blooms in spring; yellow to red fall color; attracts many different birds; butterfly attractant.
<i>Viburnum</i>	<i>nudum</i>	possumhaw	F-S	W-M	6'–8'	summer	white	Y	FACW	OBL	Showy clusters of white flowers in May and June; berries turn pink to blue to black; attracts birds and small mammals.

Genus	Specific Epithet	Common Name	Sun	Moisture	Height	Bloom Season	Flower Color	Fall Color	WIS AGCP	WIS EMP	Comments
<i>Virburnum</i>	<i>obovatum</i>	small-leaf arrowwood	P	M	12'-18'	spring	white	N	FACW	FACW	White flowers appear while the leaves develop and are followed by red fruits.
<i>Viburnum</i>	<i>prunifolium</i>	smooth blackhaw	P	M	12'-15'	spring	white	Y	FACU	FACU	Fruit is consumed by songbirds, gamebirds, and mammals and can be made into preserves.
<i>Viburnum</i>	<i>rufidulum</i>	blackhaw viburnum	F-S	D-M	10'-15'	spring	white	Y	UPL	UPL	Showy clusters of white flowers that leap out from foliage; attracts nectar insects, butterflies, and bees.
<i>Viola</i>	<i>egglestonii</i>	glade violet	P-S	D-M	6"	spring	purple, violet, blue	N	NL	NL	
<i>Viola</i>	<i>papilionacea</i>	common blue violet	PS	W	4"	spring	purple	N	NL	NL	
<i>Viola</i>	<i>pedata</i>	birdfoot violet	F-S	D	4'-10"	spring to summer	blue, purple	N	FACU	FACU	Clumping; reproduces by seeds unlike other violets that reproduce vegetatively.
<i>Viola</i>	<i>sororia</i>	blue violet	S-P	M	6'-10"	spring	white, blue, purple, pink	N	FAC	FAC	Attracts birds; leaves and flowers edible; leaves high in vitamins A and C.
<i>Vitis</i>	<i>rotundifolia</i>	muscadine	F-P	M	90'	summer	yellow	N	FAC	FAC	Flowers in June; bark is not exfoliating; purple, black, or bronze berries ripen in Sept or Oct.
<i>Wisteria</i>	<i>frutescens</i>	American wisteria	F-S	M	25'-30'	spring	white, pink to purple	N	FACW	FACW	Deciduous vine; flowers appear after plant has leafed out unlike nonnative wisterias; less aggressive compared to nonnatives; attracts butterflies.
<i>Woodwardia</i>	<i>areolata</i>	chainfern	P-S	M-W	1'-2'	N/A	N/A	N	OBL	FACW	Provides cover for frogs, toads, and newts.
<i>Xanthorhiza</i>	<i>simplicissima</i>	yellowroot	F-S	M	2'-3'	spring	purple	N	FACW	FACW	Bright green celery-like foliage; racemes of purple flowers.
<i>Yucca</i>	<i>aloifolia</i>	aloe yucca	F	D	6'-12'	summer	white	N	UPL	FACU	The evergreen leaves are thick and stiff and up to 2' long, with tiny, sharp serrations.
<i>Yucca</i>	<i>filamentosa</i>	Adam's needle yucca	F	M-D	2'-3'	spring to summer	white	N	NL	NL	Flower stalk can be as high as 6'; attracts butterflies and moths.
<i>Zephyranthes</i>	<i>atamasca</i>	atamasc lily	P	W-M	8'-15"	spring	white	N	FACW	FACW	Colony forming; will bloom best with one to two hours of direct sun or three or more hours of dappled light; tolerant of seasonal flooding.

Sun Exposure: F = Full Sun, P = Part Sun, S = Shade

Soil Moisture: W = Wet, M = Moderate, D = Dry

Wetland Indicator Stats (WIS): OBL = Oligate, FAC = Facultative, FACU = Facultative Upland, UPL = Upland

NI = No Indicator, insufficient information available to determine indicator status, NL = Not Listed

INVASIVE PLANT REMOVAL

Remove invasive plant species prior to construction of LID practices and, if possible, before seed production to prevent seeds from spreading during or after plant removal. A list of Alabama invasive plants can be found through the Alabama Invasive Plant Council (www.se-eppc.org/alabama).

Mechanical

Mechanical removal of invasive plants includes hand pulling, digging, or the use of a weed wrench or other equipment. When removing invasive plants through mechanical means it is important to remove as much of the original root system as possible. Many invasive plants have the ability to regenerate from root fragments left behind.

Hand pulling: Hand pulling is usually successful for small stands of weeds with stems less than three inches in diameter.

Equipment: Weed wrenches can be used for three-inch or greater diameter trunks; these tools use leverage to remove above- and belowground portions of invasive plants.

Erosion and sediment Control: Mechanical removal usually causes some soil disturbance to areas, making them vulnerable to invasion by other invasive plants. When removing invasives from large spaces, stabilization may be necessary using seed, straw, or other means. (See the Alabama Handbook for Erosion Control, Sediment Control, and Stormwater Management on Construction Sites and Urban Areas.)

Chemical

Chemical control of invasive plants uses herbicides to manage target plants. Herbicide activity results in yellowing foliage, necrotic (blackened) spots, or necrotic margins, and it may take a month or longer to work. Reapply as new growth appears. There are many chemical treatments, and choosing the best one is largely dependent on the target plant species for control.

Herbicide dyes: These are helpful to prevent unneeded reapplication of the herbicide and to keep track of target plants.

Recommendations by species: Many plant species have specific chemical recommendations and a recommended application window for best control.

More information can be found in the Forest Service book, *Nonnative Invasive Plants of Southern Forests: A Field Guide for Identification and Control* (www.srs.fs.usda.gov/pubs/gtr/gtr_srs062/). A summary of chemical herbicide application methods can be found in Table D.2.

Cut stump treatments: Cut stump or stem treatments involve cutting an invasive plant stem down to the ground and then applying herbicide to the cut. This method is recommended for low-density invasive species removal since the manual labor involved can be extensive when many stems require cutting. These treatments require higher concentrations of the active ingredient and should contain a minimum of 41 percent of the active ingredient. This method works best on stems that are greater than 0.5 inch in diameter. Stems should be cut close to ground level but still be visible so that you do not lose sight of them; however, in cases where reapplication may be necessary, it is best to cut down to four to six inches to leave room for additional cut-stem applications in case of resprouting. Herbicide can be applied directly to the cut on smaller stems using a sponge, paint brush, or spray bottle. Do this quickly after stem cuts are made to ensure effectiveness. For stumps greater than six inches in diameter, herbicide should be painted or sprayed all the way around the stump and to the areas immediately inside the bark. (For more information, please refer to www.aces.edu/pubs/docs/A/ANR-1465/ANR-1465-low.pdf.)

Foliar applications: Foliar applications are recommended for large monotypic stands of invasive plants and can be a selective or nonselective treatment. Selective treatments target specific invasives and can leave other plants unharmed. Nonselective herbicides (e.g., glyphosate) eradicate any vegetation where they are applied. Rain should not be forecast for the 24 to 48 hours following foliar sprays. Foliar applications are recommended for invasive plants that are less than eight feet tall; however, taller woody vines can be cut to three to five feet tall and treated below the cut, or basal bark applications may be made. Foliar applications can be sprayed whenever leaves are present, but midsummer to late fall applications are most effective for woody plants. Applications made during winter or spring can be helpful to discourage seed formation and further invasion of plants. Basal bark applications are most effective on trees of eight feet or less diameter breast height (dbh).

Basal bark application: Basal bark herbicide applications are appropriate for moderate to low-density invasive plant control. This method is selective, and there is little danger of injuring adjacent vegetation. The application is made using a backpack sprayer. A herbicide oil penetrant mixture is applied to the

lower stem or trunk of woody vegetation. (For more information, refer to www.aces.edu/pubs/docs/A/ANR-1466/ANR-14612.pdf.)

Disposal: Properly dispose of invasive plants so that rerooting does not occur. Do not pull weeds and set them immediately back on the ground; instead, place head first in the collection bag for disposal to avoid further spread of seeds or plant parts. Bagging on-site is best so plant pieces are not spread to other sites. Soft-tissue weeds can be placed in black or clear heavy-duty plastic garbage bags to be solarized (i.e., dried in the sun). Plastic sheeting or tarps can be used to dry plants between them, but this method may take several weeks to completely dry weeds. Burning is an acceptable form of disposal, but local codes and ordinances should be checked prior. Be aware that some plants such as poison ivy can cause irritation if inhaled. Composting is not recommended unless weeds are known not to reproduce vegetatively (i.e., through rooting of plant stems, etc.) or there are no flowers and/or seeds present.

WETLAND AREAS AND AQUATIC INVASIVES CONTROL

Most aquatic invasive plants form dense canopies similar to terrestrial invasive plants. Flood-prone areas are subject to invasion by invasive plant species that prefer those conditions. Aquatic invasive species should be controlled using a systemic herbicide specifically labeled for aquatic use. Some species can be controlled by water level or by creating conditions unfavorable to the species. For example, cattails (*Typha latifolia*) can be controlled by deep flooding for several weeks during the growing season after stems are cut. In some cases, the application of these herbicides may require a pesticide applicator's permit.

NATIVE PLANT NURSERIES AND RESOURCES

The following is a list of nurseries in the Southeast with native plant stock:

- Biophilia Nature Center, Elberta, AL, 251.986.1200, www.biophilia.net
- Arborgen SuperTree Nursery, 264 County Rd. 888, Selma, AL, 334.872.5452
- Joshua Timberlands, LLC., contact Sam Campbell, Elberta, AL, 251.9812.5210
- Tom Dodd Nurseries, Semmes, AL, 1.887.8612.3633
- Mulberry Woods Native Plant Nursery and Farm, Hayden, AL, 205-586-9138, www.mulberrywoodsnursery.com
- Blooming Colors, 1192 S. Donahue Dr., Auburn, AL, 334.821.7929

- Nearly Native Nursery, 776 McBride Rd. Fayetteville, GA, www.nearlynativenursery.com
- Superior Trees, Lee, FL, www.superiortrees.net
- Mellow Marsh Farm, Siler City, NC, www.mellowmarshfarm.com
- Foggy Mountain Nursery, Lansing, NC, www.foggymtn.com

REFERENCES

- Alpert, P., E. Bone, C. Holzapfel. 2000. "Invasiveness, invisibility, and the role of environmental stress in the spread of non-native plants." *Perspectives in Plant Ecology, Evolution, and Systematics* Vol 3: 52–512.
- Bailey, D. A., and M. A. Powell. 1999. "Installation and Maintenance of Landscape Bedding Plants." <http://www.ces.ncsu.edu/depts/hort/hil/hil-5512.html>.
- Bogash, S. M., and L. Adams, ed. 2002. "Handling and Planting 'Bare Root' Plants." Penn State Cooperative Extension.
- Brown, P. 2000. "Basics of Evaporation and Evapotranspiration." *Turf Irrigation Management Series* AZ1194. University of Arizona Cooperative Extension.
- Brown, R., and W. F. Hunt. 2009. "Improving Exfiltration from BMPs: Research and Recommendations." *Urban Waterways*. North Carolina Cooperative Extension System.
- Chen, Y., R. P. Bracy, A. D. Owings, and D. J. Merhaut. 2009. "Nitrogen and Phosphorus Removal by Ornamental and Wetland Plants in a Greenhouse Research System." *HortScience* 44(6): 1704–179.
- Christian, K. J., A. N. Wright, J. L. Sibley, E. F. Brantley, J. A. Howe, and C. LeBleu. 2012. "Effect of Phosphorus Concentration on Growth of *Muhlenbergia capillaris* in Flooded and Non-Flooded Conditions." *Journal of Environmental Horticulture* 30(4): 219–222.
- Dirr, M. A. 1997. *Manual of Wood Landscape Plants*. Champaign, IL: Stipes Publishing L.L.C.
- Drew, M. C. 1996. "Anoxia avoidance by selective cell death and aerenchyma formation." *Ann. Rev. Plant Mol. Biol.* 48:223–250.
- Dylewski, K. L., A. N. Wright, K. M. Tilt, and C. LeBleu. 2009. "Effects of Short Interval Cyclic Flooding on Growth and Survival of Three Native Shrubs." *HortTechnology* 21(4): 461-4612.
- Dylewski, K. L., A. N. Wright, K. M. Tilt, and C. LeBleu. 2012. "Effect of Previous Flood Exposure on Flood Tolerance and Growth of Three Landscape Shrub Taxa Subjected to Repeated Short-term Flooding." *Journal of Environmental Horticulture* 30(2): 58–64.
- Enloe, S., N. Loewenstein, and D. Cain. 2007. "Cut Stump Herbicide Treatment for Invasive Plants in Pastures, Natural Areas, and Forests." *Agronomy and Soils Series*. Alabama Cooperative Extension System ANR–14612.
- Enloe, S., N. Loewenstein, W. Kelley, A. Brodbeck. 2007. "Basal Bark Herbicide Treatment for Invasive Plants in Pastures, Natural Areas, and Forests." *Agronomy and Soils Series*. Alabama Cooperative Extension System ANR–14612.
- Floridata. Accessed May 2, 2009. www.floridata.com/ref/l/ilex_ver.cfm.
- Griffin, A. B., A. N. Wright, K. M. Tilt, and D. J. Eakes. 2010. "Post-transplant irrigation scheduling for two native deciduous shrub taxa." *HortScience* 45:1620–16212.
- Griffin, J. J., T. G. Ranney, and D. M. Pharr. 2004. "Heat and Drought Influence on Photosynthesis, Water Relations, and Soluble Carbohydrates of Two Ecotypes of Redbud (*Cercis canadensis*)." *J. Amer. Soc. Hort. Sci.* 129(4): 497–502.
- Han, D., and E. Huckabay. 2008a. "Selecting turfgrasses for home lawns." Alabama Cooperative Extension System ANR–92.
- Han, D., and E. Huckabay. 2008b. "Bermudagrass Lawns." Alabama Cooperative Extension System ANR–29.
- Harper, C. A., and P. D. Keyser. 2007. "Potential Impacts on Wildlife of Switchgrass Grown for Biofuels." University of Tennessee Biofuels Initiative.
- Hobbs, R. J., and S. E. Humphrees. 1991. "An integrated approach to the ecology and management of plant invasions." *Conservation Biology* 9:761–770.
- Jernigan, K. J., and A. N. Wright. 2009. "Effect of Repeated Short Interval Flooding Events on Root and Shoot Growth of Four Landscape Shrub Taxa." *Journal of Environmental Horticulture* 29(4): 220–222.
- Krüger, G. H. J., and L. van Rensburg. 1991. "Carbon dioxide fixation: Stomatal and non-stomatal limitation in drought stressed *Nicotiana tabacum* L. cultivars." In: P. Mathis, ed. *Photosynthesis: From light to biosphere* vol 4. Dordrecht, The Netherlands: Kluwer Academic Publishers.
- Li, M., J. R. Schutt, J. McFalls, E. R. Bargenhagen, C. Y. Sung, and L. Wheelock. 2007. "Successional Establishment, Mowing Response, and Erosion Control Characteristics of Roadside Vegetation in Texas." College Station, TX: Texas Transportation Institute.
- Madsen, J. D. "Impact of Invasive Aquatic Plants on Aquatic Biology" (ch.1.) In: *Biology and Control of Aquatic Plants: A Best Management Practices Handbook*, eds. L. A. Gettys, W. T. Haller, and M. Bellaud. Marietta, GA: Aquatic Ecosystem Restoration Foundation.
- Mattrick, C. 2001. "Managing Invasive Plants: Methods of Control." *Conservation Notes from the New England Wild Flower Society* 20–23.

- Mitsch, W. J., and J. G. Gosselink. 2006. *Wetlands* 4th ed. Hoboken, N.J.: John Wiley & Sons Publishing.
- Nilsen, E. T., and D. M. Orcutt. 1991. "Flooding" 362–400. In: *Physiology of Plants Under Stress*, eds. E. T. Nilsen and D. M. Orcutt. Hoboken, N.J.: John Wiley & Sons Publishing.
- North Carolina Department of Forestry and Natural Resources. 2007. *Riparian and Wetland Tree Planting Pocket Guide for North Carolina* 2nd ed.
- Polomski, B., and D. Shaughnessy. 2003. "Aerating Lawns" HGIC 1200. Revised by T. Hale. Clemson Cooperative Extension.
- Price, J. G., A. N. Wright, K. M. Tilt, and R. S. Boyd. 2009. "Organic matter application improves posttransplant root growth of three native woody shrubs." *HortScience* 44:377–383.
- Privet. Accessed May 30, 2012. http://plants.usda.gov/plantguide/pdf/pg_lisi.pdf.
- Reichard, S. H., and P. White. 2001. "Horticulture as a pathway to invasive plant introductions in the United States." *BioScience* 51:103–17.
- Rosenweig, M.L. 1991. *Species diversity in space and time*. New York: Cambridge University Press.
- Swank, W. T., and D. A. Crossley, eds. 1986. "Forest hydrology and ecology at Coweeta." *Ecological Studies* vol. 612. New York: Springer-Verlag.
- Tallamy, D. 2009. *Bringing Nature Home*. Portland, OR: Timberpress.
- Tallamy, D. 2010. "Why Native Plant Species are Essential for Supporting Biodiversity." Alice M. Leahy Lecture Series, Oct. 19, 2010.
- Tourbier, J. T., and R. N. Westmacott. 1981. *Water Resources Protection Technology: A Handbook for Measures to Protect Water Resources in Land Development*. Washington, D.C.: Urban Land Institute.
- United States Department of Agriculture and Natural Resources Conservation Service. 1991. *Guidelines for Establishing Aquatic Plants in Constructed Wetlands*. Athens, GA: NRCS.
- United States Department of Agriculture and the Natural Resources Conservation Service. 2001. *Plant Guide: Chinese*.
- United States Environmental Protection Agency. 1987. *Design Manual: Constructed Wetlands and Aquatic Plant Systems for Municipal Wastewater Treatment*.
- United States Geological Survey. 2012. "The Water Cycle: Transpiration." Accessed May 31, 2012. <http://ga.water.usgs.gov/edu/watercycletranspiration.html>.
- University of New Hampshire Cooperative Extension. 2010. "Methods for Disposing of Non-Native Invasive Plants," ed. Karen Bennet.
- West, D. H., K. Tilt, D. Williams, and H. Ponder. 2001. "Street Trees: Site Selection, Planting, and Maintenance in the Urban Landscape." Alabama Cooperative Extension System ANR-089.
- Williamson, M. 1991. *Biological Invasions*. London: Chapman-Hill.
- Wilson, C. 2010. "Don't Power Rake to Remove Lawn Thatch." Accessed: May 6, 2012. Denver County Extension. <http://www.colostate.edu/Depts/CoopExt/4DMG/Lawns/aerate.htm>.
- Wright, A. N., R. D. Wright, J. Browder, and B. E. Jackson. 2006. "Effect of backfill composition on post-transplant root growth of *Kalmia latifolia*." *Journal of Environmental Horticulture* 25:145–149.
- Wright, A. N., S. L. Warren, and F. A. Blazich. 2006. "Root-zone temperature influences root growth of *Kalmia latifolia* taxa and *Ilex crenata* 'Compacta'." *Journal of Environmental Horticulture* 25:73–76.
- Wright, A. N., S. L. Warren, F. A. Blazich, and U. Blum. 2004. "Root and shoot growth periodicity of *Kalmia latifolia* 'Sarah' and *Ilex crenata* 'Compacta'." *HortScience* 39:243–246.
- Yu, S. L., M. A. Kasnick, and M. R. Byrne. 1993. "A Level Spreader/Vegetated Buffer Strip System for Urban Stormwater Management." In: *Integrated Stormwater Management*, eds. R. Field, M. L. O'Shea, and K. Chin. Boca Raton, FL: Lewis Publishers.

ADEM

Alabama Department of Environmental Management

Related Glossary Terms

Drag related terms here

Index

Find Term

ADPH

Alabama Department of Public Health

Related Glossary Terms

Drag related terms here

Index

Find Term

AGCP

Atlantic Gulf Coastal Plains

Related Glossary Terms

Drag related terms here

Index

Find Term

ALDOT

Alabama Department of Transportation

Related Glossary Terms

Drag related terms here

Index

Find Term

ALNHP

Alabama Natural Heritage Program

Related Glossary Terms

Drag related terms here

Index

Find Term

ASTM

American Society for Testing and Materials

Related Glossary Terms

Drag related terms here

Index

Find Term

BOD

Biochemical Oxygen Demand

Related Glossary Terms

Drag related terms here

Index

Find Term

BRC

Bioretention Cell

Related Glossary Terms

Drag related terms here

Index

Find Term

CC

Curb Cut

Related Glossary Terms

Drag related terms here

Index

Find Term

Cfs

cubic feet per second

Related Glossary Terms

Drag related terms here

Index

Find Term

CGP

Concrete Grid Pavers

Related Glossary Terms

Drag related terms here

Index

Find Term

CN

Curve number

Related Glossary Terms

Drag related terms here

Index

Find Term

CPESC

Certified Erosion and Sediment Control Professional

Related Glossary Terms

Drag related terms here

Index

Find Term

CRF

Controlled Release Fertilizer

Related Glossary Terms

Drag related terms here

Index

Find Term

CSW

Constructed Stormwater Wetland

Related Glossary Terms

Drag related terms here

Index

Find Term

CWA

Clean Water Act

Related Glossary Terms

Drag related terms here

Index

Find Term

DA

Drainage area

Related Glossary Terms

Drag related terms here

Index

Find Term

DD

Disconnected Downspout

Related Glossary Terms

Drag related terms here

Index

Find Term

Chapter 1 - Overview

DIY

Do-it-yourself

Related Glossary Terms

Drag related terms here

Index

Find Term

EMP

Eastern Mountains Piedmont

Related Glossary Terms

Drag related terms here

Index

Find Term

FAC

Facultative wet

Related Glossary Terms

Drag related terms here

Index

Find Term

FACW

Facultative wet

Related Glossary Terms

Drag related terms here

Index

Find Term

FEMA

Federal Emergency Management Agency

Related Glossary Terms

Drag related terms here

Index

Find Term

Fps

feet per second

Related Glossary Terms

Drag related terms here

Index

Find Term

GFS

Grassed Filter Strip

Related Glossary Terms

Drag related terms here

Index

Find Term

GI

Green Infrastructure

Related Glossary Terms

Drag related terms here

Index

Find Term

Gpm

gallons per minute

Related Glossary Terms

Drag related terms here

Index

Find Term

GR

Green Roof

Related Glossary Terms

Drag related terms here

Index

Find Term

GS

Grassed Swale

Related Glossary Terms

Drag related terms here

Index

Find Term

HOA

Home Owner's Association

Related Glossary Terms

Drag related terms here

Index

Find Term

HSG

Hydrologic Soil Group

Related Glossary Terms

Drag related terms here

Index

Find Term

IA

Impervious area

Related Glossary Terms

Drag related terms here

Index

Find Term

IBC

International Building Code

Related Glossary Terms

Drag related terms here

Index

Find Term

IDF curve

Intensity-Duration-Frequency curve

Related Glossary Terms

Drag related terms here

Index

Find Term

IS

Infiltration Swale

Related Glossary Terms

Drag related terms here

Index

Find Term

IWS

Internal water storage

Related Glossary Terms

Drag related terms here

Index

Find Term

LA

Landscape Architect

Related Glossary Terms

Drag related terms here

Index

Find Term

LEED

Leadership in Energy and Environmental Design

Related Glossary Terms

Drag related terms here

Index

Find Term

LID

Low Impact Development

Related Glossary Terms

Drag related terms here

Index

Find Term

LS

Level Spreader

Related Glossary Terms

Drag related terms here

Index

Find Term

MOU

Memorandum of Understanding

Related Glossary Terms

Drag related terms here

Index

Find Term

MS4

Municipal Separate Storm Sewer Systems

Related Glossary Terms

Drag related terms here

Index

Find Term

NOAA

National Oceanic and Atmospheric Administration

Related Glossary Terms

Drag related terms here

Index

Find Term

NPDES

National Pollutant Discharge Elimination System

Related Glossary Terms

Drag related terms here

Index

Find Term

NPS

Nonpoint Source Pollution

Related Glossary Terms

Drag related terms here

Index

Find Term

NRCS

Natural Resources Conservation Service

Related Glossary Terms

Drag related terms here

Index

Find Term

OBL

Obligate

Related Glossary Terms

Drag related terms here

Index

Find Term

PA

Porous Asphalt

Related Glossary Terms

Drag related terms here

Index

Find Term

PC

Pervious Concrete

Related Glossary Terms

Drag related terms here

Index

Find Term

PE

Professional Engineer

Related Glossary Terms

Drag related terms here

Index

Find Term

PICP

Permeable Interlocking Concrete Pavers

Related Glossary Terms

Drag related terms here

Index

Find Term

PP

Permeable Pavement

Related Glossary Terms

Drag related terms here

Index

Find Term

PRG

Plastic Reinforcement Grids

Related Glossary Terms

Drag related terms here

Index

Find Term

Psf

pounds per square foot

Related Glossary Terms

Drag related terms here

Index

Find Term

Psi

pounds per square inch

Related Glossary Terms

Drag related terms here

Index

Find Term

RB

Riparian Buffers

Related Glossary Terms

Drag related terms here

Index

Find Term

RG

Rain Gardens

Related Glossary Terms

Drag related terms here

Index

Find Term

ROW

Right-of-Way

Related Glossary Terms

Drag related terms here

Index

Find Term

RW

Rainwater Harvesting

Related Glossary Terms

Drag related terms here

Index

Find Term

SA

Surface Area

Related Glossary Terms

Drag related terms here

Index

Find Term

SCM

Stormwater Control Measure

Related Glossary Terms

Drag related terms here

Index

Find Term

SITES

Sustainable Sites Initiative

Related Glossary Terms

Drag related terms here

Index

Find Term

TRM

Turf Reinforced Matting

Related Glossary Terms

Drag related terms here

Index

Find Term

TSS

Total Suspended Solids

Related Glossary Terms

Drag related terms here

Index

Find Term

UPL

Upland

Related Glossary Terms

Drag related terms here

Index

Find Term

USACE

United States Army Corps of Engineers

Related Glossary Terms

Drag related terms here

Index

Find Term

USDA

United States Department of Agriculture

Related Glossary Terms

Drag related terms here

Index

Find Term

USEPA

United States Environmental Protection Agency

Related Glossary Terms

Drag related terms here

Index

Find Term

USFWS

United States Fish and Wildlife Service

Related Glossary Terms

Drag related terms here

Index

Find Term

USGBC

United States Green Building Council

Related Glossary Terms

Drag related terms here

Index

Find Term

WIS

Wetland indicator status

Related Glossary Terms

Drag related terms here

Index

Find Term

WS

Wet Swale

Related Glossary Terms

Drag related terms here

Index

Find Term